

Addition

The additional multi message sign panels detailed in Table A.2 are accepted for use in Queensland.

Table A.2 — List of additional multi-message sign panels for use in Queensland

Sign	Sign number	Size (mm)	Figure	Notes
Advance				
BUILDING WORK AHEAD	TM1-1-Q01A TM1-1-Q01C	600 x 600 1200 x 600		The BUILDING WORK AHEAD sign may be used where construction activities are located on private property next to a road and the construction activities may impact on the operation of the road. Examples 
Trucks	TM2-25-Q01C	1200 x 600		