

Sign	Sign number	Size (mm)	Figure	Notes
Detour U-Turn (symbolic)	TM5-1-Q02	600 x 600		Shall only be used with a DETOUR panel (TM5-7A or TM5-7B). Examples  
PLANT AHEAD	TM1-27-Q01	1200 x 300		
ROAD WORK	TM1-5-Q01A TM1-5-Q01B	600 x 600 1200 x 300		
Road condition				
WATER OVER ROAD	TM3 21 Q01	1200 x 300		Refer to Q series sign notes. This sign shall only be used to indicate that the road is trafficable with care although there is water over the road.