

Added reference to QGTTM Part 2 for additional considerations when selecting lane widths. Especially when travel paths are confined on each side by physical barriers and/or hazards (for example excavation), it is important to consider any impact of breakdowns and congestion for emergency vehicle access.

See changes highlighted yellow following.

2.5.8 Lane widths

Difference

Replace the entire Section 2.5.8 with the following:

Lanes carrying traffic around, through or past a roadworks site shall be as per Table 2.5. Lane widths should consider accommodating the swept path of large vehicles expected to negotiate the roadworks site.

Table 2.5 – Lane widths

Criteria	Lane width (m)
General lane widths	
≤60 km/h	Minimum 3.0*
70, 80 or 90 km/h	Minimum 3.2*
≥100 km/h	Minimum 3.4*
Curve with radius 100–250 m	Add curve widening of 0.5 m per lane
Curve with radius <100 m	In addition to the curve widening of 0.5 m per lane, consider the swept path of long vehicles (for example, buses, trams)
Two-way residential street	Minimum of 5.5 (sum both ways)
Shuttle flow operation	
Shuttle flow with active control (by traffic controllers or PTCs)	Minimum 3.0*
Shuttle flow, without active control on residential streets, includes no control or the use of GIVE WAY and ONE WAY signs (see Section 5.4.4).	Minimum 3.0* and Maximum 3.5 to ensure vehicles take turns using a single lane