

Entire clause now located in QGTTM to make it easier for the end user to use the document. No longer needing to go back and forth between the QGTTM and AGTTM several times.

Information which was remaining in AGTTM has been relocated to QGTTM and is highlighted blue.

Revised wording of Item 8 to address side road speed limit and end of queue issues on the side road, and the need to consider travel speed when turning onto a side road with traffic control down the side road (it is not always necessary to reduce speed on the through road, but Primary PTS sign may still be required).

Removed reference to “side by side” for the PREPARE TO STOP MMS panel.

Added information on calculating queue lengths and signing options when using multiple lanes for queueing.

See changes highlighted yellow following.

4 Through the worksite

4.8 Advance warning area

Difference

Replace the entire Section 4.8 with the following:

The advance warning area is critical to the success of ‘through’ traffic management and aims to provide:

- no surprises to road users regarding traffic control
- a controlled release of relevant information (e.g. signs)
- repeated information where pertinent to emphasise danger.

It can also reduce traffic in the area by inducing road users to actively plan alternative routes where possible (refer to AGTTM Part 2). Advance warning signs and information also strengthen the delineation of a route and ensure that road users can safely and effectively navigate their way to their intended destinations. Note the following steps in conjunction with Figure 4.4, Figure 4.5 and Figure 4.6 examples when designing the advance warning area for ‘through’ methods:

1. Identify the PTCO or traffic controller position.