

2. STOP HERE ON RED SIGNAL and STOP HERE WHEN DIRECTED must be installed where warranted in accordance with Queensland MUTCD Part 3. When used, they must be installed 6 m before the PTCD / traffic control position in the direction of travel. A temporary STOP line may be installed using temporary removable road marking tape.
3. Four cones should be placed on the centreline spaced 4 m apart starting from the STOP HERE ON RED SIGNAL or STOP HERE WHEN DIRECTED sign position (downstream). A Temporary Hazard marker (T5-7) or KEEP LEFT sign (R2-3-Q01) may be installed at the start of the row of four cones (on both ends of the four cones) to direct traffic to the correct travel path if needed.
4. Estimate end-of-queue position (via the box instructions in Austroads *Guide to Temporary Traffic Management* Part 3 Section 4.8). A marker (for example, a cone or bollard) should be placed on the shoulder at the predicted end-of-queue to assist the traffic controller and traffic management implementer to monitor queue lengths.
5. A PREPARE TO STOP sign must be placed in conjunction with the Boom Barrier or Traffic Controller (symbolic) or Signals Ahead sign a minimum distance as shown in Table 2.3 from the predicted end-of-queue, not the PTCD / traffic controller position. This is the primary PREPARE TO STOP sign.

If the PREPARE TO STOP sign is more than 240 m from the traffic controller, an additional PREPARE TO STOP sign must be placed 120 m from the traffic controller (see Figure 4.4 and Figure 4.5). The primary purpose of this sign is to protect the traffic controller. This is the additional PREPARE TO STOP sign.

If visibility is lost or the distance from the PREPARE TO STOP sign to the PTCD / traffic controller is more than 300 m, the use of repeater PREPARE TO STOP signs should be considered as per Table 4.4(a).

Where these conditions are met and the additional or repeater PREPARE TO STOP signage is required, a Queued Traffic Ahead multi-message sign assembly may be used as the primary PREPARE TO STOP sign. If used, this multi-message sign assembly must include the Queued Traffic (symbolic) (TM1 47A), QUEUED TRAFFIC AHEAD (TM1 46A) and the PREPARE TO STOP (TM1-18B), see Figure 4.8(a) following.

The primary PREPARE TO STOP must be installed in advance of the predicted end-of-queue in accordance with Austroads *Guide to Temporary Traffic Management* Part 3 Table 2.3.