

As per AGTTM Part 7 Section 2.6.3, when used **side by side** in a multi-message situation, the PREPARE TO STOP panel must be placed closest to the travel way and that the 600 x 600 version of this sign is used as illustrated in Figure 4.8(b), excluding where the use of the 1200 x 300 version is specifically permitted by QGTTM.

Figure 4.8(b) – Multi message sign assembly examples (sign located on left side of the road)



Table 4.3: Estimated queue length

Maximum stopping time (minutes)	Multiplier	
	Ma (multiplier for average vehicles)	Mo (multiplier for oversized vehicles)
2	2.4	8
5	6	20
10	12	40
15	18	60
30*	36	120

*A 30 minute stop time is unusual but has been included for some circumstances

For the purpose of estimating the end-of-queue position only, the term 'oversized vehicles' also includes 'heavy vehicles'.

When estimating the queue length, Table 4.3 uses an average vehicle length of 6 m and an average heavy vehicle length of 20 m for a five minute stopping time (based on the five minute traffic count) and then adjusts the multipliers for other stopping time values.

Where very long vehicles are expected (for example outback and mining routes or routes where most vehicles are towing), then to ensure estimated queue lengths are as accurate as possible, an average length per vehicle that matches the actual traffic mix expected at that location should be used.

The estimated queue length must be at least a minimum of one average vehicle plus one heavy vehicle (of a length which may be applicable to the site). Part lengths of vehicles must be rounded up when estimating queue lengths.

To calculate the 'maximum stopping time' value used in Table 4.3 for each approach, the Traffic Management Designer must estimate the likely duration of time that queued traffic will be stopped at a traffic control station. Calculating