



Bent direction – coming from the type of material – preferred away from the mid of the datum plane A.

1:2