











Common Sheets:
500 GRID
600 USB_POWER
700 MCU

Module Specific:
800 HWCFG
900 LED
1000 UI

Sheet: /		
File: PCBA-PBF4.kicad_sch		
Title:		
Size: A3	Date:	**Rev:**
KiCad E.D.A. 9.0.6		Id: 1/15

1000



Sheet: /UI_POT/		
File: UI_POT.kicad_sch		
Title:		
Size: A4	Date:	**Rev:**
KiCad E.D.A. 9.0.6		Id: 2/15

1000

Simulation:

http://tinyurl.com/y229mty4



Sheet: /UI_BUTTON/		
File: UI_BUTTON.kicad_sch		
Title:		
Size: A4	Date:	**Rev:**
KiCad E.D.A. 9.0.6		Id: 3/15

900



Sheet: /UI_LED/		
File: UI_LED.kicad_sch		
Title:		
Size: A4	Date:	**Rev:**
KiCad E.D.A. 9.0.6		Id: 4/15

1000



Sheet: /Sheet5D7C8BFD/		
File: UI_MUX.kicad_sch		
Title:		
Size: A4	Date:	**Rev:**
KiCad E.D.A. 9.0.6		Id: 5/15

1000



Sheet: /sheet5D8763D6/		
File: UI_MUX.kicad_sch		
Title:		
Size: A4	Date:	**Rev:**
KiCad E.D.A. 9.0.6		Id: 6/15

700

USB_POWER

USB_DP
USB_DN
U0TXD
U0RXD
ESP_RESET
ESP_BOOT0

USB_DATA_P
USB_DATA_N
DEBUG_TX
DEBUG_RX
DEBUG_RESET
DEBUG_BOOT0

File: USB_POWER.kicad_sch

Power

+3V3
GZ2012D601TF
L702
PWR_FLAG
+3V3 VDD_SPI +3V3
+3V3

C743 10u
C746 1u
C747 100n
C749 100n
C751 100n
C752 100n
C753 10n
C754 1u

GND

ESP32-S3

ESP32-S3
U704

ESP_RESET	4	CHIP_PU	
ESP_LNA	1	LNA_IN	
USB_DN	25	GPIO19	D-
USB_DP	26	GPIO20	D+
	28	GPIO26	SPICS1
SPIHD	30	GPIO27	SPIHD
SPIWP	31	GPIO28	SPIWP
SPICS0	32	GPIO29	SPICS0
SPICLK	33	GPIO30	SPICLK
SPIQ	34	GPIO31	SPIQ
SPID	35	GPIO32	SPID
	54	XTAL_P	
	53	XTAL_N	
TCK	44	GPIO39	MTCK
TDO	45	GPIO40	MTDO
TDI	47	GPIO41	MTDI
TMS	48	GPIO42	MTMS
U0TXD	49	GPIO43	U0TXD
U0RXD	50	GPIO44	U0RXD
	57	GND	
	5	* GPIO0	ESP_BOOT0
	6	GPIO1	ESP_GPIO_1
	7	GPIO2	ESP_GPIO_2
	8	* GPIO3	ESP_GPIO_3
	9	GPIO4	ESP_GPIO_4
	10	GPIO5	ESP_GPIO_5
	11	GPIO6	RP_SPIO_RX
	12	GPIO7	RP_SPIO_CS
	13	GPIO8	RP_SPIO_TX
	14	GPIO9	RP_SPIO_SCK
	15	GPIO10	HWCFG_SHIFT
	16	GPIO11	HWCFG_CLOCK
	17	GPIO12	HWCFG_DATA
	18	GPIO13	RP_SWDIO
	19	GPIO14	RP_SWCLK
	21	GPIO15	RP_CLK
	22	GPIO16	ESP_GPIO_16
	23	GPIO17	RP_INTERRUPT
	24	GPIO18	ESP_GPIO_18
	27	GPIO21	LED_DATA_OUT
	38	GPIO33	ESP_GPIO_33
	39	GPIO34	ESP_GPIO_34
	40	GPIO35	ESP_GPIO_35
	41	GPIO36	ESP_GPIO_36
	42	GPIO37	ESP_GPIO_37
	43	GPIO38	MAP_MODE
	51	* GPIO45	ESP_GPIO_45
	52	* GPIO46	ESP_GPIO_46
	37	GPIO47	ESP_GPIO_47
	36	GPIO48	ESP_GPIO_48

1k R733

40MHz Y701
C748 10p
C750 10p

LCSC:
TXM40M0004322HBCEO00T
S3240000091040JY

RF

J701 C5137195
U.FL-R-SMT-1(80)
L701 1n8
C739 3p9
C742 1p8
ESP_LNA

1.8nH LQG15HS1N8S02D
3.9pF GJM1555C1H3R9WB01D
1.8pF GJM1555C1H1R8BB01D

Programming Interface

RP_UART0_TX
RP_UART0_RX
U0TXD
U0RXD
TMS
TCK
TDO
TDI

Conn_02x05_Odd_Even
J702

Mapmode switch

This pusbutton is acessible through the housing, activates USB bootloader.

+3V3 +3V3
R701 5k1
100n C757
R736 1k
SW701 C255807
MAP_MODE

Internal Pull-up

Reset

+3V3
R735 5k1
SW702 C2905169
ESP_RESET
C758 1u

Boot

SW703 C2905169
ESP_BOOT0

Test Points

ESP_GPIO_47 TP706 TestPoint
ESP_GPIO_48 TP707 TestPoint
ESP_GPIO_34 TP708 TestPoint
ESP_GPIO_33 TP709 TestPoint
TP710 TestPoint

RP2040

+1V1
+3V3
C731 100n
C732 100n
C733 1u
C734 1u
C735 100n
C736 100n
C737 100n
C738 100n
C740 100n
C741 100n
C744 100n
C745 100n

R729 5k1
RP_RUN

U703
RP2040

RP_RUN	26	RUN	
	47	USB_DP	
	46	USB_DM	
	56	QSPI_SS	
	53	QSPI_SD0	
	55	QSPI_SD1	
	54	QSPI_SD2	
	51	QSPI_SD3	
	52	QSPI_SCLK	
RP_CLK	20	XIN	
	21	XOUT	
RP_SWCLK	24	SWCLK	
RP_SWDIO	25	SWD	
	19	TESTEN	
	57	GND	
	45	VREG_VOUT	
	23	DVDD	
	1	IOVDD	
	48	USB_VDD	
	43	ADC_AVDD	
	44	VREG_IN	
	2	GPIO0	RP_UART0_TX
	3	GPIO1	RP_UART0_RX
	4	GPIO2	GRID_SOUTH_TX
	5	GPIO3	GRID_WEST_RX
	6	GPIO4	GRID_SYNC_2
	7	GPIO5	GRID_WEST_TX
	8	GPIO6	GRID_NORTH_RX
	9	GPIO7	
	11	GPIO8	
	12	GPIO9	
	13	GPIO10	
	14	GPIO11	
	15	GPIO12	TP701 TestPoint
	16	GPIO13	TP702 TestPoint
	17	GPIO14	TP703 TestPoint
	18	GPIO15	TP704 TestPoint
	27	GPIO16	RP_SPIO_RX
	28	GPIO17	RP_SPIO_CS
	29	GPIO18	RP_SPIO_SCK
	30	GPIO19	RP_SPIO_TX
	31	GPIO20	
	32	GPIO21	
	34	GPIO22	RP_INTERRUPT
	35	GPIO23	GRID_NORTH_TX
	36	GPIO24	GRID_EAST_RX
	37	GPIO25	GRID_SYNC_1
	38	GPIO26_ADC0	GRID_EAST_TX
	39	GPIO27_ADC1	GRID_SOUTH_RX
	40	GPIO28_ADC2	
	41	GPIO29_ADC3	

TP705 TestPoint

GRID Connector

Connector arrays for the interface boards on all four sides of the module.

sheet5D85C9EA

GRID_SYNC_1	GRID_WEST_SYNC_1
GRID_WEST_TX	GRID_WEST_TX
GRID_WEST_RX	GRID_WEST_RX
GRID_SYNC_2	GRID_WEST_SYNC_2
GRID_SYNC_1	GRID_SOUTH_SYNC_1
GRID_SOUTH_TX	GRID_SOUTH_TX
GRID_SOUTH_RX	GRID_SOUTH_RX
GRID_SYNC_2	GRID_SOUTH_SYNC_2
GRID_SYNC_1	GRID_EAST_SYNC_1
GRID_EAST_TX	GRID_EAST_TX
GRID_EAST_RX	GRID_EAST_RX
GRID_SYNC_2	GRID_EAST_SYNC_2
GRID_SYNC_1	GRID_NORTH_SYNC_1
GRID_NORTH_TX	GRID_NORTH_TX
GRID_NORTH_RX	GRID_NORTH_RX
GRID_SYNC_2	GRID_NORTH_SYNC_2

File: GRID.kicad_sch

J799
Conn_01x02

QSPI Flash memory

This memory can be accessed throgh the QSPI interface of the MCU. Can be used for configuration, static data or program execution.

VDD_SPI VDD_SPI
R734 5k1
U705
W25Q64JVSSIQ

SPICS0	1	CS	
SPICLK	6	CLK	
	8	VCC	
	4	GND	
SPID	5	DI(IO0)	
SPIQ	2	DO(IO1)	
SPIWP	3	IO2	
SPIHD	7	IO3	

C755 1u
C756 100n

Sheet: /MCU/
File: MCU.kicad_sch

Title:

Size: A3 | Date: | **Rev:**
KiCad E.D.A. 9.0.6 | Id: 7/15

500

GRID Connector
Bi-Directional Data
2x SYNC



Board Mounting Pattern



Sheet: /MCU/sheet5D85C9EA/		
File: GRID.kicad_sch		
Title:		
Size: A4	Date:	**Rev:**
KiCad E.D.A. 9.0.6		Id: 8/15

600

USB Port

USB C upstream facing port configured for 5V 3A power consumption.



ESD Prot.

ESP protection for all 8 signals externally accessable via the USB C connector.



Debug-Mode Multiplexing

Debug.mode is activated when both CC1 and CC2 are pulled to logic high externally.



3V3 LDO

LDO regulator for generating the +3V3 power rail for the microcontroller and UI.



Testpoints



Sheet: /MCU/USB_POWER/		
File: USB_POWER.kicad_sch		
Title:		
Size: A4	Date:	**Rev:**
KiCad E.D.A. 9.0.6		Id: 9/15

800



Board Identification

Grid firmware can identify the hardware and the board revision thorugh a 3 wire serial interface using one or more shift register as read only memory. The content of the memory is defined by pulling the inputs high or low through pcb traces or solderable configuration jumpers.

4b'Model + 4b'Revision + nb'Reserved (Multiple shift registers)

D0: MODEL (LSB)
D1: MODEL
D2: MODEL
D3: MODEL (MSB)
D4: REVISION (LSB)
D5: REVISION
D6: REVISION
D7: REVISION (MSB)

Model Codes (D3–D0):

Po16 0000
Bo16 0001
PBF4 0010
EN16 0011
...

Revision Codes (D7–D4):

RevA 0000
RevB 0001
RevC 0010
RevD 0011
...

Sheet: /HWCFG/		
File: HWCFG.kicad_sch		
Title:		
Size: A4	Date:	**Rev:**
KiCad E.D.A. 9.0.6		Id: 10/15

simulation









Sheet: /UI_HALL_PREAMP/
File: UI_HALL_PREAMP.kicad_sch

Title:

Size: A4	Date:	**Rev:**
KiCad E.D.A. 9.0.6		Id: 11/15



Sheet: /UI_HALL_PREAMP/INVERT_AND_OFFSET/
File: INVERT_AND_OFFSET.kicad_sch

Title:

Size: A4	Date:	**Rev:**
KiCad E.D.A. 9.0.6		Id: 16/15



Sheet: /UI_HALL_PREAMP/INVERT_AND_OFFSET1/		
File: INVERT_AND_OFFSET.kicad_sch		
Title:		
Size: A4	Date:	**Rev:**
KiCad E.D.A. 9.0.6		Id: 17/15



Sheet: /UI_HALL_PREAMP/INVERT_AND_OFFSET2/		
File: INVERT_AND_OFFSET.kicad_sch		
Title:		
Size: A4	Date:	**Rev:**
KiCad E.D.A. 9.0.6		Id: 18/15



Sheet: /UI_HALL_PREAMP/INVERT_AND_OFFSET3/
File: INVERT_AND_OFFSET.kicad_sch

Title:

Size: A4	Date:	**Rev:**
KiCad E.D.A. 9.0.6		Id: 19/15