

# PSoC<sup>®</sup> 3 and PSoC 5 – SFF-8485 Serial GPIO (SGPIO) Initiator Interface

## AN66019

Author: Jason Konstas Associated Project: Yes

Associated Part Family: All PSoC 3 and PSoC 5 parts

Software Version: PSoC Creator™ 1.0 Associated Application Notes: AN64315

## **Application Note Abstract**

The SGPIO Initiator component enables designers using PSoC 3 or PSoC 5 to add a Serial General Purpose Input/Output (SGPIO) Initiator interface compliant with the Small Form Factor (SFF) Committee SFF-8485 industry standard specification. The SGPIO interface is used in Serial Attached Small Computer System Interface (SAS) and Serial Advanced Technology Attachment (SATA) hard drive enclosure systems. SGPIO is a unique, custom, 4-wire protocol that can not be found in any off-the-shelf microcontroller product. PSoC 3's ability to implement custom interface logic in programmable universal digital blocks makes it an ideal choice for this application.

### Introduction


In storage systems that employ a multitude of hard disk drives using high-speed serial data communication interfaces such as SAS or SATA, there is a need for many general purpose IOs (GPIO) in the system to communicate drive status and to drive LED indicators. To reduce cable bulk, the SFF committee defined an industry standard protocol to serialize those GPIOs in these applications. While the SFF-8485 specification does not limit the number of hard drives supported by a single SGPIO bus link, most implementations support four drives through a 12-bit protocol (3 bits in both directions per drive).

The SGPIO\_Initiator component makes it extremely easy for designers developing HBAs with PSoC 3 or 5 to add multiple SPGIO Initiator interfaces to a single device, enabling a PSoC based HBA supporting many hard drives. The SGPIO\_Initiator implementation is completely hardware based, freeing the CPU in PSoC to implement management protocols such as Intelligent Platform Management Bus/Bridge (IPMB) and the International Blinking Pattern Interpretation (IBPI) defined in SFF-8489 required in these applications.

## **Typical System Storage Application**

A typical system storage application block diagram is shown in Figure 1. The backplane PCB contains the backplane controller, connectors for plugging hard drives and communications cables to the HBAs and the baseboard management controller (BMC), the system host.

Figure 1 Typical System Storage Architecture (image source: http://en.wikipedia.org/wiki/IBPI)



In this example system, four hard drives connect to the backplane. The backplane controller is able to detect the presence of these drives and send rudimentary status information over the SGPIO bus to the HBA responsible for managing the attached drives. The SGPIO Initiator on the HBA receives that information and sends back LED indicator information (on, off, and blinking rates) in accordance with the IBPI standard to drive the LEDs on the backplane. The BMC controller is the system-wide host performing management tasks and is located on the host motherboard connected to the backplane via an I<sup>2</sup>C/System Management Bus (SMBus) physical link.

The PSoC 3 family is an ideal choice for the HBA as it has the programmable digital resources available to implement multiple SGPIO Initiator interfaces in hardware, as well as providing additional  $I^2C$  or other industry standard

interfaces to hard drive controllers together with a highperformance 8051 (PSoC 3) or ARM Cortex M3 (PSoC 5) CPU core for implementing management protocols.

This application note will focus on how to use the SGPIO\_Initiator component in PSoC by working through some example projects on the CY8CKIT-001 PSoC Development Kit (DVK). The examples will show how to support the SFF-8485 specification and get data on and off the SGPIO link reliably. Supporting management protocols and higher level functionality is beyond the scope of this application note.

#### Introduction to the SGPIO Protocol

SGPIO uses a 4-wire protocol as shown in Figure 2. SCLOCK, SLOAD and SDATAOUT are all driven by the SGPIO Initiator. SDATAIN is driven by the SGPIO Target.

SCLOCK is a reference clock provided by the Initiator up to a maximum frequency of 100 kHz.

SLOAD is primarily used as a reference synchronization pulse to indicate the start of each serial frame. Since each

frame carries 3 bits per drive, the typical frame length is 12 bits long supporting four drives. Therefore, the SLOAD pulse is driven high for 1 bit period every 12 bits concurrent with the last bit period of the current frame.

SLOAD is also optionally used to communicate four bits of vendor specific information (L3:0), immediately following the synchronization pulse. The SGPIO Target should look for a pattern of at least five successive logic zero levels on the SLOAD pulse, followed immediately by a logic one level to guarantee synchronization to the SLOAD pulse and to avoid false synchronization on the L3:0 vendor specific information.

SDATAOUT is the LED indicator information (3 bits per drive) sent by the Initiator. It is clocked out of the Initiator on the rising edges of SCLOCK and the target should capture the information on the falling edges of SCLOCK.

SDATAIN is the drive status information (3 bits per drive) sent by the Target. It is also clocked out of the Target on the rising edges of SCLOCK and captured by the Initiator on the falling edges of SCLOCK.




Figure 2. SGPIO Protocol Summary

## Getting Started with the SGPIO\_Initiator Component

Distributed with this application note is a PSoC Creator<sup>TM</sup> bundled project ZIP file that contains three example design projects and a library project that contains the **SGPIO\_Initiator** component and the **SGPIO\_Target** companion component for validation purposes. Save the ZIP file to a convenient location on your hard drive and extract the contents to a local folder.

To get started with the example projects, double-click the *AN66019.cywrk* PSoC Creator workspace file.

- In the Workspace Explorer tab to the left of the screen, expand project Example1 by clicking on the small '+' icon to the left of it.
- Double-click TopDesign.cysch to open the top-level design schematic for the hardware blocks inside PSoC.

Figure 3 shows the top-level design schematic for Example Project 1.

Figure 3. Top-level Design Schematic for Example Project 1


#### SGPIO Example Project 1

SGPIO\_Target is configured for polling mode (interrupts disabled) SGPIO\_Initiator sends a fixed data pattern on SDOUT

SGPIO Target sends a fixed data pattern on SDIN

1st line of LCD displays SDOUT data received by SGPIO\_Target 2nd line of LCD displays SDIN data received by SGPIO\_Initiator





To the right of the schematic is the PSoC Creator Component Catalog. The tab labeled Cypress contains the default library of Cypress-provided content. The tab labeled Reference contains the SGPIO\_Initiator and the SGPIO\_Target components provided with this application note as part of the bundled example projects. The Solutions library can be reused and imported into any PSoC Creator design project that requires the SGPIO Initiator component functionality.

All of the example projects provided with this application note are designed to run on the PSoC DVK. Each example project contains the SGPIO\_Target component used to exercise and verify the functionality of the SGPIO\_Initiator component in loopback mode.

To replicate this environment properly, some wire connections are required on the PSoC DVK as shown in Figure 3. Using header **P19** on the DVK, make the four connections shown in orange color in Figure 3.


Pay close attention to the clock sources chosen for both components.

- The SGPIO\_Initiator input clock (labeled I\_CLK) must be set to 4x the desired SGPIO SCLOCK frequency. To run SCLOCK at the maximum 100 kHz, set I\_CLK to 400 kHz.
- The SGPIO\_Target input clock (labeled T\_CLK) should be set to at least 8x the SCLOCK frequency. 1 MHz was chosen to satisfy this requirement.

## **Example 1**

Double-click the **SGPIO\_Target** component to open the component customizer as shown in Figure 4.

Figure 4. SGPIO\_Target Component Customizer



For the first example project, ensure that the **VendorSpecific** parameter is set to **false**. This will disable support for the L3:0 vendor specific information optionally transmitted over the SLOAD signal by the Initiator. Click **OK** to close the customizer.

Program the Example1 project into the DVK by selecting **Debug > Program** from the pulldown menus. If the project is running correctly, the text displayed on the debug LCD should read:

In the **Workspace Explorer**, double-click *main.c* to examine the firmware used in this example project. The code is shown in Code 1.

Tgt: SDOUT=029C Int: SDIN=08D1

#### Code 1. Example 1 main.c Firmware Listing

```
#define DUMMY_SDOUT 0x029C
                               /* Drive0=4, Drive1=3, Drive2=2, Drive3=1 */
#define DUMMY_SDIN 0x08D1
                               /* Drive0=1, Drive1=2, Drive2=3, Drive3=4 */
void main()
    /* Initialize the Debug LCD display */
   LCD_Char_Start();
   LCD_Char_Position(0,0);
   LCD_Char_PrintString("Tgt: SDOUT=");
   LCD_Char_Position(1,0);
   LCD_Char_PrintString("Int: SDIN=");
   /* Initialize the SGPIO Components */
   SGPIO_Target_Start();
   SGPIO_Initiator_Start();
   SGPIO_Initiator_WriteTxData(DUMMY_SDOUT);
   for(;;)
       /* SGPIO_Initiator Processing */
       while(!SGPIO_Initiator_GetIntStatus());
       sdataIn = SGPIO_Initiator_ReadRxData();
                                                           /* Read new SDIN data from Target */
       SGPIO_Initiator_WriteTxData(DUMMY_SDOUT);
                                                           /* Reload dummy Initiator SDOUT test data */
       /* SGPIO_Target Processing */
       while(!SGPIO_Target_GetIntStatus());
       sdataOut = SGPIO_Target_ReadRxData();
                                                    /* Read new SDOUT from the Initiator */
       SGPIO_Target_WriteTxData(DUMMY_SDIN);
                                                    /* Reload dummy Target SDIN test data */
       /* Display results on LCD */
       LCD_Char_Position(0,11);
       LCD Char PrintHexUint16(sdataOut);
       LCD_Char_Position(1,11);
       LCD_Char_PrintHexUint16(sdataIn);
       /* Reset the Component Buffers */
       /* The slowness of LCD updates will have caused FIFO buffer overflows */
       SGPIO_Initiator_ClearRxBuffer();
       SGPIO_Target_ClearRxBuffer();
}
```

In the Code 1 excerpt, all lines of code that start with the prefix **SGPIO\_Initiator** reference APIs provided by Cypress for that component. Refer to the component datasheet for a full list of the provided APIs.

In Example 1, the CPU polls the interrupt status of the SGPIO\_Initiator component waiting for new SDIN data to arrive from the Target. When this event is detected, the SGPIO\_Initiator reads the SDIN data and loads the transmitter FIFO with dummy data to send to the Target during the next frame. The same procedure is used to read/write data to/from the SGPIO\_Target component.

Since SGPIO is a full duplex communication link, transmitting and receiving data simultaneously, it is always

necessary to write new transmit data to the SGPIO components whenever new receive data is read.

The LCD displays the SDOUT data received by the Target on the top line and displays the SDIN data received by the Initiator on the second line.

Congratulations! You just completed your first SGPIO Initiator design with PSoC. If the data displayed on your LCD reads 0000 for both Target and Initiator, check the DVK external wiring connections you made earlier. Refer to Figure 3 for the correct connection scheme.

#### **Example2 – Using Interrupts**

While the SGPIO\_Initiator component supports the polling methodology used in Example1, it is recommended to use interrupts to service the SGPIO\_Initiator interface due to the real-time sensitivity of handling the interface. This is particularly true if the CPU is burdened with supporting higher level management protocols such as IPMB or IBPI.

Close *main.c* and *TopDesign.cysch* for Example1. Go back to the Workspace Explorer and right click on **Project** 'Example2'. Select **Set As Active Project**.

Open *TopDesign.cysch* for Example2 to start working on this project. The only change made to the top level design schematic is the addition of interrupt components, retrieved from the standard **Cypress Component Catalog**. For the Example2 project, double click the SGPIO\_Target component to open the Component Customizer and ensure that the **VendorSpecific** parameter is set to **true**.

Right click on **Project 'Example2'** and **choose Set As Active Project** then program the Example2 project into

Code 2. Example2 main.c Firmware Listing

```
#include <device.h>
/* Dummy Test Patterns */
#define DUMMY_SDOUT 0x0123
#define DUMMY_VENDOR
                      0x0A
uint16 sdataIn, sdataOut, vendorL30;
void main()
    /* Initialize the Debug LCD Display */
   LCD_Char_Start();
   LCD_Char_Position(0,0);
   LCD_Char_PrintString("Tgt: D=
                                      V=");
   LCD_Char_Position(1,0);
   LCD_Char_PrintString("Int: D=");
   /* Enable Interrupts in the System */
   CYGlobalIntEnable;
   TARGET_INT_Start();
   INITIATOR_INT_Start();
   /* Initialize the SGPIO Components */
   SGPIO_Target_Start();
   SGPIO_Target_EnableInt();
   SGPIO_Initiator_Start();
   SGPIO_Initiator_EnableInt();
   SGPIO_Initiator_WriteVendorSpecific(vendorL30);
   SGPIO_Initiator_WriteTxData(sdataOut);
   for(;;)
        /* Display results on LCD */
       LCD_Char_Position(0,7);
       LCD_Char_PrintHexUint16(sdataOut);
       LCD_Char_Position(0,14);
       LCD_Char_PrintHexUint8(vendorL30);
       LCD_Char_Position(1,7);
       LCD_Char_PrintHexUint16(sdataIn);
}
```

the DVK by selecting **Debug > Program** from the pull-down menus.

If the project is running correctly, the text displayed on the debug LCD should read:

```
Tgt: D=0123 V=0A Int: D=0EDC
```

In the **Workspace Explorer**, double click on *main.c, INITIATOR\_INT.c* and *TARGET\_INT.c* to examine the firmware used in this example project. The code is shown in code excerpts Code 2, Code 3, and Code 4.

The first thing to notice in the second example is that the code in *main.c* only handles the LCD display. Handling of the SGPIO\_Initiator component data transfers is done entirely in the **INITIATOR\_INT** interrupt service routine. Similarly, handling of the SGPIO\_Target component data transfers is done entirely in the **TARGET\_INT** interrupt service routine.

#### Code 3. Example2 INITIATOR\_INT.c Firmware Listing

```
CY_ISR(INITIATOR_INT_Interrupt)
       Place your Interrupt code here. */
   /* `#START INITIATOR_INT_Interrupt` */
   // Read SDIN data from the Rx FIFO //
   sdataIn = SGPIO_Initiator_ReadRxData();
   /* Load SDOUT data for transmission on the next frame */
   SGPIO_Initiator_WriteTxData(sdataOut);
/* `#END` */
Code 4. Example 2 TARGET INT.c Firmware Listing
CY_ISR(TARGET_INT_Interrupt)
    /* Place your Interrupt code here. */
   /* `#START TARGET_INT_Interrupt` */
   /* Read SDOUT data and vendor specific L3:0 data from the Rx FIFO */
   sdataOut = SGPIO_Target_ReadRxData();
   vendorL30 = SGPIO_Target_ReadRxData();
    /* Load the inverse of what was received for transmission out on SDIN next frame */
   SGPIO_Target_WriteTxData(~sdataOut);
/* `#END` */
```

## Example 3 – Add Support for SGPIO Bus Timeout


The SFF-8485 SGPIO specification requires that the SGPIO Target detect a bus timeout condition typically caused by the removal of the cable that connects to the HBA. In that case, SCLOCK, SLOAD, and SDATAOUT will all be pulled high using 2 k $\Omega$  pull-up resistors on the backplane PCB. If the Target detects all three inputs are high for 64 msec, then all LED indicators should be turned off.

The SGPIO\_Target component does not handle higher-level functions such as turning LEDs on or off. However, it does provide the mechanism for detecting the bus timeout condition.

Close *main.c* and *TopDesign.cysch* for Example2. Go back to the Workspace Explorer and right click on **Project** 'Example3'. Select **Set As Active Project**.

Open *TopDesign.cysch* for Example3 as shown in Figure 5 to start working on this project.

Figure 5. Top-level Design Schematic for Example Project 3



Two major changes have been made to the top-level design schematic for this example. First, the SGPIO\_Initiator circuit has been modified such that pressing the switch labeled **SW1** on the PSoC DVK will force all three output signals from the SGPIO\_Initiator high. This will be used to test the Target's ability to detect the bus timeout condition. To support this example, add another wire on the DVK from **P19 P0 0** to **P14 SW1**.

The second change made to the schematic is the addition of a 1 ms Timer component from the standard Cypress Component Catalog. The Timer used in this example is clocked from a 100 kHz clock source (provided by PSoC's versatile internal clock divider subsystem) and has been configured with a period of 100 to generate a terminal count interrupt every 1 ms. Support for the 64 ms bus timeout will be handled in firmware using provided APIs.

Program the Example3 project into the DVK by selecting **Debug > Program** from the pull-down menus. If the project is running correctly, the text displayed on the

debug LCD should look similar to Example2 with the exception that the data packets sent and received over the SGPIO bus will increment periodically.

Press and hold the switch labeled **SW1** on the CY8CKIT-001 DVK to force SCLOCK, SLOAD, and SDATAOUT high to confirm that the Target can detect the fault.

When the bus timeout fault is detected for 64 msec, the text displayed on the debug LCD should read:

SGPIO TIMEOUT

Release the switch to resume normal operation.

In the Workspace Explorer, double click on *main.c* and *INT\_1MS.c* to examine the firmware used in this example project. Those excerpts are shown below in Code 5 and Code 6. The code in **TARGET\_INT.c** has been modified to return the same data received (no longer inverted) and is not shown in this application note.

#### Code 5. Example3 main.c Firmware Listing

```
#include <device.h>
#define DUMMY_SDOUT
                        0x0123
#define DUMMY_VENDOR
                        0 \times 05
uint16 vendorL30 = DUMMY_VENDOR;
uint8  timeout64Counter = 0;
uint8  timeout64Flag = 0;
uint16 testData = 0;
void main()
   uint8 delayLoop = 0;
    /* Initialize the Debug LCD Display */
   LCD_Char_Start();
   LCD_Char_Position(0,0);
   LCD_Char_PrintString("Tgt: D=
   LCD_Char_Position(1,0);
   LCD_Char_PrintString("Int: D=");
    /* Start the Millisecond Timer Component */
   Timer_1ms_Start();
    /* Enable Interrupts in the System */
   CYGlobalIntEnable;
   TARGET_INT_Start();
   INITIATOR_INT_Start();
   INT_1MS_Start();
    /* Initialize the SGPIO Components */
   SGPIO_Target_Start();
   SGPIO_Target_EnableInt();
   SGPIO_Initiator_Start();
   SGPIO_Initiator_EnableInt();
   SGPIO_Initiator_WriteVendorSpecific(vendorL30);
   SGPIO_Initiator_WriteTxData(testData);
       for(;;)
               // Change the Dummy Test Data Periodically //
               if (++Delay_Loop == 255)
                   Test_Data++;
               // Display results on LCD //
               if (timeout64Flag)
                   // Display timeout message //
                   LCD_Char_Position(0,0);
                   LCD_Char_PrintString("SGPIO TIMEOUT
                                                         ");
                   LCD_Char_Position(1,0);
                   LCD_Char_PrintString("
                                                         ");
                   timeout64Flag = 0;
                   // Wait for bus activity to resume and then restore LCD display //
                   SGPIO_Target_ResetTimeout();
                   while (SGPIO_Target_GetTimeoutStatus()){};
                   LCD_Char_Position(0,0);
                   LCD_Char_PrintString("Tgt: D=
                   LCD_Char_Position(1,0);
                   LCD_Char_PrintString("Int: D=");
                   SGPIO_Target_Start();
                   SGPIO_Target_EnableInt();
               }
               else
                   LCD_Char_Position(0,7);
                   LCD_Char_PrintHexUint16(sdataOut);
```

```
LCD_Char_Position(0,14);
LCD_Char_PrintHexUint8(vendorL30);
LCD_Char_Position(1,7);
LCD_Char_PrintHexUint16(sdataIn);
}
}
}
```

#### Code 6. Example3 INT\_1MS.c Firmware Listing

```
CY_ISR(INT_1MS_Interrupt)
       Place your Interrupt code here. */
    /* `#START INT_1MS_Interrupt` */
    /* Check for SGPIO bus activity since the last 1ms interrupt */
    if (SGPIO_Target_GetTimeoutStatus())
        /* No bus activity detected */
       if (++timeout64Counter > 63)
           timeout64Counter = 63;
           timeout64Flag = 1;
           SGPIO_Target_Stop();
   else
        /* Bus activity detected */
        timeout64Counter = 0;
    /* Reset the SGPIO bus activity detection logic */
   SGPIO_Target_ResetTimeout();
    /* `#END` */
}
```

The INT\_1MS code excerpt demonstrates how to use the SGPIO\_Target APIs to detect the bus timeout condition. The custom hardware implementation of the SGPIO\_Target component includes a sticky bit that goes to zero whenever bus activity is detected. This sticky bit is re-armed for activity detection by calling the SGPIO\_Target\_ResetTimeout() API. In this example, that API is called every millisecond in this interrupt service routine. On subsequent millisecond interrupts, the status of that sticky bit is checked using the SGPIO\_Target\_GetTimeoutStatus() API.

That API returns a zero if there has been activity detected on the SGPIO bus and returns a non-zero value if no activity has been detected.

The 1 ms interrupt service routine increments the timeout64Counter variable every time 1 ms if no activity has been detected. If that variable exceeds 63 counts, then 64 msec of no activity has been detected on the SGPIO bus. The example shown here stops the SGPIO\_Target component and sets a flag called timeout64Flag for the main loop to handle.

Referring back to the Code 5 excerpt, the main processing loop detects the timeout flag and reuses the same API calls to wait until SGPIO bus activity resumes (when the **SW1** switch is released in this example project). When bus activity does resume, the SGPIO\_Target component is restarted and normal operation resumes.

One benefit of implementing the 64 ms bus timeout using this firmware/hardware combination is that a single millisecond timer and interrupt service routine can be used to monitor many SGPIO Target interfaces in the same PSoC device. Each SGPIO\_Target component consumes two of PSoC's universal digital blocks (UDBs), enabling one PSoC 3 device to support up to 12 SGPIO\_Target interface components in a single chip.

Congratulations! You have just completed an SGPIO Initiator and Target loopback design using PSoC 3 that fully implements all features specified by the SFF-8485 Serial GPIO specification.

### **Going Forward**

The PSoC Creator library project provided along with this application note can be shared freely with other designers and reused in your own PSoC Creator design projects. To make use of this feature, copy the **SGPIOLibrary** folder that was provided with the example projects to a convenient location on your hard drive or shared network.

When you begin your next SGPIO design project in PSoC Creator, the **Solutions** Component Catalog will not be automatically available to you.

To gain access to the SGPIO\_Initiator component, select **Project > Dependencies** from the pull-down menus. Under **User Dependencies** click on the folder icon and navigate to the location of the SGPIOLibrary.cyprj file.

10

Select the **Components** and **Code** check boxes and click **OK**. The Solutions component catalog will now be available in your design project and the SGPIO\_Initiator and SGPIO\_Target components will be available to use in your new project.

## **Summary**

The SGPIO\_Initiator component enables designers to quickly and easily design HBAs for system storage applications providing support for many hard drives. PSoC's custom logic capability enables designers to implement custom protocol interfaces like SGPIO without the issue of firmware implementations such as bit-banging with complex and difficult timing requirements. PSoC's unique ability to combine custom digital logic, analog signal chain processing and an MCU in a single device enables system designers to integrate many external fixed-function ASSPs. This powerful integration capability not only reduces BOM cost, but also results in PCB board layouts that are less congested and more reliable.

## **Document History**

Document Title: PSoC® 3 and PSoC 5 - SFF-8485 Serial GPIO (SGPIO) Initiator Interface - AN66019

Document Number: 001-66019

Revision	ECN	Orig. of Change	Submission Date	Description of Change
**	3122236	JK	12/28/2010	New Spec – Initial Release
*A	3265814	JK	07/03/2011	Added support for PSoC 5. Changed application note title. Updated the example projects to use SGPIO_Target Component v1.20 and SGPIO_Initiator Component v1.10
*B	3323585	JK	07/25/2011	Updated AN# number in the header throughout the document.

PSoC is a registered trademark of Cypress Semiconductor Corp. PSoC Creator and PSoC Designer are trademarks of Cypress Semiconductor Corp. All other trademarks or registered trademarks referenced herein are the property of their respective owners.

Cypress Semiconductor 198 Champion Court San Jose, CA 95134-1709 Phone: 408-943-2600 Fax: 408-943-4730 http://www.cypress.com/

© Cypress Semiconductor Corporation, 2010–2011. The information contained herein is subject to change without notice. Cypress Semiconductor Corporation assumes no responsibility for the use of any circuitry other than circuitry embodied in a Cypress product. Nor does it convey or imply any license under patent or other rights. Cypress products are not warranted nor intended to be used for medical, life support, life saving, critical control or safety applications, unless pursuant to an express written agreement with Cypress. Furthermore, Cypress does not authorize its products for use as critical components in life-support systems where a malfunction or failure may reasonably be expected to result in significant injury to the user. The inclusion of Cypress products in life-support systems application implies that the manufacturer assumes all risk of such use and in doing so indemnifies Cypress against all charges.

This Source Code (software and/or firmware) is owned by Cypress Semiconductor Corporation (Cypress) and is protected by and subject to worldwide patent protection (United States and foreign), United States copyright laws and international treaty provisions. Cypress hereby grants to licensee a personal, non-exclusive, non-transferable license to copy, use, modify, create derivative works of, and compile the Cypress Source Code and derivative works for the sole purpose of creating custom software and or firmware in support of licensee product to be used only in conjunction with a Cypress integrated circuit as specified in the applicable agreement. Any reproduction, modification, translation, compilation, or representation of this Source Code except as specified above is prohibited without the express written permission of Cypress.

Disclaimer: CYPRESS MAKES NO WARRANTY OF ANY KIND, EXPRESS OR IMPLIED, WITH REGARD TO THIS MATERIAL, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. Cypress reserves the right to make changes without further notice to the materials described herein. Cypress does not assume any liability arising out of the application or use of any product or circuit described herein. Cypress does not authorize its products for use as critical components in life-support systems where a malfunction or failure may reasonably be expected to result in significant injury to the user. The inclusion of Cypress' product in a life-support systems application implies that the manufacturer assumes all risk of such use and in doing so indemnifies Cypress against all charges.

Use may be limited by and subject to the applicable Cypress software license agreement.