

1篇

- gsoap/importgsoap/custom
- gsoap/plugin
- gsoap/stdsoap2.cpp
- gsoap/stdsoap2.h
- gsoap/typemap.dat
- -

## 修改typemap.dat

由于后续编译过程中需要用到 duration.c 文件,会遇到类型LONG64报错的问题,需要gsoap/typemap.dat 文件中取消以下行的注释:

xsd\_\_duration = #import "custom/duration.h" | xsd\_\_duration

## 生成头文件onvif.h

执行命令

./step1\_gen\_head.sh

此步骤会生成onvif head/onvif.h文件

该脚本会在线下载wsdl文件(需要自己配置),并且修改onvif.h文件,加入鉴权的相关项。

#### 命令解析

step1\_gen\_head.sh主要使用了wsdl2h命令来生成onvif.h文件。wsdl2h参数解析:

- -c: 生成c风格代码 (注:后缀名还是.cpp,但实际上是.c)
- -c++: 生成c++风格代码 (注:默认是生成c++代码)
- -x:表示不生成xml文件(注:生成的xml文件,有助于了解发送是SOAP是怎样的结构,建议不使用-x)
- -1:表示指定导入路径
- -C:表示生成客户端代码
- -S:表示生成服务端代码
- -s:不使用STL代码
- -o: 生成.h文件叫什么名字
- -t: 后面紧跟"typemap.dat"这个批处理文件

The wsdl2h tool performs the mapping of WSDL and XML schemas to C and/or C++ automatically. The output of wsdl2h is a "data binding interface file" which is simply an annotated C/C++ header file with the serializable C/C++ data types that represent XML schema components. This file also includes comments and documentation of the serializable data types.

生成的onvif.h是一个数据绑定接口定义文件,后续步骤会用到。

#### 关于鉴权

鉴权也就是设备使用用户名密码登录。

如果onvif.h不加入#import "wsse.h",使用soap\_wsse\_add\_UsernameTokenDigest函数会导致编译出错,也就无法登录设备进行操作了。 但是默认生成的onvif.h中是没有#import "wsse.h"的。step1\_gen\_head.sh脚本已经处理了这个问题。

- wsdl的相关功能描述
- - https://www.onvif.org/ver10/device/wsdl/devicemgmt.wsdl 用于获取设备参数
- https://www.onvif.org/onvif/ver10/network/wsdl/remotediscovery.wsdl 用于发现设备
- - https://www.onvif.org/onvif/ver20/ptz/wsdl/ptz.wsdl 云台控制
- - https://www.onvif.org/onvif/ver10/media/wsdl/media.wsdl 获取264的视频流地址
- - https://www.onvif.org/onvif/ver20/media/wsdl/media.wsdl 获取h265视频流地址
- - http://www.onvif.org/onvif/ver20/imaging/wsdl/imaging.wsdl 光圈,对比度,饱和度

更多的我暂时没用到,也就不举例了。

SOAP\_ENV\_\_Fault重复定义

如果没有修改相关文件,生成代码的时候会出现如下错误。

wsa5.h(280): "WARNING\*: Duplicate declaration of 'SOAP\_ENV\_Fault' (already declared at line 268) wsa5.h(290): \*\*ERROR\*\*: service operation name clash: struct/class 'SOAP\_ENV\_Fault' already declared at wsa.h:278

之所有会出现这个错误,是因为onvif.h头文件中同时:

```
#import "wsdd10.h" // wsdd10.h中又#import "wsa.h" #import "wsa5.h" // wsa.h和wsa5.h两个文件重复定义了int SOAP_ENV__Fault
```

## 解决方法:

修改importwsa5.h文件,将int SOAP\_ENV\_\_Fault修改为不冲突的任何名字,例如int SOAP\_ENV\_\_Fault\_xxx,再次使用soapcpp2工具编译就成功了。

脚本也已经自动处理了,具体实现是

```
sed -i 's/int SOAP_ENV__Fault$/int SOAP_ENV__Fault_xxx/g' gsoap/import/wsa5.h
```

## 生成onvif相关源代码

执行生成命令

./step2\_gen\_code.sh

脚本已经删除了一些无用文件、复制并重命名了相关文件。其中onvif.h文件其实已经没用了,可以删掉,不需要参与后续IPC客户端程序的编译。这里有好多个命名空间的.nsmap文件,文件内容都一模一样,拿wsdd.nsmap一个来用即可。

## soap目录

这里把从gsoap中将来用到的一些文件复制过来了,修改成了cpp后缀

## onvif目录

- 一些生成的源代码文件,就是我们要的东西。
- 各种nsmap文件:命名空间,除了名字不一样,内容是一样的,里面的内容竟然是每一个xml文件里的Envelope字段内容。我们只需要留下一个就可以了,并将之改名为wsdd.nsmap

◆ soapC.cpp: 指定数据结构的序列化和反序列化

• soapClient.cpp: 客户端代码

• soapH.h: 主头文件,所有客户机和服务器源代码都要包括它

• soapStub.h: 从输入头文件 (onvif.h) 生成的经过修改且带命名空间前缀的头文件

#### 示例

还是参考工程NoevilMe/onvif demo; Linux c++ onvif client demo (github.com)

#### **CMakeLists**

```
cmake_minimum_required(VERSION 3.0)
project(OnvifSoap)

set(CMAKE_CXX_STANDARD 11)

set(CMAKE_CXX_FLAGS "-g -00")

set(LIB_SOAP_SRC
soap/struct_timeval.cpp
soap/duration.cpp
soap/duration.cpp
soap/dwsaapi.cpp
soap/smseapi.cpp
soap/smseapi.cpp
soap/smseapi.cpp
soap/smseapi.cpp
soap/smseapi.cpp
soap/smseapi.cpp
soap/smseapi.cpp
soap/smseapi.cpp
soap/smdevp.cpp
```

soap目录编译成了libonvif\_soap,依赖openssl。 还需要定义两个宏WITH\_OPENSSL和 WITH\_DOM onvif目录编译成了libonvif,依赖libonvif soap.

#### damo

位于tests/scan\_device.cpp

```
#include "onvif/soapH.h"
#include "soap/wsaapi.h"
#include castdio.h>
#include cstdio.h>
#include cstdibi.h:

#include "onvif/wsdd.nsmap"

#define SOAP_ASSERT assert
#define SOAP_DBGLOG printf
#define SOAP_DBGERR printf

#define SOAP_DBGERR printf

#define SOAP_DBGERR printf

#define SOAP_DBGERR printf
```

#### 执行结果

```
1 $ ./dev_scan
http://10.10.10.103/onvif/device_service, tdn:NetworkVideoTransmitter tds:Device
3 http://10.10.104/onvif/device_service, tdn:NetworkVideoTransmitter tds:Device
4
5 detect end! It has detected 2 devices!
```

# tdn:NetworkVideoTransmitter

```
NVT (Network Video Transmitter)
```

A Network Video Transmitter (NVT) is an ONVIF device that sends media data over
an IP network to a client. For example, an NVT may be an IP network camera or
an encoder device.

An NVT implements the following services to provide its core functionality:

- Device service enables an NVT to provide device management functionality such as device capabilities, system and network settings, security settings and firmware upgrade.
- Event service enables an NVT to send events to clients. Media service enables an NVT to stream media data to clients. Media data includes video, audio, video analytics and other metadata.
- Device IO service enables an NVT to support physical inputs and outputs. An NVT can also implement the following services to provide extended functionality:
- PTZ service enables an NVT to provide PTZ control if the device is a PTZ camera.
- Imaging service enables an NVT to provide configuration of image settings which affect the visual appearance of the video, for example, exposure time, gain and white balance, focus control.
- Video Analytics service enables an NVT to provide video analytics functionality.

Beyond this, an NVT can also include additional ONVIF services, for example the Recording service if support for local storage is required

网络视频服务器(比如,网络摄像机,编码设备等),通过IP网络发送媒体数据到客户端。

## å 文章知识点与官方知识档案匹配,可进一步学习相关知识

云原生入门技能树〉首页〉概览 15303 人正在系统学习中

```
20150310_001_cuilw.rar_ONVIF_onvif client_onvif linux_onvif 客户端_onvif含户端源码,真实测试用例,资测
Linux——Shell脚本编程(2)
Linux——Shell脚本编程(2)
Linux——Shell脚本编程(2)
```



