8051 – Instruction set

ARITHMETIC INSTRUCTIONS

ADD	A,#byte	$A \leftarrow A + byte$
-----	---------	-------------------------

ADD A,@Rn ;
$$A \leftarrow A + DM(Rn)$$

ADD A,Ri ;
$$A \leftarrow A + Ri$$

ADD A,byte
$$;A \leftarrow A + DM(byte)$$

ADDC A,#byte ;
$$A \leftarrow A + byte + CY$$

ADDC A,@Rn ;A
$$\leftarrow$$
 A + DM(Rn) + CY

ADDC A,Ri
$$;A \leftarrow A + Ri + CY$$

ADDC A,byte
$$;A \leftarrow A + DM(byte) + CY$$

LOGICAL INSTRUCTIONS

ANL A,#byte ; $A \leftarrow A \land byte$

ANL A,@Rn ; $A \leftarrow A \land DM(Rn)$

ANL A,Ri ; $A \leftarrow A \wedge Ri$

ANL A,byte $;A \leftarrow A \land DM(byte)$

ANL dbyte,#byte ;DM(dbyte) \leftarrow DM(dbyte) \land byte

ANL byte,A ;DM(byte) \leftarrow A \land DM(byte)

CLR A ;A $\leftarrow 0$

CPL A $;A \leftarrow \overline{A}$

RL A ;A \leftarrow A(6..0)|A(7) RLC A ;CY|A \leftarrow A|CY RR A :A \leftarrow A(0)|A(7..1)

RR A ;A \leftarrow A(0)|A(7..1) RRC A ;A|CY \leftarrow CY|A

SWAP A ;A \leftarrow A(3..0)|A(7..4)

DATA MOVE INSTRUCTIONS

MOV A,#byte	$;A \leftarrow byte$
-------------	----------------------

MOV A,@Rn ;
$$A \leftarrow DM(Rn)$$

MOV A,Ri ;A
$$\leftarrow$$
 Ri

MOV A,byte
$$;A \leftarrow DM(byte)$$

MOV @Rn,A ;DM(Rn)
$$\leftarrow$$
 A

MOV @Rn,#byte ;DM(Rn)
$$\leftarrow$$
 byte

MOV @Rn,byte ;DM(Rn)
$$\leftarrow$$
 DM(byte)

MOV Ri,A ;Ri
$$\leftarrow$$
 A

MOV Ri,#byte ;Ri
$$\leftarrow$$
 byte

MOV Ri,byte ;Ri
$$\leftarrow$$
 DM(byte)

MOV byte,A ;DM(byte)
$$\leftarrow$$
 A

MOV	dbyte,#byte	$;DM(dbyte) \leftarrow byte$
MOV	byte,@Rn	$;DM(byte) \leftarrow DM(Rn)$
MOV	byte,Ri	$;DM(byte) \leftarrow Ri$
MOV	dbyte,byte	$;DM(dbyte) \leftarrow DM(byte)$
MOV	DPTR,#addr	;DPTR \leftarrow addr
MOVC	A, $@A + DPTR$	$A \leftarrow CM(A+DPTR)$
MOVC	A, $@A + PC$	$;A \leftarrow CM(A+PC)$
MOVX	A,@DPTR	$A \leftarrow XM(DPTR)$
MOVX	A,@Rn	$A \leftarrow XM(P2 Rn)$
MOVX	@DPTR,A	$XM(DPTR) \leftarrow A$
MOVX	@Rn,A	$;XM(P2 Rn) \leftarrow A$

Push, Pop, and exchange

PUSH	byte	$;DM(SP+1) \leftarrow DM(byte), SP \leftarrow SP + 1$
POP	byte	$;DM(byte) \leftarrow DM(SP), SP \leftarrow SP - 1$

XCH A,Ri ; $A \leftrightarrow Ri$

XCH A,byte $;A \leftrightarrow DM(byte)$

 $XCH \hspace{1cm} A, @Rn \hspace{1cm} ; A \leftrightarrow DM(R_i)$

XCHD A,@Rn ;A(3..0) \leftrightarrow DM(Rn;3..0)

PROGRAM AND MACHINE CONTROL

CALL Note: Assembler translates CALL to ACALL or LCALL

ACALL short $|DM(SP+2)|DM(SP+1) \leftarrow PC+2$,

 $;PC(10..0) \leftarrow short, SP \leftarrow SP + 2$

LCALL addr ; $DM(SP+2)|DM(SP+1) \leftarrow PC+3$,

 $:PC(15..0) \leftarrow addr, SP \leftarrow SP + 2$

RET :PC \leftarrow DM(SP)|DM(SP-1), SP \leftarrow SP-2

RETI ;PC \leftarrow DM(SP)|DM(SP-1), SP \leftarrow SP-2

;Reenable equal or lower priority INT

JMP Note: JMP is translated to AJMP, LJMP, or SJMP.

AJMP short ;PC(10..0) \leftarrow short

LJMP addr ;PC(15..0) \leftarrow addr

SJMP byte ;PC \leftarrow PC + 2 + byte(7)..byte(7)|byte

JMP @A+DPTR ;PC $\leftarrow DPTR + A$

JZ byte ;IF A = 0 THEN

 $PC \leftarrow PC + 2 + byte(7)..byte(7)|byte$

;ELSE PC \leftarrow PC+2

JNZ byte ;IF $A \neq 0$ THEN

 $PC \leftarrow PC + 2 + byte(7)..byte(7)|byte$

;ELSE PC \leftarrow PC+2

CJNE	A,dbyte,byte	;IF A \neq DM(dbyte) THEN ;PC \leftarrow PC + 2 + byte(7)byte(7) byte ;IF A < DM(dbyte) THEN CY \leftarrow 1
CJNE	A,#dbyte,byte	;ELSE CY \leftarrow 0 ;IF A \neq dbyte THEN ;PC \leftarrow PC + 2 + byte(7)byte(7) byte
		;IF A < dbyte THEN CY \leftarrow 1 ;ELSE CY \leftarrow 0
CJNE	Rn,#dbyte,byte	;IF Rn \neq dbyte THEN ;PC \leftarrow PC + 2 + byte(7)byte(7) byte
		;IF A < DM(dbyte) THEN CY \leftarrow 1 ;ELSE CY \leftarrow 0
CJNE	@Rn,#dbyte,byte	;IF DM(Rn) ≠ dbyte THEN ;PC ← PC + 2 + byte(7)byte(7) byte ;IF A < dbyte THEN CY ← 1
		;ELSE CY $\leftarrow 0$

DJNZ	Rn,byte	$Rn \leftarrow Rn-1, IF(Rn-1) \neq 0 THEN$
		$;$ PC \leftarrow PC + 2 + byte(7)byte(7) byte
		;ELSE PC \leftarrow PC + 2
DJNZ	dbyte,byte	$;DM(dbyte) \leftarrow DM(dbyte)-1,$
		;IF $(DM(dbyte)-1) \neq 0$ THEN
		$;$ PC \leftarrow PC + 3 + byte(7)byte(7) byte
		;ELSE PC \leftarrow PC + 3
NOP		$;$ PC \leftarrow PC + 1

BIT MANIPULATION INSTRUCTIONS

CLR C ;CY \leftarrow 0

CLR byte ;BADM(byte) $\leftarrow 0$

SETB C ;CY \leftarrow 1

SETB byte ;BADM(byte) $\leftarrow 1$

CPL C; $CY \leftarrow \overline{CY}$

CPL byte $;BADM(byte) \leftarrow \overline{BADM(byte)}$

ANL C,byte ; $CY \leftarrow CY \land BADM(byte)$

ANL C,/byte ; $CY \leftarrow CY \land \overline{BADM(byte)}$

ANL byte,bit $;BADM(byte) \leftarrow BADM(byte) \land bit$

ORL C,byte ; $CY \leftarrow CY \lor BADM(byte)$

ORL C,/byte ; $CY \leftarrow CY \lor \overline{BADM(byte)}$

ORL byte,bit $;BADM(byte) \leftarrow BADM(byte) \lor bit$

MOV C,byte ; $CY \leftarrow BADM(byte)$

MOV byte,C ;BADM(byte) \leftarrow CY

BIT JUMP INSTRUCTIONS

	·	0 0 - 1,0
JB	dbyte,byte	;IF $BADM(dbyte) = 1 THEN$
		$;PC \leftarrow PC + 3 + byte(7)byte(7) byte$
		;ELSE PC \leftarrow PC+3
JNB	dbyte,byte	;IF $BADM(dbyte) = 0$ THEN
		$;PC \leftarrow PC + 3 + byte(7)byte(7) byte$
		;ELSE PC \leftarrow PC+3
JBC	dbyte,byte	;IF $BADM(dbyte) = 1 THEN$
		; BADM(dbyte) $\leftarrow 0$
		; $PC \leftarrow PC + 3 + byte(7)byte(7) byte(7) $
		;ELSE PC \leftarrow PC+3
JC	byte	;IF $CY = 1$ THEN
		$;PC \leftarrow PC + 3 + byte(7)byte(7) byte$
		;ELSE PC \leftarrow PC+3
JNC	byte	;IF $CY = 0$ THEN
		$PC \leftarrow PC + 3 + byte(7)byte(7) byte$
		;ELSE PC \leftarrow PC+3

INSTRUCTIONS THAT AFFECT FLAGS (i

Instruction	CY	OV.	AC	Instruction	CY	ΟV	AC
ADD	X	X	X	CLR C	0	-	-
ADDC	X	X	X	CPL C	X	-	-
SUBB	X	X	X	ANL C,bit	X	-	-
MUL	0	X	-	ANL C,/bit	X	-	-
DIV	0	Χ	-	ORL C,bit	X	-	-
DA	X	-	-	ORL C,bit	X	-	-
RRC	X	-	-	MOV C,bit	X	-	-
RLC	X	-	-	CJNE	X	-	-
SETB C	1	-	-				