

ULO License Activation

Select the license you wish to activate, then use available Unetwork credits or purchase additional Unetwork credits required to connect to Unetwork and perform tasks.

For additional support please visit:

 [How to Bind a License](#)

Select the License to Use.

Tap continue to proceed.

Click here to unbind (De-activate) the license from your device.

License connectivity status and requirements.

