

Rockchip Audio Developer Guide

ID: RK-KF-YF-145

Release Version: V2.4.0

Release Date: 2025-08-18

Security Level: ☐Top-Secret ☐Secret ☐Internal ☒Public

DISCLAIMER

THIS DOCUMENT IS PROVIDED "AS IS". ROCKCHIP ELECTRONICS CO., LTD. ("ROCKCHIP") DOES NOT PROVIDE ANY WARRANTY OF ANY KIND, EXPRESSED, IMPLIED OR OTHERWISE, WITH RESPECT TO THE ACCURACY, RELIABILITY, COMPLETENESS, MERCHANTABILITY, FITNESS FOR ANY PARTICULAR PURPOSE OR NON-INFRINGEMENT OF ANY REPRESENTATION, INFORMATION AND CONTENT IN THIS DOCUMENT. THIS DOCUMENT IS FOR REFERENCE ONLY. THIS DOCUMENT MAY BE UPDATED OR CHANGED WITHOUT ANY NOTICE AT ANY TIME DUE TO THE UPGRADES OF THE PRODUCT OR ANY OTHER REASONS.

Trademark Statement

"Rockchip", "瑞芯微", "瑞芯" shall be Rockchip's registered trademarks and owned by Rockchip. All the other trademarks or registered trademarks mentioned in this document shall be owned by their respective owners.

All rights reserved. ©2025. Rockchip Electronics Co., Ltd.

Beyond the scope of fair use, neither any entity nor individual shall extract, copy, or distribute this document in any form in whole or in part without the written approval of Rockchip.

Rockchip Electronics Co., Ltd.

No.18 Building, A District, No.89, software Boulevard Fuzhou, Fujian, PRC

Website: www.rock-chips.com

Customer service Tel: +86-4007-700-590

Customer service Fax: +86-591-83951833

Customer service e-Mail: fae@rock-chips.com

Preface

Overview

This document mainly introduces the audio function, kernel driver development and debugging of Rockchip series chips.

Product Version

Chipset	Kernel Version
RK chipset	Linux 4.4, Linux 4.19, Linux 5.10, Linux 6.1

Intended Audience

This document (this guide) is mainly intended for:

Technical support engineers

Software development engineers

Revision History

Version	Author	Date	Change Description
V1.0.0	Sugar Zhang	2016-06-06	Initial version
V1.1.0	Sugar Zhang	2017-02-15	Added DRM HDMI Audio configuration
V1.2.0	Sugar Zhang	2020-02-18	Content revision and update
V1.3.0	Sugar Zhang	2020-02-25	Added FAQ chapter
V1.4.0	Sugar Zhang	2020-06-26	Added digital CODEC audio interface
V1.5.0	Sugar Zhang	2021-01-21	Added audio clock compensation
V1.6.0	Sugar Zhang	2021-09-02	Added PDM support description
V1.7.0	Jordan Luo	2023-05-17	Added multicodecs feature description
V1.8.0	Sugar Zhang	2023-07-15	Added sai module description
V1.9.0	Sugar Zhang	2023-11-10	Added mclkout usage description
V2.0.0	Sugar Zhang	2024-05-15	Added DLP description
V2.1.0	Sugar Zhang	2024-09-10	Updated sai feature
V2.2.0	Sugar Zhang	2024-10-25	Added ASRC module description
V2.3.0	Sugar Zhang	2025-05-02	Added RK3576/RK3506/RV1103B/RV1126B
V2.4.0	Sugar Zhang	2025-08-18	Updated support list

Contents

Rockchip Audio Developer Guide

1. Overview
 - 1.1 Rockchip Audio Features
 - 1.2 DAI
 - 1.2.1 SAI
 - 1.2.1.1 SAI Controller Features
 - 1.2.1.2 RK Series Chips SAI Support List
 - 1.2.1.2.1 SAI Version Description
 - 1.2.2 ASRC
 - 1.2.2.1 ASRC Controller Features
 - 1.2.2.2 THD+N
 - 1.2.2.2.1 16bits
 - 1.2.2.2.2 24bits
 - 1.2.2.3 Latency
 - 1.2.2.3.1 Phase Delay
 - 1.2.2.3.2 FIFO Delay
 - 1.2.2.3.3 Example
 - 1.2.2.4 RK Series Chips ASRC Support List
 - 1.2.3 I2S
 - 1.2.3.1 I2S Controller Features
 - 1.2.3.2 I2S-TDM Controller Features
 - 1.2.3.3 RK Series Chips I2S Support List
 - 1.2.4 PDM
 - 1.2.4.1 PDM Controller Features
 - 1.2.4.2 RK Series Chips PDM Support List
 - 1.2.5 DCODEC
 - 1.2.6 VAD
 - 1.2.7 SPDIF
 - 1.3 Combo DAI
2. Audio Driver Development
 - 2.1 Basic Sound Card Composition
 - 2.2 Driver List
 - 2.3 DAI Driver Development
 - 2.3.1 SAI
 - 2.3.1.1 Protocol Format Settings
 - 2.3.1.1.1 AUDIO_FMT_I2S
 - 2.3.1.1.2 AUDIO_FMT_LEFT_J
 - 2.3.1.1.3 AUDIO_FMT_RIGHT_J
 - 2.3.1.1.4 AUDIO_FMT_DSP_A
 - 2.3.1.1.5 AUDIO_FMT_DSP_B
 - 2.3.1.1.6 AUDIO_FMT_TDM_I2S
 - 2.3.1.1.7 AUDIO_FMT_TDM_I2S_INV
 - 2.3.1.1.8 AUDIO_FMT_TDM_LEFT_J
 - 2.3.1.1.9 AUDIO_FMT_TDM_DSP_A
 - 2.3.1.1.10 AUDIO_FMT_TDM_DSP_B
 - 2.3.1.2 Multi Lanes
 - 2.3.1.2.1 TDM16 x 1
 - 2.3.1.2.2 TDM16 x 2
 - 2.3.1.2.3 TDM16 x 3
 - 2.3.1.2.4 TDM16 x 4

- 2.3.1.2.5 Order vs Interleaved
 - 2.3.1.3 Multi SAI Combined
 - 2.3.1.4 Slot Mask
 - 2.3.1.5 slot width settings
 - 2.3.1.6 data line full mapping settings
 - 2.3.1.7 multi lanes settings
 - 2.3.1.8 wait time
 - 2.3.1.9 mclkout / mclkin
 - 2.3.1.10 controls
 - 2.3.1.10.1 path sel
 - 2.3.1.10.2 lanes sel
 - 2.3.1.10.3 loopback sel
 - 2.3.2 ASRC
 - 2.3.2.1 Sound Card Configuration
 - 2.3.2.2 Resample Settings
 - 2.3.2.3 Clock Source Settings
 - 2.3.2.4 Recording
 - 2.3.2.5 Playback
 - 2.3.3 I2S
 - 2.3.3.1 Protocol format configuration
 - 2.3.3.2 Master / Slave configuration
 - 2.3.3.3 Clock phase inversion configuration
 - 2.3.3.4 bclk-fs configuration
 - 2.3.3.5 High-precision clock configuration
 - 2.3.3.6 wait time
 - 2.3.3.7 Others
 - 2.3.3.8 mclkout / mclkin
 - 2.3.4 I2S-TDM
 - 2.3.4.1 TX/RX Clock Sharing configuration
 - 2.3.4.2 Data Lane Remapping configuration
 - 2.3.4.3 TDM half-frame mode configuration
 - 2.3.4.4 TDM Slots configuration
 - 2.3.4.5 mclkout / mclkin
 - 2.3.5 PDM
 - 2.3.5.1 Data Lane Remapping configuration
 - 2.3.5.2 High-precision clock configuration
 - 2.3.5.3 Others
 - 2.3.6 DCODEC
 - 2.3.6.1 Clock Synchronization Mode
 - 2.3.6.2 DSM output Mode
 - 2.3.7 VAD
 - 2.3.7.1 Audio source configuration
 - 2.3.7.2 Detect channel configuration
 - 2.3.7.3 Data storage mode configuration
 - 2.3.7.4 Buffer size configuration
- 2.4 Combo DAI Driver Development
 - 2.4.1 Sub Dai configuration
 - 2.4.2 Channel Mapping configuration
 - 2.4.3 Master / Slave configuration
 - 2.4.4 Clock phase inversion configuration
 - 2.4.5 Examples
- 2.5 CODEC Driver Development
- 2.6 Machine Driver Development

- 2.6.1 Simple Card Driver
 - 2.6.1.1 Protocol Format configuration
 - 2.6.1.2 mclk-fs configuration
 - 2.6.1.3 Master / Slave configuration
 - 2.6.1.4 Clock phase inversion configuration
 - 2.6.1.5 TDM slots configuration
 - 2.6.1.6 Example of Adding a Sound Card
- 2.6.2 Multi Codecs Machine Driver
 - 2.6.2.1 dai / codec configuration
 - 2.6.2.2 Protocol Format configuration
 - 2.6.2.3 mclk-fs configuration
 - 2.6.2.4 Master / Slave configuration
 - 2.6.2.5 Clock phase inversion configuration
 - 2.6.2.6 wait-card-locked configuration
 - 2.6.2.7 Others
- 2.6.3 HDMI Audio
- 2.7 Audio Clock Compensation
- 2.8 DLP
 - 2.8.1 Loopback Mode
- 2.9 Dynamic DMA Channel
- 2.10 PATTERN DEBUG
- 3. Debugging
 - 3.1 Hardware Instruments
 - 3.1.1 Multimeter
 - 3.1.2 Oscilloscope
 - 3.1.3 Signal Generator
 - 3.1.4 AP Analyzer
 - 3.2 Debug Commands
 - 3.2.1 procfs
 - 3.2.2 clk summary
 - 3.2.3 Register
 - 3.2.3.1 io command
 - 3.2.3.2 regmap
 - 3.2.3.3 i2c-tools
 - 3.2.3.3.1 i2cdetect
 - 3.2.3.3.2 i2cdump
 - 3.2.3.3.3 i2cset
 - 3.2.3.3.4 i2cget
 - 3.2.4 alsa-utils
 - 3.2.4.1 aplay
 - 3.2.4.2 arecord
 - 3.2.4.3 arecord | aplay
 - 3.2.4.4 amixer
 - 3.2.4.5 alsaloop
 - 3.2.5 tiny-alsa
 - 3.2.5.1 tinypcminfo
 - 3.2.5.2 tinypplay
 - 3.2.5.3 tinycap
 - 3.2.5.4 tinymix
 - 3.2.6 xrun profiling
 - 3.2.6.1 xrun kmsg
 - 3.2.6.2 xrun ftrace
 - 3.2.6.3 trace-cmd

3.2.6.4 KernelShark

3.3 PC Tools

4. FAQ

4.1 Audio interface support

4.2 Failed to register sound cards

4.3 Playback has no sound

4.4 Playback Distortion

4.5 Record has no Sound

4.6 Record Distortion

4.7 Excessive or insufficient playback rate

4.8 Regular dropouts

4.9 Noise

4.10 XRUN

4.11 I/O error

1. Overview

1.1 Rockchip Audio Features

This section describes the audio features of the RK platform.

Rockchip Audio

	Function	Feature	Description
DAI	I2S	8 CH IN / OUT	Inter IC Sound
	TDM	16 CH IN / OUT	Time Division Multiplexing
	PCM	2 CH IN / OUT	Pulse Code Modulation
	PDM	8 CH IN	Pulse Density Modulation
	DSM	2 CH OUT	Delta Sigma Modulation
	DCODEC	4 CH IN / 2 CH OUT	Digital Codec Interface
	SPDIF	2 CH IN / OUT / 7.1 BITSTREAM	Sony/Philips Digital Interface
	SAI	128 CH IN / OUT	Serial Audio Interface
	ASRC	8 CH IN / OUT	Asynchronous Sample Rate Converter
COMBO DAI	I2S + I2S	16 CH IN / OUT	e.g. Sound Bar Product
	I2S + PDM	16 CH IN / OUT	e.g. Smart Home Product
	TDM + TDM	32 CH IN / 32 CH OUT	
	TDM + PDM	24 CH IN / 16 CH OUT	
	SAI + SAI	256 CH IN / OUT or More	e.g. Mic Array
	ASRC + ASRC	40 CH	e.g. rk2118 32 CH IN / 8 CH OUT
	...	...	...
	DMIC ARRAY + ANALOG LOOPBACK	For Acoustic Echo Cancellation	e.g. Smart Home Product
	HDMI + ANALOG OUTPUT	For Multi Streaming	e.g. OTT Product
COMBO CODEC	CARD + VAD	For Automatic Speech Recognition	e.g. Smart Home Product
DIGITAL OUTOUT	HDMI OUT	7.1 LPCM Multi Channel / Bitstream	e.g. Dolby / DTS Lossless Bitstream
	DP	7.1 LPCM Multi Channel	e.g. Dolby / DTS Lossless Bitstream
	OPTICAL	2 CH LPCM / 7.1 Bitstream	e.g. 7.1 DD+ Bitstream
	DCODEC	Link with External Analog Part	e.g. RK812
	DSM	Stereo Differential Output	e.g. Play Music over DSM on RV1126
DIGITAL INPUT	HDMI IN	HDMI INPUT	e.g. with Third Part IC, e.g. TC358749
	HDMI ARC	Audio Return Channel	e.g. RK3308
	PDM DMICS	DMIC Array	e.g. 8 Omnidirectional PDM Mics
	I2S DMICS	DMIC Array	e.g. 8 Omnidirectional I2S Mics
	DCODEC	Link with External Analog Part	e.g. RK812
	VAD	Voice Activity Detection	Wake Up System if Sound Threshold Reached
	SPDIF IN	2 CH LPCM	e.g. ARC on RK3308

ANALOG IO	INTERNAL CODECS	2 CH IN / OUT or More	8CH IN on RK3308
	EXTERNAL CODECS	2 CH IN / OUT or More	e.g. RK817
	ACC	Audio Clk Compensation (SW / HW)	e.g. UAC for clk drift and compensation
OTHERS	DLP	Digital Loopback (SW / HW)	e.g. 2 CH Mics with Digital Loopback
	AUPLL-IO-IN	Audio PLL with Clk Sustain	e.g. rk2116 external amp for vehicle

Figure 1-1 Rockchip Audio Features

1.2 DAI

This chapter mainly describes the support for digital audio interfaces on the RK platform.

1.2.1 SAI

1.2.1.1 SAI Controller Features

- Supports flexible protocols, including common I2S/DSP/TDM, etc.
- Supports FSYNC ERR / LOST detection
- Supports FSYNC/SCLK INV
- Supports FSYNC formats with any duty cycle
- Supports flexible DATA timing adjustment. SFT adjustment unit is half SCLK
- Supports Mono: RX supports optional Slot, TX supports Mono copied to all Slots
- Supports Master/Slave mode, the mode applies to both TX/RX logic simultaneously
- Supports 128 slots per lane (subject to clock constraints, e.g., 50M: TDM 32 slots @ 48k 32 bits)
- Supports configurable slot bit width: 8 ~ 32 bits
- Supports slot mask
- Supports full data line mapping, can remap the relationship between data line and path
- Supports TX Auto Stop Mode
- Supports TX->RX Loopback
- Supports Multi SAI Combined (MSC)

1.2.1.2 RK Series Chips SAI Support List

The table below lists the SAIs available for peripheral use:

SAIx	RX Lanes	TX Lanes	Version	Note
RK1820 SAI-M0	4*	4*	V4	SDI0~3 and SDO3~0 multiplexed
RK1820 SAI-M1/M2	4	4	V4	
RK2116 SAI0-RMIO	4	4	V5	Matrix IO full multiplexed
RK2116 SAI1/2/3-RMIO	2	2	V5	
RK2116 SAI4/5/6/7-RMIO	1	1	V5	
RK2118 SAI0/4-RMIO	4	4	V2	
RK2118 SAI1/2/3/5/6/7-RMIO	2	2	V2	
RK3528 SAI0	1	1	V1	
RK3528 SAI1	4	4	V1	
RK3506 SAI0-M0/RMIO	4	1	V2	
RK3506 SAI1-M0/RMIO	1	4	V2	
RK3506 SAI2-M0/M1	1	1	V2	
RK3506 SAI3-M0	1	1	V2	
RK3562 SAI0-M0	4*	4*	V1	SDI1~3 and SDO3~1 multiplexed
RK3562 SAI0-M1	4	4	V1	
RK3562 SAI1-M0	4	4	V1	
RK3562 SAI1-M1	4*	4*	V1	SDI1~3 and SDO3~1 multiplexed
RK3562 SAI2	1	1	V1	
RK3576 SAI0-M0	4	4	V1	
RK3576 SAI0-M1/M2	4*	4*	V1	SDI1~3 and SDO3~1 multiplexed
RK3576 SAI1-M0	4*	4*	V1	SDI1~3 and SDO3~1 multiplexed
RK3576 SAI1-M1	4	4	V1	
RK3576 SAI2-M0/M1/M2	1	1	V1	
RK3576 SAI3-M0/M1/M2/M3	1	1	V1	

SAIx	RX Lanes	TX Lanes	Version	Note
RK3576 SAI4-M0/M1/M2/M3	1	1	V1	
RV1103B SAI	1	1	V3	
RV1126B SAI0-M0/M1	4*	4*	V4	SDI1~3 and SDO3~1 multiplexed
RV1126B SAI1-M0/M1/M2	1	1	V4	
RV1126B SAI2-M0/M1	3	1	V4	

Table 1-2 RK Series Chips SAI Support List

1.2.1.2.1 SAI Version Description

Version	Description
V1	1, First Version
V2	1, Support Frame Sync xN (FSXN) 2, Support Frame Sync Error Detect (FSE) 3, Support Frame Sync Lost Detect (FSLOST) 4, Support SAI Chained 5, Support Transmit Auto Gate Mode 6, Support Timing Shift Left for TX
V3	1, Support Loopback LR Select (e.g. L:MIC R:LP)
V4	1, Enhance Frame Integrity Robustness 2, Support FIFO Interleaved Cfg 3, Support Data Debug
V5	1, Support MSC V2 2, Fsync Clk Phase sync with MAC.pps 3, Clk Sync with USB or MAC by ACC 4, Support Data Debug by ch ID

Table 1-3 SAI Version Description

1.2.2 ASRC

1.2.2.1 ASRC Controller Features

- Supports sample rate conversion 8k ~ 384k
- Supports input/output sample rate conversion with ratio from 1:8 to 8:1.
- Supports asynchronous clock source synchronization.

- Supports THD +N -120dB ~ -140dB @ 24bits
- Supports real-time mode
- Supports file mode
- Supports low latency
- Supports Multi ASRC Combined

1.2.2.2 THD+N

Test environment: AP -> SAI -> ASRC -> SAI -> AP

1.2.2.2.1 16bits

The table below shows THD+N(dB) for 16bits. It does not show the obvious optimal performance at integer multiples as in 24bits, and the overall difference is small.

SR\RSR	8k	11.025k	12K	16K	22.05K	24K	32K	44.1K	48K	64K
8K	-96.2	-96.0	-95.9	-96.0	-95.7	-95.8	-95.7	-95.6	-95.7	-95.6
11.025K	-96.6	-95.9	-95.8	-95.8	-95.6	-95.6	-95.5	-95.5	-95.5	-95.5
12K	-96.7	-96.0	-96.1	-95.5	-95.7	-95.5	-95.5	-95.5	-95.5	-95.5
16K	-97.2	-96.5	-96.3	-95.6	-95.5	-95.5	-95.5	-95.4	-95.4	-95.4
22.05K	-97.7	-97.0	-96.8	-96.2	-95.4	-95.5	-95.4	-95.3	-95.3	-95.3
24K	-97.7	-97.1	-96.9	-96.3	-95.6	-95.5	-95.5	-95.3	-95.3	-95.3
32K	-97.8	-97.4	-97.3	-96.7	-96.2	-96.0	-95.4	-95.3	-95.3	-95.3
44.1K	-98.3	-97.7	-97.7	-97.1	-96.6	-96.5	-96.0	-95.2	-95.2	-95.2
48K	-98.3	-97.7	-97.7	-97.2	-96.7	-96.6	-96.1	-95.5	-95.2	-95.3
64K	-98.2	-98.0	-98.0	-97.5	-97.1	-96.9	-96.5	-96.0	-95.8	-95.3

Table 1-4 16bits THD+N (dB)

1.2.2.2.2 24bits

The table below shows THD+N(dB) for 24bits. The results show that integer multiple conversion yields the best performance.

SR\RSR	8k	11.025k	12K	16K	22.05K	24K	32K	44.1K	48K	64K
8K	-141.3	-132.4	-133.6	-139.8	132.4	-135.0	-137.1	-132.1	-133.7	-133.1
11.025K	-131.8	-140.8	-134.0	-133.0	-137.3	-131.3	-133.0	-138.2	-131.1	-132.2
12K	-138.4	-131.0	-140.9	-131.5	-131.4	-129.5	-132.4	-131.1	-131.6	-131.1
16K	-143.0	-130.0	-138.1	-140.0	-133.3	-134.0	-140.7	-133.0	-135.0	-133.6
22.05K	-129.8	-142.9	-132.0	-131.5	-140.5	-129.5	-128.7	-140.3	-129.4	-129.8
24K	-144.0	-127.3	-142.8	-136.3	-130.5	-140.7	-132.7	-129.8	-140.1	-132.6
32K	-142.0	-136.5	-141.7	-141.8	-127.7	-133.8	-140.5	-132.6	-134.5	-131.7
44.1K	-139.8	-144.7	-139.3	-128.6	-142.8	-132.3	-132.2	-140.5	-129.0	-129.2
48K	-142.6	-122.5	-144.4	-143.3	-126.1	-142.7	-138.8	-130.2	-140.5	-137.3
64K	-142.8	-141.9	-142.2	-143.0	-139.0	-139.2	-142.5	-128.5	-134.9	-140.4

Table 1-5 24bits THD+N (dB)

1.2.2.3 Latency

Latency = Phase Delay + FIFO Delay.

1.2.2.3.1 Phase Delay

RATIO = Sample Rate (output) / Sample Rate (input)

RATIO	Phase Delay
RATIO <= 1	32 samples @ SR(input)
RATIO > 1	32 * ratio samples @ SR(input)

1.2.2.3.2 FIFO Delay

FIFO Delay = ASRC_IN_THRESH + ASRC_OUT_THRESH.

This parameter is configurable. The current software configuration is as shown in the table:

Thresh	Value
ASRC_IN_THRESH	2
ASRC_OUT_THRESH	24

1.2.2.3.3 Example

Case	Latency
48k -> 16k	Latency = $32 + 2 + 24 = 58$ samples @ 48k, 1.2ms
48k -> 48k	Latency = $32 + 2 + 24 = 58$ samples @ 48k, 1.2ms
48k -> 96k	Latency = $32 * (96 / 48) + 2 + 24 = 90$ samples @ 48k, 1.9ms

Note: To optimize latency, adjust FIFO Delay.

1.2.2.4 RK Series Chips ASRC Support List

Chip	ASRC	Max Capability	Version
RK2118	ASRC_8CH x 2, ASRC_4CH x 6	40 CH	V1
RK3506	ASRC_4CH x 2	8 CH	V1
RK3576	ASRC_4CH x 2, ASRC_2CH x 2	12 CH	V1
RV1126B	ASRC_2CH x 2	4 CH	V1

1.2.3 I2S

The RK platform has two types of I2S controllers: I2S and I2S-TDM. The I2S controller supports I2S and PCM protocols; the I2S-TDM controller supports I2S, PCM, and TDM protocols.

1.2.3.1 I2S Controller Features

- Supports 8-channel I2S protocol: standard, left justified, right justified
- Supports stereo PCM protocol: early, late 1, late 2, late 3
- Supports master/slave mode, the mode applies to both TX/RX logic simultaneously
- Supports sample rates from 8k ~ 192k, 384k sample rate
- Supports bit width 16 ~ 32 bits
- Supports MSB/LSB mode
- Supports clock phase adjustment
- Supports clock compensation

Note:

- The 384k sample rate requires a high-precision clk, which can be imported from the MCLK PIN externally or use slave mode.
- Does not support mono PCM. If needed, use stereo PCM to transmit mono PCM, with valid data placed in slot 0.

- Clock compensation is used for clock compensation in systems with different sources, such as UAC, but has usage condition restrictions. Refer to the [Audio Clock Compensation](#) chapter.

1.2.3.2 I2S-TDM Controller Features

In addition to the functions supported by the I2S controller, the I2S-TDM controller adds support for the following functions:

- Supports 8 slots TDM PCM protocol: normal, left shift mode[0~3]
- Supports 8 slots TDM I2S protocol: normal, left justified, right justified
- Supports configurable slot bit width: 16 ~ 32 bits
- Supports full data line mapping, can remap the relationship between data line and path
- Supports TX/RX asynchronous mode, independent clocks, can support independent sample rates, bit widths, protocols
- Supports TX/RX synchronous mode, shared clock
- Supports PCM FSYNC width configuration: [1~7] sclk cycle or one channel block
- Supports I2S FSYNC width configuration: half frame / whole frame

Note:

- Slots only support even configuration.
- In TDM I2S long frame mode, it can support 16-channel transmission.
- Under the TDM protocol, only path-0 is used. Therefore, when the physical connection PIN does not correspond to the channel, please use data line remapping to path-0.

1.2.3.3 RK Series Chips I2S Support List

Chip	I2S	I2S-TDM
PX30/RK3326	I2S1_2CH, I2S2_2CH	I2S0_8CH
RK1808	I2S1	I2S0
RK3036	I2S0	
RK3066	I2S0, I2S1, I2S2	
RK312X	I2S_8CH, I2S_2CH	
RK3188	I2S0	
RK3288	I2S0	
RK322X	I2S0, I2S1, I2S2	
RK3308	I2S_2CH_0, I2S_2CH_1	I2S_8CH_0, I2S_8CH_1, I2S_8CH_2, I2S_8CH_3
RK3328	I2S0, I2S1, I2S2	
RK3368	I2S_8CH, I2S_2CH	
RK3399	I2S0, I2S1, I2S2	
RK3568/RK3566		I2S0_8CH, I2S1_8CH, I2S2_2CH, I2S3_2CH
RK3588	I2S2_2CH, I2S3_2CH	I2S0_8CH, I2S1_8CH
RV1108	I2S0, I2S1, I2S2	
RV1126/RV1109	I2S1_2CH, I2S2_2CH	I2S0_8CH

Table 1-6 RK Series Chips I2S Support List

1.2.4 PDM

The RK platform supports PDM protocol digital mics or ADCs. Specific features are as follows:

1.2.4.1 PDM Controller Features

- Supports master mode only
- Supports up to 8 MIC arrays
- Supports 16 ~ 24 bits bit width
- Supports 8 ~ 48k sample rate
- Supports channel swap
- Supports high-pass filtering: 3.79 Hz, 60 Hz, 243 Hz, 493 Hz

- Supports storage alignment: left-aligned, right-aligned
- Supports full data line mapping
- Supports clock phase adjustment
- Supports clock compensation

Note:

- Storage alignment is only for formats with bit width greater than 16 bits. For formats greater than 16 bits, data is stored by word, and the lower bits are padded with 0 by default.
- Clock compensation is used for clock compensation in systems with different sources, such as UAC, but has usage condition restrictions. Refer to the [Audio Clock Compensation](#) chapter.
- Full data line mapping function is only supported on RV1126 and subsequent chips: RV1126/RV1109, RK3568/RK3566...

1.2.4.2 RK Series Chips PDM Support List

Chip	Name	Max Channel	Version
PX30/RK3326	PDM	8	V2
RK1808	PDM	8	V2
RK2108	PDM	4	V3
RK3308	PDM_8CH	8	V2
RK3328	PDM	8	V1
RK3568/RK3566	PDM	8	V3
RV1126/RV1109	PDM	8	V3

Table 1-7 RK Series Chips PDM Support List

Version Description

Version	Description
V1	1. Supports standard mode, corresponding clocks: 2.048/2.822/3.072 MHz.
V2	1. Added fractional division. 2. Added storage alignment mode.
V3	BUG FIX: 1. Fixed sign bit overflow issue when input signal amplitude is close to 0 db with HPF enabled. 2. Fixed passband ripple consistency issue, new version passband ripple is less than 0.1 db. 3. Fixed aliasing issue. Features: 1. Added low-power mode, corresponding clocks 1.024/1.411/1.536 MHz. 2. Added high-performance mode, corresponding clocks 4.096/5.644/6.144 MHz.

Table 1-8 PDM Version Description

1.2.5 DCODEC

The RK platform supports the digital CODEC interface, which can interface with analog CODECs that support this protocol, such as RK812, to form a complete CODEC.

Additionally, when the controller works in DSM mode, it can drive an external PA to meet the needs of ordinary sound quality products, saving costs.

- Supports 3-channel ADC
- Supports stereo DAC
- Supports asynchronous mode: playback and recording sample rates can be different.
- Supports synchronous mode: playback and recording sample rates must be the same.
- Supports PGA / ALC
- Supports DSM output, directly driving PA
- Supports high-pass filtering

1.2.6 VAD

Voice Activity Detection (VAD). VAD receives data from the DAI, performs statistical analysis, and triggers an interrupt to wake up the system when a preset threshold is reached. A brief data flow diagram is shown in Figure 1-1:




Figure 1-1 RK VAD Data Flow

1. When the system is suspend, DAI -> VAD -> SRAM keeps working. VAD continuously receives data, filters and self-learning noise and stores audio data in the SRAM circular buffer.
2. When VAD detects that the sound exceeds the preset threshold, it generates an interrupt to wake up the CPU. The CPU turns off VAD. When VAD is turned off, the data flow automatically switches to the DMAC path, i.e., the standard recording path: DAI -> DMAC -> DDR -> CPU.
3. The CPU seamlessly fills the data from the SRAM into the recording buffer. Data processing is transparent to the user mode.
4. After waking up, the ASR program analyzes the captured data for processing, keyword detection, etc.

1.2.7 SPDIF

The RK platform supports the SPDIF Transmitter interface protocol. Specifically, RK3308 also supports SPDIF Receiver.

- Supports 16 ~ 24 bits width
- Supports 192k sample rate
- Supports stereo uncompressed audio, i.e., LPCM

- Supports 5.1 / 7.1 compressed audio, e.g., DD, DD+
- Supports Optical, Coaxial

Note:

- When outputting at 192k sample rate, Optical components supporting 192k are required.

1.3 Combo DAI

The RK platform supports the combined use of any DAI, reorganizing DAI to generate Combo DAI, as shown in Figure 1-2:




Figure 1-2 Combo DAI

2. Audio Driver Development

This chapter describes the audio support on the RK platform, driver development, and debugging.

2.1 Basic Sound Card Composition

This section introduces the basic composition of a sound card, as shown in Figure 2-1:




Figure 2-1 ALSA Sound Card Composition

- DAI: Digital Audio Interface.
- MACHINE: Link dai and codec to be a new sound card.
- DMAENGINE: Transfer data between memory and dai's fifo.

In general, adding a sound card based on the released SDK only requires porting or writing a codec driver. In some cases, a machine driver may also need to be added. For details, see the [Machine Driver Development](#) chapter.

2.2 Driver List

The driver list and description are as follows:

```
kernel/sound/soc/rockchip$ tree -I "*.o|*.h"
.
├── rockchip_asrc.c           # asynchronous sample rate converter
├── rockchip_dlp.c           # digital audio loopback
├── rockchip_dlp_pcm.c       # for single dai dlp
├── rockchip_dummy_dai.c     # used for multi-dais as channel map
├── rockchip_hdmi_analog.c   # hdmi and codec share the same i2s
├── rockchip_hdmi.c          # hdmi with jack det
├── rockchip_hdmi_dp.c       # hdmi and dp share the same i2s
├── rockchip_i2s.c           # old i2s which support i2s/pcm
├── rockchip_i2s_tdm.c       # new i2s-tdm which support i2s/pcm/tdm
├── rockchip_multicodecs.c   # support multi-streaming
├── rockchip_multi_dais.c    # support combo-dais
├── rockchip_multi_dais_pcm.c # co-work with combo-dais
├── rockchip_pdm.c           # pdm dai driver
├── rockchip_pdm_v2.c        # pdmv2 dai driver
├── rockchip_sai.c           # sai dai driver
├── rockchip_spdif.c         # spdif tx dai driver
└── rockchip_spdifrx.c       # spdif rx dai driver
```

```

└─ rockchip_trcm.c                # used for i2s-tdm
└─ rockchip_utils.c              # common utils

kernel/sound/soc/codecs$ tree -P "rk*.c|h*.c|d*.c"
.
└─ dmic.c                        # dmic, e.g. i2s dmics, pdm dmics
└─ dummy-codec.c                # dummy codec
└─ hdmi-codec.c                 # hdmi codec driver
└─ rk312x_codec.c               # internal codec
└─ rk3228_codec.c               # internal codec
└─ rk3308_codec.c               # internal codec 8ch adc
└─ rk3328_codec.c               # internal codec
└─ rk3506_codec.c               # internal codec
└─ rk3528_codec.c               # internal codec
└─ rk730.c                      # rk730 audio codec
└─ rk817_codec.c                # codec in rk817 pmic ic
└─ rk_dsm.c                     # audio dsm

```

2.3 DAI Driver Development

The DAI drivers in the released SDK are already completed. Developers only need to configure properties according to the application scenario to enable the corresponding functions.

2.3.1 SAI

2.3.1.1 Protocol Format Settings

SAI supports flexible protocol timing, as shown in the figure:

- Supports FSYNC formats with any duty cycle
- Supports data transmission under any shift condition. Shift in units of half SCLK (SFT)
- Supports FSYNC/SCLK INV

Example 1: FSYNC = 1 x SCLK, SFT = 2 x 0.5 SCLK, rising edge receive data, falling edge send data




Figure 2-2 Timing Gen

Example 2: FSYNC = 1 x SCLK, SFT = 2 x 0.5 SCLK, falling edge receive data, rising edge send data






Figure 2-3 Timing Gen SCLK INV

Common formats listed below are all constructed from the timing shown in the above figures.


2.3.1.1.1 AUDIO_FMT_I2S




2.3.1.1.2 AUDIO_FMT_LEFT_J




2.3.1.1.3 AUDIO_FMT_RIGHT_J




2.3.1.1.4 AUDIO_FMT_DSP_A




2.3.1.1.5 AUDIO_FMT_DSP_B




2.3.1.1.6 AUDIO_FMT_TDM_I2S




2.3.1.1.7 AUDIO_FMT_TDM_I2S_INV




2.3.1.1.8 AUDIO_FMT_TDM_LEFT_J



2.3.1.1.9 AUDIO_FMT_TDM_DSP_A



2.3.1.1.10 AUDIO_FMT_TDM_DSP_B




2.3.1.2 Multi Lanes


In Multi Lanes scenarios, the channel arrangement is interleaved, with a granularity of 2 CHs as a unit. For scenarios with more than 2 Lanes, if the peer data is output in Lane order, de-interleaving is required. You can directly call the API to handle it.

The following describes the channel arrangement relationship of Multi Lanes using TDM16 as an example. The same applies to other formats.


2.3.1.2.1 TDM16 x 1




2.3.1.2.2 TDM16 x 2



2.3.1.2.3 TDM16 x 3



2.3.1.2.4 TDM16 x 4



2.3.1.2.5 Order vs Interleaved

The corresponding relationship when interfacing with an ordered format is described using TDM16 x 2. The same applies to others.

As shown in the figure, the signal transmitted from the peer is arranged sequentially on the Lane. SAI receives it in an interleaved manner. The received data arrangement is as shown in the figure and needs to be de-interleaved to output in an ordered format.




Figure 2-4 Order vs Interleaved





Figure 2-5 De-Interleaved

2.3.1.3 Multi SAI Combined

Supports merging multiple SAIs into one SAI for use, expanding Lanes capability.

- Based on a one-master-multiple-slaves mechanism, the SoC internally provides clock signal sharing.
- Only the master SAI provides the interface clock. Pay attention to hardware layout.
- SAI V5 supports merging audio streams (previous versions merged audio streams via DMA)


Example: SAI0 + SAI1 + SAI2 form I2S 8TX




2.3.1.4 Slot Mask

SAI supports slot mask. You can ignore data from the corresponding slot by configuring the mask bit.

Example 1: TDM16 x 1 with Mask last 2 slot



Example 2: TDM16 x 2 with Mask last 2 slot



Note:

The slot mask acts on all Lanes simultaneously, so be careful when using it in Multi Lanes scenarios.

2.3.1.5 slot width settings

Property	Value	Description
rockchip,sai-slot-width	int	Default slot width is 32bit

Example: slot width is 16bits, typically used in bt scenarios, equivalent to the bclk-fs property of I2S.

```
&sai0 {
    rockchip,sai-slot-width = <16>;
};
```

2.3.1.6 data line full mapping settings

Hardware can connect to any data line. Configure the corresponding properties to correct the channel order, or use [path sel](#) to select or check correctness.

property	value	Description
rockchip,sai-tx-route		Default order: SDO0 SDO1 SDO2 SDO3
rockchip,sai-rx-route		Default order: SDI0 SDI1 SDI2 SDI3

Example: Playback channel order is "SDO3 | SDO2 | SDO1 | SDO0"

```
&sai0 {
    rockchip,sai-tx-route = <3 2 1 0>;
};
```

2.3.1.7 multi lanes settings

This property is mainly used for Multiple Lanes TDM. It can also be selected or checked for correctness via [lanes sel](#).

property	value	Description
rockchip,tdm-tx-lanes	int	Default 1 lane
rockchip,tdm-rx-lanes	int	Default 1 lane

Example: tdm-tx x 4, tdm-rx x 2

```
&sai0 {
    rockchip,tdm-tx-lanes = <4>;
    rockchip,tdm-rx-lanes = <2>;
};
```

2.3.1.8 wait time

This property is mainly used for the timeout mechanism in slave mode. When the peripheral clock is lost, the ASoC framework times out by default after 10s and returns. This property can be configured to shorten the waiting time and optimize the experience. It is recommended to set it greater than or equal to the buffer time.

property	value	Description
rockchip,sai-tx-wait-time-ms	int	Default 10s
rockchip,sai-rx-wait-time-ms	int	Default 10s

Example: buffer time 40ms, wait time 50ms

```
&sai0 {
    rockchip,sai-tx-wait-time-ms = <50>;
    rockchip,sai-rx-wait-time-ms = <50>;
};
```

2.3.1.9 mclkout / mclk_in

mclk supports mclkout and mclk_in functions, sharing pins. Combined with the sai master/slave mode, the usage scenarios are described. If the peripheral does not need mclk, the connection can be omitted.

sai	mclk	Description
master	out	SoC provides clock to the peripheral
master	in	sai uses external mclk_in clock, typical application: audio clock same source
slave	out	Peripheral works in master mode, mclk provided by SoC
slave	in	No application scenario

Example: mclkout

```
rk817_codec: codec {
    #sound-dai-cells = <0>;
    compatible = "rockchip,rk817-codec";
    clocks = <&mclkout_sai0>;
    clock-names = "mclk";
    assigned-clocks = <&mclkout_sai0>;
    assigned-clock-rates = <12288000>;
    pinctrl-names = "default";
    pinctrl-0 = <&i2s0m0_mclk>;
    hp-volume = <20>;
    spk-volume = <3>;
    mic-in-differential;
    status = "okay";
};
```

```
};
```

Example: mclkin

```
&sai0 {
    assigned-clocks = <&cru CLK_SAI0>;
    assigned-clock-parents = <&mclkin_i2s0>;
    pinctrl-0 = <&sai0_sdi
                &sai0_sdo
                &sai0_lrck
                &sai0_sclk
                &sai0_mclk>;
};

&mclkin_sai0 {
    clock-frequency = <24576000>;
    status = "okay";
};
```

2.3.1.10 controls

You can easily view and set modes, protocols, functions, etc., via amixer or tiny mixer.

```
# amixer -c 0 controls
numid=34,iface=MIXER,name='SAI2 Clk Auto Switch'
numid=5,iface=MIXER,name='SAI2 Receive Mono Slot Select'
numid=6,iface=MIXER,name='SAI2 Receive Mono Switch'
numid=29,iface=MIXER,name='SAI2 Receive PATH0 Source Select'
numid=28,iface=MIXER,name='SAI2 Receive PATH1 Source Select'
numid=27,iface=MIXER,name='SAI2 Receive PATH2 Source Select'
numid=26,iface=MIXER,name='SAI2 Receive PATH3 Source Select'
numid=4,iface=MIXER,name='SAI2 Receive SDIx Select'
numid=2,iface=MIXER,name='SAI2 Receive Start Mode Sel'
numid=11,iface=MIXER,name='SAI2 SDI0 Loopback I2S LR Channel Sel'
numid=15,iface=MIXER,name='SAI2 SDI0 Loopback I2S LR Switch'
numid=19,iface=MIXER,name='SAI2 SDI0 Loopback Src Select'
numid=23,iface=MIXER,name='SAI2 SDI0 Loopback Switch'
numid=10,iface=MIXER,name='SAI2 SDI1 Loopback I2S LR Channel Sel'
numid=14,iface=MIXER,name='SAI2 SDI1 Loopback I2S LR Switch'
numid=18,iface=MIXER,name='SAI2 SDI1 Loopback Src Select'
numid=22,iface=MIXER,name='SAI2 SDI1 Loopback Switch'
numid=9,iface=MIXER,name='SAI2 SDI2 Loopback I2S LR Channel Sel'
numid=13,iface=MIXER,name='SAI2 SDI2 Loopback I2S LR Switch'
numid=17,iface=MIXER,name='SAI2 SDI2 Loopback Src Select'
numid=21,iface=MIXER,name='SAI2 SDI2 Loopback Switch'
numid=8,iface=MIXER,name='SAI2 SDI3 Loopback I2S LR Channel Sel'
numid=12,iface=MIXER,name='SAI2 SDI3 Loopback I2S LR Switch'
numid=16,iface=MIXER,name='SAI2 SDI3 Loopback Src Select'
numid=20,iface=MIXER,name='SAI2 SDI3 Loopback Switch'
numid=25,iface=MIXER,name='SAI2 Sync In Switch'
numid=24,iface=MIXER,name='SAI2 Sync Out Switch'
```



```

numid=7,iface=MIXER,name='SAI2 Transmit Mono Switch'
numid=33,iface=MIXER,name='SAI2 Transmit SD00 Source Select'
numid=32,iface=MIXER,name='SAI2 Transmit SD01 Source Select'
numid=31,iface=MIXER,name='SAI2 Transmit SD02 Source Select'
numid=30,iface=MIXER,name='SAI2 Transmit SD03 Source Select'
numid=3,iface=MIXER,name='SAI2 Transmit SDOx Select'
numid=1,iface=MIXER,name='SAI2 Transmit Start Mode Sel'
numid=35,iface=PCM,name='SAI2 PCM Read Wait Time MS'
numid=36,iface=PCM,name='SAI2 PCM Write Wait Time MS'

```

2.3.1.10.1 path sel

sai transmits data in the order PATH0~3: when 1 lane is enabled, PATH0 is used; when 2 lanes are enabled, PATH0/1 are used; and so on.

PATHx and SDx are fully mapped. You can select SDIx / SDOx to route data, providing flexible hardware connections.

```

numid=29,iface=MIXER,name='SAI2 Receive PATH0 Source Select'
numid=28,iface=MIXER,name='SAI2 Receive PATH1 Source Select'
numid=27,iface=MIXER,name='SAI2 Receive PATH2 Source Select'
numid=26,iface=MIXER,name='SAI2 Receive PATH3 Source Select'
numid=33,iface=MIXER,name='SAI2 Transmit SD00 Source Select'
numid=32,iface=MIXER,name='SAI2 Transmit SD01 Source Select'
numid=31,iface=MIXER,name='SAI2 Transmit SD02 Source Select'
numid=30,iface=MIXER,name='SAI2 Transmit SD03 Source Select'

```

Example: SAI2 4CH I2S format data output from SDO2/3

```

# amixer cset iface=MIXER,name='SAI2 Transmit SD02 Source Select' "From PATH0"
numid=31,iface=MIXER,name='SAI2 Transmit SD02 Source Select'
; type=ENUMERATED,access=rw-----,values=1,items=4
; Item #0 'From PATH0'
; Item #1 'From PATH1'
; Item #2 'From PATH2'
; Item #3 'From PATH3'
: values=0

# amixer cset iface=MIXER,name='SAI2 Transmit SD03 Source Select' "From PATH1"
numid=30,iface=MIXER,name='SAI2 Transmit SD03 Source Select'
; type=ENUMERATED,access=rw-----,values=1,items=4
; Item #0 'From PATH0'
; Item #1 'From PATH1'
; Item #2 'From PATH2'
; Item #3 'From PATH3'
: values=1

```

Example: SAI2 2CH I2S format data input from SDI3

```
# amixer cset iface=MIXER,name='SAI2 Receive PATH0 Source Select' "From SDI3"
numid=29,iface=MIXER,name='SAI2 Receive PATH0 Source Select'
; type=ENUMERATED,access=rw-----,values=1,items=4
; Item #0 'From SDI0'
; Item #1 'From SDI1'
; Item #2 'From SDI2'
; Item #3 'From SDI3'
: values=3
```

2.3.1.10.2 lanes sel

Select the number of SDO and SDI lanes to use N lanes. The default is "Auto" mode. In I2S format, it is automatically enabled based on 2ch per lane. In TDM mode, only 1 lane will be used in this mode. When multiple lane TDM is needed, configure N lanes before the controller works.

```
numid=4,iface=MIXER,name='SAI2 Receive SDIx Select'
numid=3,iface=MIXER,name='SAI2 Transmit SDOx Select'
```

Example: TDM-TX: 2 lanes TDM-RX: 4 lanes

```
# amixer -c 0 cset iface=MIXER,name='SAI2 Transmit SDOx Select' "SDOx2"
numid=3,iface=MIXER,name='SAI2 Transmit SDOx Select'
; type=ENUMERATED,access=rw-----,values=1,items=5
; Item #0 'Auto'
; Item #1 'SDOx1'
; Item #2 'SDOx2'
; Item #3 'SDOx3'
; Item #4 'SDOx4'
: values=2

# amixer -c 0 cset iface=MIXER,name='SAI2 Receive SDIx Select' "SDIx4"
numid=4,iface=MIXER,name='SAI2 Receive SDIx Select'
; type=ENUMERATED,access=rw-----,values=1,items=5
; Item #0 'Auto'
; Item #1 'SDIx1'
; Item #2 'SDIx2'
; Item #3 'SDIx3'
; Item #4 'SDIx4'
: values=4
```

2.3.1.10.3 loopback sel

Supports digital loopback at the lane level. Select the source of SDIx to be from SDOx. No hardware connection is required.

```

numid=19,iface=MIXER,name='SAI2 SDI0 Loopback Src Select'
numid=23,iface=MIXER,name='SAI2 SDI0 Loopback Switch'
numid=18,iface=MIXER,name='SAI2 SDI1 Loopback Src Select'
numid=22,iface=MIXER,name='SAI2 SDI1 Loopback Switch'
numid=17,iface=MIXER,name='SAI2 SDI2 Loopback Src Select'
numid=21,iface=MIXER,name='SAI2 SDI2 Loopback Switch'
numid=16,iface=MIXER,name='SAI2 SDI3 Loopback Src Select'
numid=20,iface=MIXER,name='SAI2 SDI3 Loopback Switch'

```

Example: The loopback signal for SDI1 comes from SDO3

```

# amixer -c 0 cset iface=MIXER,name='SAI2 SDI0 Loopback Src Select' "From SDO3"
numid=19,iface=MIXER,name='SAI2 SDI0 Loopback Src Select'
; type=ENUMERATED,access=rw-----,values=1,items=4
; Item #0 'From SDO0'
; Item #1 'From SDO1'
; Item #2 'From SDO2'
; Item #3 'From SDO3'
: values=3

```

Starting from SAI-V3, i2s 1mic + 1lp loopback combination is supported. Chip support refers to the [SAI Support List](#).

```

numid=11,iface=MIXER,name='SAI2 SDI0 Loopback I2S LR Channel Sel'
numid=15,iface=MIXER,name='SAI2 SDI0 Loopback I2S LR Switch'
numid=10,iface=MIXER,name='SAI2 SDI1 Loopback I2S LR Channel Sel'
numid=14,iface=MIXER,name='SAI2 SDI1 Loopback I2S LR Switch'
numid=9,iface=MIXER,name='SAI2 SDI2 Loopback I2S LR Channel Sel'
numid=13,iface=MIXER,name='SAI2 SDI2 Loopback I2S LR Switch'
numid=8,iface=MIXER,name='SAI2 SDI3 Loopback I2S LR Channel Sel'
numid=12,iface=MIXER,name='SAI2 SDI3 Loopback I2S LR Switch'

```

Example: I2S left channel MIC data + right channel loopback data

```

# amixer -c 0 cset iface=MIXER,name='SAI2 SDI0 Loopback I2S LR Channel Sel' "L:M
IC R:LP"
numid=11,iface=MIXER,name='SAI2 SDI0 Loopback I2S LR Channel Sel'
; type=ENUMERATED,access=rw-----,values=1,items=2
; Item #0 'L:MIC R:LP'
; Item #1 'L:LP R:MIC'
: values=0

```

2.3.2 ASRC

Currently uses the multicodec driver to integrate ASRC into the audio stream.

2.3.2.1 Sound Card Configuration

1. Enable CONFIG

```
CONFIG_SND_SOC_ROCKCHIP_ASRC=y
```

2. After the sound card is successfully configured, two devices will be generated. Take sound card 0 as an example:

Sound Card Device	Description
hw:0,0	without asrc
hw:0,1	with asrc

Example 1: SAI(Slave) -> ASRC -> MEM

```
sai0-asrc-sound {
    compatible = "rockchip,multicodecs-card";
    rockchip,card-name = "rockchip,sai0-asrc";
    rockchip,mclk-fs = <256>;
    rockchip,format = "i2s";
    rockchip,cpu = <&sai0>;
    rockchip,asrc = <&asrc0>;
    rockchip,codec = <&dummy_codec>;
    rockchip,bitclock-master = <&dummy_codec>;
    rockchip,frame-master = <&dummy_codec>;
    rockchip,audio-routing =
        "Dummy Playback", "SAI0 Playback",
        "SAI0 Capture", "Dummy Capture",
        "SAI0 Playback", "ASRC0 Playback",
        "ASRC0 Capture", "SAI0 Capture";
};
```

Example 2: SPDIFRX -> ASRC -> MEM

```
spdifrx0-asrc-sound {
    compatible = "rockchip,multicodecs-card";
    rockchip,card-name = "spdifrx0-asrc";
    rockchip,cpu = <&spdif_rx0>;
    rockchip,asrc = <&asrc0>;
    rockchip,codec = <&dummy_codec>;
    rockchip,audio-routing =
        "Dummy Capture", "Dummy Capture",
        "ASRC0 Capture", "SPDIF_RX0 Capture";
};
```

2.3.2.2 Resample Settings

Set the resample clock to 48K as follows:

```
amixer -c 0 sset 'ASRC0 SET RESAMPLE RATE' 48000
```

2.3.2.3 Clock Source Settings

Set the SRC/DST tracking clock source for ASRC. SRC/DST can be any combination of local clock and external clock.

Example 1: ASRC's SRC clock comes from SAI0, DST clock comes from ASRC. ASRC handles the asynchronous between SAI0 and the local clock.

```
amixer -c 0 sset 'ASRC0 RX LINK DAI Select' 'sai0'  
amixer -c 0 sset 'ASRC0 TX LINK DAI Select' 'asrc0'
```

Example 2: ASRC's SRC clock comes from SAI0, DST clock comes from SAI2. ASRC handles the asynchronous between SAI0 and SAI2.

```
amixer -c 0 sset 'ASRC0 RX LINK DAI Select' 'sai0'  
amixer -c 0 sset 'ASRC0 TX LINK DAI Select' 'sai2'
```

2.3.2.4 Recording

```
amixer -c 0 sset 'ASRC0 SET RESAMPLE RATE' 48000  
amixer -c 0 sset 'ASRC0 RX LINK DAI Select' 'sai0'  
amixer -c 0 sset 'ASRC0 TX LINK DAI Select' 'asrc0'  
arecord -D hw:0,1 --period-size=1024 --buffer-size=4096 -r 48000 -c 2 -f s16_le r.wav
```

2.3.2.5 Playback

```
amixer -c 0 sset 'ASRC0 SET RESAMPLE RATE' 48000  
amixer -c 0 sset 'ASRC0 RX LINK DAI Select' 'asrc0'  
amixer -c 0 sset 'ASRC0 TX LINK DAI Select' 'sai0'  
aplay -D hw:0,1 --period-size=1024 --buffer-size=4096 r.wav
```

2.3.3 I2S

2.3.3.1 Protocol format configuration

Protocol format configuration is achieved by parsing the DTS through the Machine Driver, and then invoking the API `set_fmt` to set the protocol format of the controller. For Simple Card, please refer to the [Simple Card](#) section.

2.3.3.2 Master / Slave configuration

Master / slave configuration is achieved by parsing the DTS through the Machine Driver, and then invoking the API `set_fmt` to set the protocol format of the controller. For Simple Card, please refer to the [Simple Card](#) section.

2.3.3.3 Clock phase inversion configuration

Clock phase inversion configuration is achieved by parsing the DTS through the Machine Driver, and then invoking the API `set_fmt` to set the protocol format of the controller. For Simple Card, please refer to the [Simple Card](#) section.

2.3.3.4 bclk-fs configuration

Property	Value	Description
rockchip,bclk-fs	int	The default value for bclk is 64 times the sampling rate

Example: bclk is 32 times the sampling rate

```
&i2s0 {
    rockchip,bclk-fs = <32>;
};
```

2.3.3.5 High-precision clock configuration

Property	Value	Description
rockchip,mclk-calibrate	boolean	Support high-precision clock and clock compensation, please refer to audio clock compensation

2.3.3.6 wait time

This property is mainly used for the timeout mechanism in slave mode. When the peripheral clock is lost, the ASoC framework times out by default after 10s and returns. This property can be configured to shorten the waiting time and optimize the experience. It is recommended to set it greater than or equal to the buffer time.

property	value	Description
rockchip,i2s-tx-wait-time-ms	int	Default 10s
rockchip,i2s-rx-wait-time-ms	int	Default 10s

Example: buffer time 40ms, wait time 50ms

```
&i2s0 {  
    rockchip,i2s-tx-wait-time-ms = <50>;  
    rockchip,i2s-rx-wait-time-ms = <50>;  
};
```

2.3.3.7 Others

Property	Value	Description
rockchip,no-dmaengine	boolean	Used for Multi-DAI, please refer to Combo DAI Driver
rockchip,playback-only	boolean	Only supports playback function
rockchip,capture-only	boolean	Only supports capture function

2.3.3.8 mclkout / mclk_in

mclk supports mclkout and mclk_in functions, sharing pins. Combined with the i2s master/slave mode, the usage scenarios are described. If the peripheral does not need mclk, the connection can be omitted.

i2s	mclk	Description
master	out	SoC provides clock to the peripheral
master	in	i2s uses external mclk_in clock, typical application: audio clock same source
slave	out	Peripheral works in master mode, mclk provided by SoC
slave	in	No application scenario

Example: mclkout

```
rk817_codec: codec {
```

```

        #sound-dai-cells = <0>;
        compatible = "rockchip,rk817-codec";
        clocks = <&mclkout_i2s0>;
        clock-names = "mclk";
        assigned-clocks = <&mclkout_i2s0>;
        assigned-clock-rates = <12288000>;
        pinctrl-names = "default";
        pinctrl-0 = <&i2s0m0_mclk>;
        hp-volume = <20>;
        spk-volume = <3>;
        mic-in-differential;
        status = "okay";
};

```

Example: mclkin

```

&i2s3_2ch {
    assigned-clocks = <&cru CLK_I2S3_2CH>;
    assigned-clock-parents = <&mclkin_i2s3>;
    pinctrl-0 = <&i2s3_sdi
                &i2s3_sdo
                &i2s3_lrck
                &i2s3_sclk
                &i2s3_mclk>;
};

&mclkin_i2s3 {
    clock-frequency = <24576000>;
    status = "okay";
};

```

For more details, please refer to: [kernel/Documentation/devicetree/bindings/sound/rockchip-i2s.txt](https://kernel.org/doc/Documentation/devicetree/bindings/sound/rockchip-i2s.txt)

2.3.4 I2S-TDM

In addition to the functions supported by the I2S controller, the I2S-TDM controller also adds support for the following features

2.3.4.1 TX/RX Clock Sharing configuration

Property	Value	Description
rockchip,clk-trcm	0	TX/RX are logically independent and use their own clocks, and there are two sets of clocks on IO
rockchip,clk-trcm	1	TX/RX are logically synchronized and share the clock of TX. There is only the clock of TX on the IO
rockchip,clk-trcm	2	TX/RX are logically synchronized and share the clock of RX. There is only the clock of RX on the IO

Example: Set to share the TX clock mode.

```
&i2s0 {  
    rockchip,clk-trcm = <1>;  
};
```

2.3.4.2 Data Lane Remapping configuration

The hardware design can connect to any SDOx/SDIx, and the software can remap the relationship between the PATHx and SDOx/SDIx.

property	value	Description
rockchip,i2s-tx-route	<int int int int>	Default order: SDO0 SDO1 SDO2 SDO3
rockchip,i2s-rx-route	<int int int int>	Default order: SDI0 SDI1 SDI2 SDI3

Example: Playback channel order is arranged as "SDO3 | SDO2 | SDO1 | SDO0".

```
&i2s0 {  
    rockchip,i2s-tx-route = <3 2 1 0>;  
};
```

2.3.4.3 TDM half-frame mode configuration

property	value	Description
rockchip,tdm-fsync-half-frame	boolean	In TDM I2S mode, the frame clock supports both half-frame and long-frame formats, long-frame format default.

Example: Half-frame format

```
&i2s0 {
    rockchip,tdm-fsync-half-frame;
};
```

2.3.4.4 TDM Slots configuration

The driver has implemented the API `set_tdm_slot`, and the machine driver parses the DTS properties and calls the API `set_tdm_slot` to set the corresponding slots of the controller. For Simple Card, please refer to the section [Simple Card](#).

2.3.4.5 mclkout / mclkin

mclk supports mclkout and mclkin functions, sharing pins. Combined with the i2stdm master/slave mode, the usage scenarios are described. If the peripheral does not need mclk, the connection can be omitted.

i2stdm	mclk	Description
master	out	SoC provides clock to the peripheral
master	in	i2stdm uses external mclkin clock, typical application: audio clock same source
slave	out	Peripheral works in master mode, mclk provided by SoC
slave	in	No application scenario

Example: mclkout

```
rk817_codec: codec {
    #sound-dai-cells = <0>;
    compatible = "rockchip,rk817-codec";
    clocks = <&mclkout_i2s0>;
    clock-names = "mclk";
    assigned-clocks = <&mclkout_i2s0>;
    assigned-clock-rates = <12288000>;
    pinctrl-names = "default";
    pinctrl-0 = <&i2s0m0_mclk>;
    hp-volume = <20>;
    spk-volume = <3>;
    mic-in-differential;
    status = "okay";
};
```

Example: mclkin

```
&i2s0_8ch {
    assigned-clocks = <&cru CLK_I2S0_8CH_TX>, <&cru CLK_I2S0_8CH_RX>;
    assigned-clock-parents = <&mclkin_i2s0>, <&mclkin_i2s0>;
    pinctrl-0 = <&i2s0_sdi0
        &i2s0_sdo0
```

```

        &i2s0_lrck
        &i2s0_sclk
        &i2s0_mclk>;

};

&mclkin_i2s0 {
    clock-frequency = <24576000>;
    status = "okay";
};

```

For more details, please refer to: [kernel/Documentation/devicetree/bindings/sound/rockchip,i2s-tdm.txt](#)

2.3.5 PDM

2.3.5.1 Data Lane Remapping configuration

The hardware design can connect to any SDIx, and the software can remap the relationship between the PATHx and SDIx.

property	value	Description
rockchip,path-map	<int int int int>	Default order: SDI0 SDI1 SDI2 SDI3

Example: Recording channel order arranged as "SDI3 | SDI2 | SDI1 | SDI0"

```

&pdm_8ch {
    rockchip,path-map = <3 2 1 0>;
};

```

2.3.5.2 High-precision clock configuration

Property	Value	Description
rockchip,mclk-calibrate	boolean	Support high-precision clock and clock compensation, please refer to audio clock compensation

2.3.5.3 Others

Property	Value	Description
rockchip,no-dmaengine	boolean	Used for Multi-DAI, please refer to Combo DAI Driver

For more details, please refer to: [kernel/Documentation/devicetree/bindings/sound/rockchip,pdm.txt](#)

For more details, please refer to:
<kernel/Documentation/devicetree/bindings/sound/rockchip,codec-digital.txt>

2.3.7 VAD

2.3.7.1 Audio source configuration

Property	Value	Description
rockchip,audio-src	phandle	Set the audio source for speech detection

The audio source used for voice detection comes from DAI, and the audio sources supported by different chips are different, as shown in the following table:

SoC	Audio Source
RK1808	I2S0, I2S1, PDM
RK3308	I2S_8CH_0, I2S_8CH_1, I2S_8CH_2, I2S_8CH_3, PDM_8CH
RK3568/RK3566	I2S1_8CH, I2S2_2CH, I2S3_2CH

Example: VAD use PDM_8CH as audio source on RK3308

```
&vad {
    rockchip,audio-src = <&pdm_8ch>;
};
```

2.3.7.2 Detect channel configuration

Property	Value	Description
rockchip,det-channel	int	Set the channel used for detection, default channel 0

Example: VAD uses channel 2 as detection channel on RK3308

```
&vad {
    rockchip,det-channel = <2>;
};
```

2.3.7.3 Data storage mode configuration

Property	Value	Description
rockchip,mode	0	The audio data is buffered only after the VAD detects a speech signal.
rockchip,mode	1	Once the VAD is enabled, the audio data is immediately buffered.
rockchip,mode	2	Do not buffer any audio data.

Example: VAD uses mode 1 on RK3308

```
&vad {  
    rockchip,mode = <1>;  
};
```

Note:

In order to ensure that the post-ASR application can obtain the complete audio data, it is recommended to use Mode 1. The buffered data is stored in the circular bufer of the SRAM. After the VAD wakes up the system, the audio data buffered on the SRAM is merged into the audio stream, and this part of the data processing is transparent to the application.

2.3.7.4 Buffer size configuration

Property	Value	Description
rockchip,buffer-time-ms	int	Set the VAD buffer size, the size is equal to: sample rate * bit width * channel * time.

Example: Set the buffer time to 100ms, which is 204800 bytes under the condition of 16k 16bits 8ch.

```
&vad {  
    rockchip,buffer-time-ms = <100>;  
};
```

Note: Increasing the buffer size will increase the latency of the ASR application accordingly. Moreover, the system SRAM is limited, so adjust it with caution. The adjustment strategy is to "ensure data integrity", that is, the buffer size should cover the "wake-up -> application takeover" time. If this part of the time is too long, please optimize it.

For more details, please refer to: <kernel/Documentation/devicetree/bindings/sound/rockchip,vad.txt>

2.4 Combo DAI Driver Development

2.4.1 Sub Dai configuration

Property	Value	Description
dais	<phandle>...	Sub-DAI is used to combine with other Sub-DAIs to form a combo DAI. The "rockchip,no-dmaengine" property is used for Sub-DAI to remove the associated DMA engine and then unify the registration and binding by the Combo DAI framework.

Example: Combine i2s_8ch_2 and pdm_8ch into Combo DAI

```
&i2s_8ch_2 {
    status = "okay";
    rockchip,no-dmaengine;
};

&pdm_8ch {
    status = "okay";
    rockchip,no-dmaengine;
};

&multi-dais {
    dais = <&i2s_8ch_2>, <&pdm_8ch>;
};
```

2.4.2 Channel Mapping configuration

Property	Value	Description
capture,channel-mapping	<int ...>	The number of capture channels for each sub DAI used for combination
playback,channel-mapping	<int ...>	The number of playback channels for each sub DAI used for combination

Example: Stereo playback and 8-channel capture (6-channel microphone + 2-channel loopback).

```
&multi-dais {
    dais = <&i2s_8ch_2>, <&pdm_8ch>;
    playback,channel-mapping = <2 0>;
    capture,channel-mapping = <2 6>;
};
```

2.4.3 Master / Slave configuration

Property	Value	Description
bitclock-master	<int ...>	Set the device that provides the bit clock, with 1 indicating that the device provides the clock, i.e., the master.
frame-master	<int ...>	Set the device that provides the frame clock, with 1 indicating that the device provides the clock, i.e., the master.

Example 1: Combining i2s_8ch_2 and pdm_8ch to form an 8-channel capture sound card (loopback + microphone array). i2s_8ch_2 can be configured as a master/slave mode, and in this example, it is set as the master while pdm only supports the master mode.

```
&multi-dais {
    dais = <&i2s_8ch_2>, <&pdm_8ch>;
    capture,channel-mapping = <2 6>;
    playback,channel-mapping = <2 0>;
    bitclock-master = <1 1>;
    frame-master = <1 1>;
};
```

Example 2: Combining two I2S to form 16 channels, one as master and one as slave. The external hardware needs to connect the DAI that provides the clock to each slave DAI.

```
&multi-dais {
    dais = <&i2s_8ch_0>, <&i2s_8ch_1>;
    capture,channel-mapping = <8 8>;
    playback,channel-mapping = <8 8>;
    bitclock-master = <1 0>;
    frame-master = <1 0>;
};
```

Example 3: Combining two I2S interfaces to form 16 channels, both set to slave mode, and the the clock is provided by the codec which act as master.

```
&multi-dais {
    dais = <&i2s_8ch_0>, <&i2s_8ch_1>;
    capture,channel-mapping = <8 8>;
    playback,channel-mapping = <8 8>;
    bitclock-master = <0 0>;
    frame-master = <0 0>;
};
```


2.4.4 Clock phase inversion configuration

Property	Value	Description
bitclock-inversion	<int ...>	1 indicates inverted bit clock
frame-inversion	<int ...>	1 indicates inverted frame clock

Example: Invert the clocks of all sub-DAIs.

```
&multi-dais {
    dais = <&i2s_8ch_0>, <&i2s_8ch_1>;
    bitclock-inversion = <1 1>;
    frame-inversion = <1 1>;
};
```

2.4.5 Examples

Example 1: RK3308 PDM array microphone + stereo capture + stereo playback + VAD voice detection

```
multi_dais: multi-dais {
    status = "okay";
    compatible = "rockchip,multi-dais";
    dais = <&i2s_8ch_2>, <&pdm_8ch>;
    capture,channel-mapping = <2 6>;
    playback,channel-mapping = <2 0>;
    bitclock-master = <1 1>;
    frame-master = <1 1>;
    bitclock-inversion = <0 0>;
    frame-inversion = <0 0>;
    rockchip,grf = <&grf>;
};

&i2s_8ch_2 {
    status = "okay";
    rockchip,no-dmaengine;
};

&pdm_8ch {
    status = "okay";
    rockchip,no-dmaengine;
};

vad-sound {
    status = "okay";
    compatible = "rockchip,multicodecs-card";
    rockchip,card-name = "rockchip,rk3308-vad";
    rockchip,cpu = <&multi_dais>;
    rockchip,codec = <&acodec>, <&vad>;
};
```

```
};
```

Example 2: RK3308 SoundBar I2S_8CH_0 + I2S_8CH_1 combined for 16-channel output

```
&i2s_8ch_0 {
    #sound-dai-cells = <0>;
    rockchip,no-dmaengine;
};

&i2s_8ch_1 {
    #sound-dai-cells = <0>;
    rockchip,no-dmaengine;
    pinctrl-names = "default";
    pinctrl-0 = <&i2s_8ch_1_m0_sdo0
                  &i2s_8ch_1_m0_sdo1_sdi3
                  &i2s_8ch_1_m0_sdo2_sdi2
                  &i2s_8ch_1_m0_sdo3_sdi1
                  &i2s_8ch_1_m0_sdi0>;
};

i2s_16ch_dais: i2s-16ch-dais {
    compatible = "rockchip,rk3308-multi-dais", "rockchip,multi-dais";
    dais = <&i2s_8ch_0>, <&i2s_8ch_1>;
    capture,channel-mapping = <8 8>;
    playback,channel-mapping = <8 8>;
    bitclock-master = <1 0>;
    frame-master = <1 0>;
    rockchip,grf = <&grf>;
};
```

For more details, please refer to: <kernel/Documentation/devicetree/bindings/sound/rockchip,multidais.txt>

2.5 CODEC Driver Development

Please refer to: [Linux Sound Subsystem Documentation](#)

2.6 Machine Driver Development

The main purpose of this section is to describe the steps for adding a sound card with practical examples.

2.6.1 Simple Card Driver

Simple Card is a general-purpose machine driver for ASoC which can be adapted to most standard sound cards.

2.6.1.1 Protocol Format configuration

Property	Value	Description
simple-audio-card,format	string	Set the protocol format

Format	Description
i2s	i2s standard format
right_j	i2s right-justified format
left_j	i2s left-justified format
dsp_a	pcm delay 1 bit
dsp_b	pcm no delay
pdm	pdm format

Example: set to i2s left-justified format

```
audiopwmout_diff: audiopwmout-diff {
    compatible = "simple-audio-card";
    ....
    simple-audio-card,format = "left_j";
    simple-audio-card,cpu {
        sound-dai = <&i2s3_2ch>;
    };
    master: simple-audio-card,codec {
        sound-dai = <&dig_acodec>;
    };
};
```

2.6.1.2 mclk-fs configuration

Property	Value	Description
simple-audio-card,mclk-fs	int	By default, mclk is 256 times the sample rate

Example: mclk is 512 times the sample rate.

```

audiopwmout_diff: audiopwmout-diff {
    compatible = "simple-audio-card";
    ....
    simple-audio-card,mclk-fs = <512>;
    simple-audio-card,cpu {
        sound-dai = <&i2s3_2ch>;
    };
    master: simple-audio-card,codec {
        sound-dai = <&dig_acodec>;
    };
};

```

2.6.1.3 Master / Slave configuration

Property	Value	Description
simple-audio-card,bitclock-master	phandle	Set the device that provides the bit clock, by default DAI provides the clock
simple-audio-card,frame-master	phandle	Set the device that provides the frame clock, by default DAI provides the clock

Example: DAI acts as slave mode, CODEC acts as master mode

```

audiopwmout_diff: audiopwmout-diff {
    compatible = "simple-audio-card";
    ....
    simple-audio-card,bitclock-master = <&master>;
    simple-audio-card,frame-master = <&master>;
    simple-audio-card,cpu {
        sound-dai = <&i2s3_2ch>;
    };
    master: simple-audio-card,codec {
        sound-dai = <&dig_acodec>;
    };
};

```

2.6.1.4 Clock phase inversion configuration

Property	Value	Description
simple-audio-card,bitclock-inversion	boolean	Inverted bit clock
simple-audio-card,frame-inversion	boolean	Inverted frame clock

Example: bclk and lrck are both inverted.

```

audiopwmout_diff: audiopwmout-diff {
    compatible = "simple-audio-card";
    ...
    simple-audio-card,bitclock-inversion;
    simple-audio-card,frame-inversion;
    simple-audio-card,cpu {
        sound-dai = <&i2s3_2ch>;
    };
    simple-audio-card,codec {
        sound-dai = <&dig_acodec>;
    };
};

```

2.6.1.5 TDM slots configuration

Property	Value	Description
dai-tdm-slot-num	int	Set the number of slots
dai-tdm-slot-width	int	Set the bit width of the slot

Example: slot bit width is 32 bits, 8 slots

```

i2s-dmic-array {
    compatible = "simple-audio-card";
    ...
    simple-audio-card,mclk-fs = <256>;
    simple-audio-card,cpu {
        sound-dai = <&i2s_8ch_0>;
        dai-tdm-slot-num = <8>;
        dai-tdm-slot-width = <32>;
    };
    simple-audio-card,codec {
        sound-dai = <&dummy_codec>;
    };
};

```

Note: mclk-fs equals to [slot num] * [slot-width], or an even multiple of it.

For more details, please refer to: [kernel/Documentation/devicetree/bindings/sound/simple-card.txt](https://kernel.org/doc/Documentation/devicetree/bindings/sound/simple-card.txt)

2.6.1.6 Example of Adding a Sound Card

1. Port or write a codec driver.

```

sound/soc/codecs/Kconfig
sound/soc/codecs/Makefile
sound/soc/codecs/tas571x.c
sound/soc/codecs/tas571x.h

```

2. Enable CONFIG

```
CONFIG_SND_SIMPLE_CARD
CONFIG_SND_SOC_ROCKCHIP_I2S
CONFIG_SND_SOC_ROCKCHIP_I2S_TDM
CONFIG_SND_SOC_TAS571X
```

3. Add DTS sound card node

- Enable the corresponding i2s node according to the hardware connection

```
&i2s_8ch_1 {
    status = "okay";
    #sound-dai-cells = <0>;
    pinctrl-names = "default";
    pinctrl-0 = <&i2s_8ch_1_m0_sclktx
                &i2s_8ch_1_m0_lrcktx
                &i2s_8ch_1_m0_sdo0
                &i2s_8ch_1_m0_mclk>;
};
```

- Add the codec node under the corresponding I2C or SPI according to the hardware connection.

```
&i2c1 {
    clock-frequency = <400000>;
    status = "okay";

    tas5731: tas5731@1a {
        #sound-dai-cells = <0>;
        compatible = "ti,tas5731";
        reg = <0x1a>;
        clocks = <&cru SCLK_I2S1_8CH_TX_OUT>;
        clock-names = "mclk";
        pinctrl-names = "default";
        pinctrl-0 = <&i2s_8ch_1_m0_mclk>;
        pdn-gpios = <&gpio0 RK_PA5 GPIO_ACTIVE_LOW>;
        reset-gpios = <&gpio1 RK_PA1 GPIO_ACTIVE_LOW>;
    };
};
```

- Add and enable sound card node

```

tas5731_sound: tas5731-sound {
    status = "okay";
    compatible = "simple-audio-card";
    simple-audio-card,format = "i2s";
    simple-audio-card,name = "rockchip,tas5731";
    simple-audio-card,mclk-fs = <256>;
    simple-audio-card,cpu {
        sound-dai = <&i2s_8ch_1>;
    };
    simple-audio-card,codec {
        sound-dai = <&tas5731>;
    };
};

```

- Confirm that the sound card has been created successfully

```

# cat /proc/asound/cards
0 [rockchiptas5731]: rockchip_tas5731 - rockchip,tas5731

```

Note:

The mclk follows the principle of "who uses, who applies". When the codec needs to use an external mclk, the driver needs to apply for and manage the mclk. In this example, the codec mclk comes from the RK3308's SCLK_I2S1_8CH_TX_OUT.

2.6.2 Multi Codecs Machine Driver

When Simple Card does not meet the requirements, it is necessary to write the corresponding Machine Driver. This section introduces RK's Multi Codecs Machine Driver, which is used in scenarios where one DAI corresponds to multiple CODECs or a Combo DAI corresponds to multiple CODECs, as shown in Figure 2-3:




Figure 2-3 Multi Codecs Machine Driver

2.6.2.1 dai / codec configuration

Property	Value	Description
rockchip,cpu	phandle	set the dai device
rockchip,codec	phandle...	Set the associated codecs

Example: i2s0_8ch applied to both codec and vad

```
&sound {
    compatible = "rockchip,multicodecs-card";
    rockchip,cpu = <&i2s0_8ch>;
    rockchip,codec = <&codec>, <&vad>;
};
```

2.6.2.2 Protocol Format configuration

Property	Value	Description
rockchip,format	string	set protocol format

Format	Description
i2s	i2s standard format
right_j	i2s right-justifiedformat
left_j	i2s left-justified format
dsp_a	pcm delay 1 bit
dsp_b	pcm no delay
pdm	pdm

Example: Set to i2s left-justified format

```
&sound {
    rockchip,format = "left_j";
};
```

2.6.2.3 mclk-fs configuration

Property	Value	Description
rockchip,mclk-fs	int	By default, mclk is 256 times the sample rate

Example: mclk is 512 times the sample rate

```
&sound {
    rockchip,mclk-fs = <512>;
};
```

2.6.2.4 Master / Slave configuration

Property	Value	Description
rockchip,frame-master	phandle	Set the device that provides the bit clock, by default DAI provides the clock
rockchip,bitclock-master	phandle	Set the device that provides the frame clock, by default DAI provides the clock

Example: DAI acts as slave mode, CODEC acts as master mode

```
&sound {
    compatible = "rockchip,multicodecs-card";
    rockchip,frame-master = <&codec>;
    rockchip,bitclock-master = <&codec>;
    rockchip,cpu = <&i2s0_8ch>;
    rockchip,codec = <&codec>, <&vad>;
};
```

2.6.2.5 Clock phase inversion configuration

Property	Value	Description
rockchip,bitclock-inversion	boolean	Inverted bit clock
rockchip,frame-inversion	boolean	Inverted frame clock

Example: bclk and lrck are both inverted

```
&sound {
    compatible = "rockchip,multicodecs-card";
    rockchip,bitclock-inversion;
    rockchip,frame-inversion;
    rockchip,cpu = <&i2s0_8ch>;
    rockchip,codec = <&codec>, <&vad>;
};
```

2.6.2.6 wait-card-locked configuration

Property	Value	Description
rockchip,wait-card-locked	int	Wait for a specific soundcard ID to register before registering, ensuring the current soundcard's ID is after the specified ID

Example: Hope the current bluetooth-sound registers as card1, need card0 to register before the current card registers.

```
bluetooth_sound: bluetooth-sound {
    status = "disabled";
    compatible = "rockchip,multicodecs-card";
    rockchip,card-name = "rockchip,rk3308-pcm";
    rockchip,mclk-fs = <128>;
    rockchip,cpu = <0>;
    rockchip,codec = <0>;
    rockchip,format = "dsp_b";
    rockchip,bitclock-inversion = <0>;
    rockchip,wait-card-locked = <0>;
};
```

2.6.2.7 Others

Property	Value	Description
hp-det-gpio	phandle	Headphone detection pin
spk-con-gpio	phandle	Amplifier speaker control pin
hp-con-gpio	phandle	Headphone control pin
io-channels	phandle	adc detection channel for distinguish 3/4-pole headphones
poll-interval	int	adc polling time interval. Default 100 ms
keyup-threshold-microvolt	int	adc button voltage
play-pause-key	phandle	Play pause key
rockchip,audio-routing	string	Sound card routing

Example:

ADC3 used to distinguish 3/4-pole headphones, and also for play/pause buttons on the headphone cable.

Headphone corresponds to es8388's LROUT1, controlled by Headphone Power gpio1_d2.

Speaker corresponds to es8388's LROUT2, controlled by Speaker Power gpio1_d3.

LINPUT corresponds to es8388's Main Mic, RINPUT corresponds to Headset Mic.

```

es8388_sound: es8388-sound {
    status = "okay";
    compatible = "rockchip,multicodecs-card";
    rockchip,card-name = "rockchip-es8388";
    hp-det-gpio = <&gpio1 RK_PD5 GPIO_ACTIVE_LOW>;
    io-channels = <&saradc 3>;
    io-channel-names = "adc-detect";
    keyup-threshold-microvolt = <1800000>;
    poll-interval = <100>;
    spk-con-gpio = <&gpio1 RK_PD3 GPIO_ACTIVE_HIGH>;
    hp-con-gpio = <&gpio1 RK_PD2 GPIO_ACTIVE_HIGH>;
    rockchip,format = "i2s";
    rockchip,mclk-fs = <256>;
    rockchip,cpu = <&i2s0_8ch>;
    rockchip,codec = <&es8388>;
    rockchip,audio-routing =
        "Headphone", "LOUT1",
        "Headphone", "ROUT1",
        "Speaker", "LOUT2",
        "Speaker", "ROUT2",
        "Headphone", "Headphone Power",
        "Headphone", "Headphone Power",
        "Speaker", "Speaker Power",
        "Speaker", "Speaker Power",
        "LINPUT1", "Main Mic",
        "LINPUT2", "Main Mic",
        "RINPUT1", "Headset Mic",
        "RINPUT2", "Headset Mic";
    pinctrl-names = "default";
    pinctrl-0 = <&hp_det>;
    play-pause-key {
        label = "playpause";
        linux,code = <KEY_PLAYPAUSE>;
        press-threshold-microvolt = <2000>;
    };
};

```

For more details, please ref to: [kernel/Documentation/devicetree/bindings/sound/rockchip,multicodecs.txt](https://kernel.org/doc/Documentation/devicetree/bindings/sound/rockchip,multicodecs.txt)

2.6.3 HDMI Audio

The RK 4.4 kernel HDMI contains two frameworks: the RK HDMI framework and the DRM framework. Therefore, there are also two corresponding audio implementations.

Starting from the RK 4.19 kernel version, only the standard DRM framework is used.

Example 1: Audio Configuration for RK HDMI Framework on RK3399

```

dw_hdmi_audio: dw-hdmi-audio {
    compatible = "rockchip,dw-hdmi-audio";
    #sound-dai-cells = <0>;
};

```

```

hdmi_sound: hdmi-sound {
    compatible = "simple-audio-card";
    simple-audio-card,format = "i2s";
    simple-audio-card,mclk-fs = <128>;
    simple-audio-card,name = "rockchip,hdmi";
    simple-audio-card,cpu {
        sound-dai = <&i2s2>;
    };
    simple-audio-card,codec {
        sound-dai = <&dw_hdmi_audio>;
    };
};

```

Example 2 : Audio Configuration for DRM HDMI framework on RK3399

```

hdmi: hdmi@ff940000 {
    compatible = "rockchip,rk3399-dw-hdmi";
    .....
    #address-cells = <1>;
    #size-cells = <0>;
    #sound-dai-cells = <0>;
};

hdmi_sound: hdmi-sound {
    compatible = "simple-audio-card";
    simple-audio-card,format = "i2s";
    simple-audio-card,mclk-fs = <128>;
    simple-audio-card,name = "rockchip,hdmi";
    simple-audio-card,cpu {
        sound-dai = <&i2s2>;
    };
    simple-audio-card,codec {
        sound-dai = <&hdmi>;
    };
};

```

2.7 Audio Clock Compensation

The RK platform provides audio clock fine-tuning to solve audio asynchronization issues in heterogeneous systems, such as UAC, HDMI IN, BT voice, etc. The adjustment range is ± 1000 ppm (parts per million).

1. Enable CONFIG

```
CONFIG_ROCKCHIP_CLK_COMPENSATION
```

2. Adding PLL fractional mode frequency (clock fine-tuning compensation function is only valid in PLL fractional mode), following the principle of "PLL is an even multiple of mclk". The chip scheme is described in two categories:

- Chips with independent audio PLL only need to follow the even multiple principle. For example, RK3308 VPLL0 is set to 1179648000 Hz, and VPLL1 is set to 903168000 Hz.
- When the audio and other modules share the PLL, the product needs to evaluate the impact of clock fine-tuning on the shared module, described as follows:
 - a. Whether the ± 1000 ppm adjustment has an impact on the module function, for example: Ethernet requires accurate clock, while the video encoding controller does not have an accurate requirement.
 - b. If condition a is met, adjust the PLL frequency to the appropriate fractional frequency. For example, on RV1126, both the video encoding controller that works around 500 MHz and the audio playback support for 48k sampling rate compatibility are required. You can choose a fractional PLL frequency close to 500 MHz, such as 491520000 MHz.

Example: Modify the CPLL frequency of RV1126 to a fractional frequency.

```
diff --git a/drivers/clk/rockchip/clk-rv1126.c b/drivers/clk/rockchip/clk-rv1126.c
index 9ba0bff..1b95aed 100644
--- a/drivers/clk/rockchip/clk-rv1126.c
+++ b/drivers/clk/rockchip/clk-rv1126.c
@@ -74,6 +74,8 @@ static struct rockchip_pll_rate_table rv1126_pll_rates[] = {
    RK3036_PLL_RATE(594000000, 1, 99, 4, 1, 1, 0),
    RK3036_PLL_RATE(504000000, 1, 84, 4, 1, 1, 0),
    RK3036_PLL_RATE(500000000, 1, 125, 6, 1, 1, 0),
+   RK3036_PLL_RATE(496742400, 1, 124, 6, 1, 0, 3113851),
+   RK3036_PLL_RATE(491520000, 1, 40, 2, 1, 0, 16106127),
```

DTS configuration: only configure 491520000 Hz, support 8k, 16k, 24k, 48k, 96k, 192k sample rate

```
&cru {
    assigned-clocks =
        <&pmucru CLK_RTC32K>, <&pmucru PLL_GPLL>,
        <&pmucru PCLK_PDPMU>, <&cru PLL_CPLL>,
        <&cru PLL_HPPLL>, <&cru ARMCLK>,
        <&cru ACLK_PDBUS>, <&cru HCLK_PDBUS>,
        <&cru PCLK_PDBUS>, <&cru ACLK_PDPHP>,
        <&cru HCLK_PDPHP>, <&cru HCLK_PDAUDIO>,
        <&cru HCLK_PDCORE_NIU>;
    assigned-clock-rates =
        <32768>, <1188000000>,
        <100000000>, <491520000>,
        <1400000000>, <600000000>,
        <500000000>, <200000000>,
        <100000000>, <300000000>,
        <200000000>, <150000000>,
        <200000000>;
};
```

3. Enable DAI clock compensation function, configure `root_pll`

I2S controller

```
&i2s1_2ch {
    clocks = <&cru MCLK_I2S1>, <&cru HCLK_I2S1>, <&cru PLL_CPLL>;
    clock-names = "i2s_clk", "i2s_hclk", "i2s_clk_root";
    rockchip,mclk-calibrate;
};
```

I2S-TDM controller

```
&i2s0_8ch {
    clocks = <&cru MCLK_I2S0_TX>, <&cru MCLK_I2S0_RX>, <&cru HCLK_I2S0>,
            <&cru MCLK_I2S0_TX_DIV>, <&cru MCLK_I2S0_RX_DIV>,
            <&cru PLL_CPLL>, <&cru PLL_CPLL>;
    clock-names = "mclk_tx", "mclk_rx", "hclk",
            "mclk_tx_src", "mclk_rx_src",
            "mclk_root0", "mclk_root1";
    rockchip,mclk-calibrate;
};
```

PDM controller

```
&pdm {
    status = "okay";
    clocks = <&cru MCLK_PDM>, <&cru HCLK_PDM>, <&cru PLL_CPLL>;
    clock-names = "pdm_clk", "pdm_hclk", "pdm_clk_root";
    rockchip,mclk-calibrate;
};
```

4. Function verification

After the function is enabled, the clock can be fine-tuned by [amixer](#).

Example: Fine-tuning audio frequency of rk809 sound card on RV1126

```
# cat /proc/asound/cards
0 [rockchiprk809co]: rockchip_rk809- - rockchip,rk809-codec
                      rockchip,rk809-codec

# aplay -D hw:0,0 --period-size=1024 --buffer-size=4096 -f dat /dev/zero &
Playing raw data '/dev/zero' : Signed 16 bit Little Endian, Rate 48000 Hz, Stereo

# cat /sys/kernel/debug/clk/clk_summary | egrep "i2s0|cpll"
pll_cpll          1          1          0  491519999
cpll              6         11          0  491519999
  mclk_i2s0_rx_div  1          1          0  12288000
    mclk_i2s0_rx_mux 1          1          0  12288000
      mclk_i2s0_rx    1          1          0  12288000
        mclk_i2s0_rx_fracdiv 0          0          0  12288000
  mclk_i2s0_tx_div  1          1          0  12288000
    mclk_i2s0_tx_mux 1          1          0  12288000
      mclk_i2s0_tx    2          2          0  12288000
        mclk_i2s0_tx_out2io 2          2          0  12288000
```

```

mclk_i2s0_tx_fracdiv      0      0      0  12288000

# amixer contents
...
numid=3,iface=PCM,name='PCM Clk Compensation In PPM'
; type=INTEGER,access=rw-----,values=1,min=-1000,max=1000,step=1
: values=0

# amixer -- cset numid=3 10
numid=3,iface=PCM,name='PCM Clk Compensation In PPM'
; type=INTEGER,access=rw-----,values=1,min=-1000,max=1000,step=1
: values=10

# cat /sys/kernel/debug/clk/clk_summary | egrep "i2s0|cp11"
pll_cp11                  1      1      0  491524892
cp11                      6     11      0  491524892
  mclk_i2s0_rx_div        1      1      0  12288123
  mclk_i2s0_rx_mux        1      1      0  12288123
  mclk_i2s0_rx            1      1      0  12288123
  mclk_i2s0_rx_fracdiv    0      0      0  12288123
  mclk_i2s0_tx_div        1      1      0  12288123
  mclk_i2s0_tx_mux        1      1      0  12288123
  mclk_i2s0_tx            2      2      0  12288123
  mclk_i2s0_tx_out2io     2      2      0  12288123
  mclk_i2s0_tx_fracdiv    0      0      0  12288123

# amixer -- cset numid=3 -10
numid=3,iface=PCM,name='PCM Clk Compensation In PPM'
; type=INTEGER,access=rw-----,values=1,min=-1000,max=1000,step=1
: values=-10

pll_cp11                  1      1      0  491515106
cp11                      6     11      0  491515106
  mclk_i2s0_rx_div        1      1      0  12287878
  mclk_i2s0_rx_mux        1      1      0  12287878
  mclk_i2s0_rx            1      1      0  12287878
  mclk_i2s0_rx_fracdiv    0      0      0  12287878
  mclk_i2s0_tx_div        1      1      0  12287878
  mclk_i2s0_tx_mux        1      1      0  12287878
  mclk_i2s0_tx            2      2      0  12287878
  mclk_i2s0_tx_out2io     2      2      0  12287878
  mclk_i2s0_tx_fracdiv    0      0      0  12287878

```

2.8 DLP

Supports audio digital loopback in single-dai and multi-dai scenarios. Supports I2S/I2STDM/SAI controllers.

2.8.1 Loopback Mode

Currently supports the following loopback modes, which can be extended.

Mode List:

```
# amixer contents
numid=2,iface=MIXER,name='Software Digital Loopback Mode'
; type=ENUMERATED,access=rw-----,values=1,items=7
; Item #0 'Disabled'
; Item #1 '2CH: 1 Loopback + 1 Mic'
; Item #2 '2CH: 1 Mic + 1 Loopback'
; Item #3 '2CH: 1 Mic + 1 Loopback-mixed'
; Item #4 '2CH: 2 Loopbacks'
; Item #5 '4CH: 2 Mics + 2 Loopbacks'
; Item #6 '4CH: 2 Mics + 1 Loopback-mixed'
; Item #7 "4CH: 4 Loopbacks",
; Item #8 "6CH: 4 Mics + 2 Loopbacks",
; Item #9 "6CH: 4 Mics + 1 Loopback-mixed",
; Item #10 "6CH: 6 Loopbacks",
; Item #11 "8CH: 6 Mics + 2 Loopbacks",
; Item #12 "8CH: 6 Mics + 1 Loopback-mixed",
; Item #13 "8CH: 8 Loopbacks",
; Item #14 "10CH: 8 Mics + 2 Loopbacks",
; Item #15 "10CH: 8 Mics + 1 Loopback-mixed",
; Item #16 "16CH: 8 Mics + 8 Loopbacks",
: values=0
```

Example: i2s enable digital loopback

Enable:

```
CONFIG_SND_SOC_ROCKCHIP_DLP
```

```
&i2s {
    rockchip,digital-loopback;
};
```

2.9 Dynamic DMA Channel

The RK platform supports PL330 and RKDMA controllers. PL330 can only work with 8 channels at the same time, while RKDMA has not these restrictions.

The kernel ASoC uses statically applied DMA channels. If PL330 is used, it will not be able to be time-shared for more peripherals. Based on this background, audio dynamic request and release of DMA channels are provided.

```
CONFIG_SND_SOC_DYNAMIC_DMA_CHAN
```


2.10 PATTERN DEBUG

Supports playing PATTERN data for easy analysis of timing issues. After enabled, the playback data will be replaced with a fixed sequence, including MSB bit check, channel id, etc.

```
commit 0083e5a0ce9fe6654e586c9021b7b3cf90b5bf3c
Author: Sugar Zhang <sugar.zhang@rock-chips.com>
Date: Tue Aug 13 22:09:29 2024 +0800

ALSA: pcm: Add support for pcm pattern playback

CONFIG_SND_PCM_PATTERN_DEBUG

* MSB check
* channel id
* as much as more 0/1 stress

PATTERN8(x)      (0xa0 | (x))
PATTERN16(x)     (0xab00 | (x))
PATTERN32(x)     (0xabcabc00 | (x))

e.g. 16bit 4ch pattern:

0xab01 0xab02 0xab03 0xab04 0xab01 ...

This pattern is only used for IOCTL_READ/WRITE, not
suitable for MMIO.
```

3. Debugging

Introduction and Application of Common Debugging Tools.

3.1 Hardware Instruments

3.1.1 Multimeter

Measure the hardware power supply and confirm that the operating voltage is normal based on the chip manual. On the SoC side, confirm that the voltage of the IO domain is consistent with the software configuration, and on the CODEC side, confirm that the power supply of each path meets the manual requirements.

Example: RV1126 EVB, RK817 connected to I2S0, CODEC operates at 1.8V; the multimeter measures the hardware voltage to be 1.8V, as shown in Figure 3-2.

U1000J
RV1126/1109
BGA409 58R00X58R00X42R69 S




Figure 3-1 I2S IO power supply

The configuration of the corresponding power domain in the DTS is set to 1.8v, as shown below:

```
&pmu_io_domains {
    status = "okay";
    ...
    vccio7-supply = <&vcc_1v8>;
};
```

Warning: If the hardware power supply and software configuration are inconsistent, it may cause functional abnormalities, chip damage, and other risks.

3.1.2 Oscilloscope

Using an oscilloscope to measure hardware signals such as clock and data is important for debugging. It is necessary to measure the clock frequency, amplitude, duty cycle, jitter, etc. to confirm whether they comply with protocol specifications. For example, if the working voltage is 3.3V but the actual clock signal is only 2V, it may be caused by an external device pulling down the signal, a short circuit to ground, or incorrect software voltage configuration. It is also important to capture the clock and data signals and analyze them with specific data patterns to confirm if they are correct. A logic analyzer can also be used for this purpose. Trigger mode can be used to capture the problem scene, such as whether there is jitter or glitches in the CLK signal during audio dropouts.

3.1.3 Signal Generator

Signal generators can be used to generate different waveforms such as square waves, triangular waves, and sine waves. In the context of ADC testing, a signal generator can be used to produce a known input signal, such as a sine wave, which can then be fed into the ADC. The output of the ADC can then be compared to the input signal to evaluate the ADC's distortion level and accuracy.

3.1.4 AP Analyzer

CODEC performance analyzer is used to test and analyze various performance parameters of an analog-to-digital or digital-to-analog converter (ADC/DAC) in a CODEC system. It can be used to test the digital interface signals and measure the analog signal parameters, such as signal-to-noise ratio (SNR), total harmonic distortion (THD), dynamic range, and other performance metrics. With this tool, engineers can identify any issues with CODEC performance and optimize the system accordingly.

3.2 Debug Commands

3.2.1 procfs

Confirm that the sound card has been successfully registered, you can check the /proc filesystem.

You can navigate to the /proc/asound directory and check the contents of the cards file. The cards file contains a list of all the registered sound cards on the system.

You can use the following command to view the contents of the cards file:

```
# cat /proc/asound/cards
0 [rockchiprk809co]: rockchip_rk809- - rockchip,rk809-codec
                        rockchip,rk809-codec
7 [Loopback          ]: Loopback - Loopback
                        Loopback 1

# ls /dev/snd/
by-path    controlC7  pcmC0D0p  pcmC7D0p  pcmC7D1p
controlC0  pcmC0D0c  pcmC7D0c  pcmC7D1c  timer
```

If the sound card has been successfully registered, you should see its name and number listed in the output.

3.2.2 clk summary

Query the audio clock to make sure it is set correctly

Example: Query the frequency of the i2s0 mclk and its corresponding PLL, result: the mclk is 12288000 Hz, and the source is cpll

```
# cat /sys/kernel/debug/clk/clk_summary | egrep "i2s0|pll"
pll_cppll          1          1          0  500000000
cppll              5          10          0  500000000
  mclk_i2s0_rx_div    0          0          0  500000000
    mclk_i2s0_rx_fracdiv 0          0          0  12288000
      mclk_i2s0_rx_mux 0          0          0  12288000
        mclk_i2s0_rx    0          0          0  12288000
mclk_i2s0_tx_div    1          1          0  500000000
  mclk_i2s0_tx_fracdiv 1          1          0  12288000
    mclk_i2s0_tx_mux  1          1          0  12288000
      mclk_i2s0_tx    1          1          0  12288000
        mclk_i2s0_tx_out2io 2        2          0  12288000
```

3.2.3 Register

3.2.3.1 io command

You can use the "io" command to view or modify registers (suitable for SOC register query) and confirm the configuration and working status with the chip manual.

```
# cat /proc/iomem | grep i2s
ff800000-ff800fff : i2s@ff800000
#
# io -4 -l 0x40 0xff800000
ff800000: 7200000f 004e000f 10003f3f 00000010
ff800010: 000f0110 01f00000 00000000 00000003
ff800020: 00000000 00000000 00000000 0000001f
ff800030: 00003eff 00003eff 00000303 20150001
```

3.2.3.2 regmap

View registers through the regmap node (read-only).

```
# ls /sys/kernel/debug/regmap/
0-0020-rk817-codec
ff800000.i2s
...
# cat /sys/kernel/debug/regmap/0-0020-rk817-codec/registers
12: 03
13: f4
14: 00
15: ff
16: 00
17: 40
18: 48
19: 00
1a: 00
1b: ff
```

```
1c: 00
1d: 00
1e: 02
1f: 00
...
```

Note: The regmap is based on a cache mechanism. If the register is directly modified through the io command, the regmap node will not reflect the updated register unless the driver sets the register type to volatile or disables the regmap cache.

Example: Disable regmap cache and obtain the correct register value.

```
# cd /sys/kernel/debug/regmap/ff800000.i2s/
# cat registers /* dump register by regmap */
00: 7200000f
04: 004e000f
08: 10003f3f
0c: XXXXXXXX
10: 000f0010
14: 01f00000
18: XXXXXXXX
1c: 00000000
20: XXXXXXXX
24: XXXXXXXX
2c: XXXXXXXX
30: 00003eff
34: 00003eff
38: 00000303

# io -4 0xff800000 0x0 /* set 0xff800000 to 0 */
# io -4 -l 0x40 0xff800000 /* dump to check value of 0xff800000, now it's 0 */
ff800000: 00000000 004e000f 10003f3f 00000000
ff800010: 000f0010 01f00000 00000000 00000000
ff800020: 00000000 00000000 00000000 00000000
ff800030: 00003eff 00003eff 00000303 20150001

# cat registers /* dump register by regmap */
00: 7200000f /* it's still old value */
04: 004e000f
08: 10003f3f
0c: XXXXXXXX
10: 000f0010
14: 01f00000
18: XXXXXXXX
1c: 00000000
20: XXXXXXXX
24: XXXXXXXX
2c: XXXXXXXX
30: 00003eff
34: 00003eff
38: 00000303

# echo N > cache_only
```

```
[148833.374641] rockchip-i2s-tdm ff800000.i2s: debugfs cache_only=N forced: syncing cache
# echo Y > cache_bypass
[148834.760274] rockchip-i2s-tdm ff800000.i2s: debugfs cache_bypass=Y forced

# cat registers /* dump again, now it's correct */
00: 00000000
04: 004e000f
08: 10003f3f
0c: 00000000
10: 000f0010
14: 01f00000
18: 00000000
1c: 00000000
20: 00000000
24: 00000000
2c: 00000000
30: 00003eff
34: 00003eff
38: 00000303
```

3.2.3.3 i2c-tools

View or modify the codec register (suitable for i2c type codec devices) through the i2c tool, and confirm the configuration and working status with the codec manual.

3.2.3.3.1 i2cdetect

Detect devices on the i2c bus

```
Usage: i2cdetect [-y] [-a] [-q|-r] I2CBUS [FIRST LAST]
        i2cdetect -F I2CBUS
        i2cdetect -l
        I2CBUS is an integer or an I2C bus name
        If provided, FIRST and LAST limit the probing range.
```

Example: Querying devices on the i2c0 bus

[illegible]

3.2.3.3.2 i2cdump

dump all registers of the device

```
Usage: i2cdump [-f] [-y] [-r first-last] I2CBUS ADDRESS [MODE [BANK [BANKREG]]]
I2CBUS is an integer or an I2C bus name
ADDRESS is an integer (0x03 - 0x77)
MODE is one of:
    b (byte, default)
    w (word)
    W (word on even register addresses)
    s (SMBus block)
    i (I2C block)
    c (consecutive byte)
Append p for SMBus PEC
```

Example: Query the registers of rk817 (device address: 0x20) under the i2c0 bus, where 0x12 ~ 0x4f are codec registers.

```
# i2cdump -f -y 0 0x20 b
    0  1  2  3  4  5  6  7  8  9  a  b  c  d  e  f
00: 03 35 18 10 08 17 04 00 00 00 01 01 00 80 02 00
10: 00 00 03 f4 00 ff 00 40 48 00 00 ff 00 00 02 00
20: 00 00 00 00 ff 00 00 1f 00 99 00 00 00 00 00 03
30: 04 03 03 00 a5 02 00 00 11 03 03 00 00 e0 0f 09
40: a5 7f 04 58 2d 0c a5 00 00 00 00 0f 20 00 0f 88
50: 8c 00 01 00 01 b0 44 1e 00 60 16 6a 16 6a ff f8
60: ff f8 00 00 00 00 00 00 00 00 00 16 66 01 d7 00
70: 00 00 00 00 ff ed d6 58 16 6a ff f9 00 00 00 00
80: 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00
90: 60 81 d5 7f fb df ca 81 d2 ff 00 00 00 00 00 00
a0: 00 00 00 00 b8 00 00 00 00 00 00 00 00 00 00 00
b0: 00 0f 0f 0f 0f ad 0e ff ff 00 64 18 18 64 12 18
c0: 64 00 00 64 62 62 64 ff ff ff ff ff 08 08 30 30
d0: 08 08 30 30 30 30 18 14 58 58 6c 6c 6c 6c 0b 33
e0: 00 00 00 55 a2 c8 c5 40 00 ff 22 03 0a 80 94 0b
f0: c0 8c a0 40 18 10 00 86 00 dc 00 ff 00 ff 60 00
```

3.2.3.3.3 i2cset

Modify a single register value

```
Usage: i2cset [-f] [-y] [-m MASK] [-r] I2CBUS CHIP-ADDRESS DATA-ADDRESS [VALUE] ... [MODE]
I2CBUS is an integer or an I2C bus name
ADDRESS is an integer (0x03 - 0x77)
MODE is one of:
    c (byte, no value)
    b (byte data, default)
    w (word data)
    i (I2C block data)
    s (SMBus block data)
Append p for SMBus PEC
```

Example: Set the value of register-0x12 to 0

```
# i2cset -f -y -r 0 0x20 0x12 0x0 b
Value 0x00 written, readback matched
```

3.2.3.3.4 i2cget

Query a single register value

```
Usage: i2cget [-f] [-y] I2CBUS CHIP-ADDRESS [DATA-ADDRESS [MODE]]
I2CBUS is an integer or an I2C bus name
ADDRESS is an integer (0x03 - 0x77)
MODE is one of:
  b (read byte data, default)
  w (read word data)
  c (write byte/read byte)
Append p for SMBus PEC
```

Example: Get the value of register-0x12

```
# i2cget -f -y 0 0x20 0x12 b
0x00
```

For more details, please refer to: [i2c-tools](#)

3.2.4 alsa-utils

RK Linux SDK comes with alsa-utils tools by default.

3.2.4.1 aplay

```
Usage: aplay [OPTION]... [FILE]...

-h, --help                help
--version                 print current version
-l, --list-devices         list all soundcards and digital audio devices
-L, --list-pcms            list device names
-D, --device=NAME          select PCM by name
-q, --quiet                quiet mode
-t, --file-type TYPE       file type (voc, wav, raw or au)
-c, --channels=#           channels
-f, --format=FORMAT        sample format (case insensitive)
-r, --rate=#               sample rate
-d, --duration=#           interrupt after # seconds
-s, --samples=#            interrupt after # samples per channel
-M, --mmap                 mmap stream
-N, --nonblock              nonblocking mode
-F, --period-time=#        distance between interrupts is # microseconds
```



```

-B, --buffer-time=#      buffer duration is # microseconds
  --period-size=#        distance between interrupts is # frames
  --buffer-size=#        buffer duration is # frames
-A, --avail-min=#        min available space for wakeup is # microseconds
-R, --start-delay=#      delay for automatic PCM start is # microseconds
                          (relative to buffer size if <= 0)
-T, --stop-delay=#       delay for automatic PCM stop is # microseconds from xrun
-v, --verbose            show PCM structure and setup (accumulative)
-V, --vumeter=TYPE       enable VU meter (TYPE: mono or stereo)
-I, --separate-channels  one file for each channel
-i, --interactive        allow interactive operation from stdin
-m, --chmap=ch1,ch2,..   Give the channel map to override or follow
  --disable-resample     disable automatic rate resample
  --disable-channels     disable automatic channel conversions
  --disable-format       disable automatic format conversions
  --disable-softvol      disable software volume control (softvol)
  --test-position        test ring buffer position
  --test-coef=#          test coefficient for ring buffer position (default 8)
                          expression for validation is: coef * (buffer_size / 2)
  --test-nowait          do not wait for ring buffer - eats whole CPU
  --max-file-time=#      start another output file when the old file has recorded
                          for this many seconds
  --process-id-file      write the process ID here
  --use-strftime          apply the strftime facility to the output file name
  --dump-hw-params       dump hw_params of the device
  --fatal-errors         treat all errors as fatal

```

Example: Play mute data with 48kHz sample rate, 2 channels, and 16 bits through sound card 0

```
# aplay -D hw:0,0 --period-size=1024 --buffer-size=4096 -r 48000 -c 2 -f s16_le /dev/zero
```

3.2.4.2 arecord

Usage: arecord [OPTION]... [FILE]...

```

-h, --help                help
  --version               print current version
-l, --list-devices        list all soundcards and digital audio devices
-L, --list-pcms           list device names
-D, --device=NAME         select PCM by name
-q, --quiet               quiet mode
-t, --file-type TYPE      file type (voc, wav, raw or au)
-c, --channels=#          channels
-f, --format=FORMAT       sample format (case insensitive)
-r, --rate=#              sample rate
-d, --duration=#          interrupt after # seconds
-s, --samples=#           interrupt after # samples per channel
-M, --mmap                mmap stream
-N, --nonblock            nonblocking mode
-F, --period-time=#       distance between interrupts is # microseconds
-B, --buffer-time=#       buffer duration is # microseconds

```

```

--period-size=#    distance between interrupts is # frames
--buffer-size=#    buffer duration is # frames
-A, --avail-min=#  min available space for wakeup is # microseconds
-R, --start-delay=# delay for automatic PCM start is # microseconds
                    (relative to buffer size if <= 0)
-T, --stop-delay=# delay for automatic PCM stop is # microseconds from xrun
-v, --verbose      show PCM structure and setup (accumulative)
-V, --vumeter=TYPE enable VU meter (TYPE: mono or stereo)
-I, --separate-channels one file for each channel
-i, --interactive  allow interactive operation from stdin
-m, --chmap=ch1,ch2,.. Give the channel map to override or follow
--disable-resample  disable automatic rate resample
--disable-channels  disable automatic channel conversions
--disable-format    disable automatic format conversions
--disable-softvol   disable software volume control (softvol)
--test-position     test ring buffer position
--test-coef=#       test coefficient for ring buffer position (default 8)
                    expression for validation is: coef * (buffer_size / 2)
--test-nowait       do not wait for ring buffer - eats whole CPU
--max-file-time=#   start another output file when the old file has recorded
                    for this many seconds
--process-id-file   write the process ID here
--use-strftime      apply the strftime facility to the output file name
--dump-hw-params    dump hw_params of the device
--fatal-errors      treat all errors as fatal

```

Example: Record audio with 16kHz sample rate, 8 channels and 32 bits through sound card 0

```
# arecord -D hw:0,0 --period-size=1024 --buffer-size=4096 -r 16000 -c 8 -f s32_le r.wav
```

3.2.4.3 arecord | aplay

The two can be connected through a pipeline to achieve a loopback function, which is convenient for driver debugging and metric testing.

Example: sound card 0 capture -> sound card 1 playback

```
# arecord -D hw:0,0 --period-size=1024 --buffer-size=4096 -r 48000 -c 2 -f s16_le -t raw |
aplay -D hw:1,0 --period-size=1024 --buffer-size=4096 -r 48000 -c 2 -f s16_le -t raw
```

3.2.4.4 amixer

Control the internal path switches of the codec, and implement audio stream routing, volume control, etc. by referring to the audio topology diagram in the codec manual (such as Figure 3-2 RK3308 codec)




Figure 3-2 RK3308 codec

Usage: amixer <options> [command]

Available options:

- h,--help this help
- c,--card N select the card
- D,--device N select the device, default 'default'
- d,--debug debug mode
- n,--nocheck do not perform range checking
- v,--version print version of this program
- q,--quiet be quiet
- i,--inactive show also inactive controls
- a,--abstract L select abstraction level (none or basic)
- s,--stdin Read and execute commands from stdin sequentially
- R,--raw-volume Use the raw value (default)
- M,--mapped-volume Use the mapped volume

Available commands:

- scontrols show all mixer simple controls
- scontents show contents of all mixer simple controls (default command)

```

sset sID P      set contents for one mixer simple control
sget sID        get contents for one mixer simple control
controls       show all controls for given card
contents       show contents of all controls for given card
cset cID P      set control contents for one control
cget cID        get control contents for one control

```

Example: Query the controls of the sound card and switch the playback path to SPK.

```

# amixer -c 0 contents
numid=1,iface=MIXER,name='Playback Path'
; type=ENUMERATED,access=rw-----,values=1,items=11
; Item #0 'OFF'
; Item #1 'RCV'
; Item #2 'SPK'
; Item #3 'HP'
; Item #4 'HP_NO_MIC'
; Item #5 'BT'
; Item #6 'SPK_HP'
; Item #7 'RING_SPK'
; Item #8 'RING_HP'
; Item #9 'RING_HP_NO_MIC'
; Item #10 'RING_SPK_HP'
: values=0
...
# amixer -c 0 cset numid=1 2
numid=1,iface=MIXER,name='Playback Path'
; type=ENUMERATED,access=rw-----,values=1,items=11
; Item #0 'OFF'
; Item #1 'RCV'
; Item #2 'SPK'
; Item #3 'HP'
; Item #4 'HP_NO_MIC'
; Item #5 'BT'
; Item #6 'SPK_HP'
; Item #7 'RING_SPK'
; Item #8 'RING_HP'
; Item #9 'RING_HP_NO_MIC'
; Item #10 'RING_SPK_HP'
: values=2

```

3.2.4.5 alsaloop

- Support routing between any sound card
- Support adaptive clock synchronization
- Support self-adaptive resampling
- Support mixer controls redirection

Usage: alsaloop [OPTION]...

```

-h,--help      help
-g,--config    configuration file (one line = one job specified)
-d,--daemonize daemonize the main process and use syslog for errors
-P,--pdevice   playback device
-C,--cdevice   capture device
-X,--pctl      playback ctl device
-Y,--cctl      capture ctl device
-l,--latency   requested latency in frames
-t,--tlatency  requested latency in usec (1/1000000sec)
-f,--format    sample format
-c,--channels  channels
-r,--rate      rate
-n,--resample  resample in alsa-lib
-A,--samplerate use converter (0=sincbest,1=sincmedium,2=sincfastest,
                           3=zerohold,4=linear)
-B,--buffer    buffer size in frames
-E,--period    period size in frames
-s,--seconds   duration of loop in seconds
-b,--nblock    non-block mode (very early process wakeup)
-S,--sync      sync mode(0=none,1=simple,2=captshift,3=playshift,4=samplerate,
               5=auto)
-a,--slave     stream parameters slave mode (0=auto, 1=on, 2=off)
-T,--thread    thread number (-1 = create unique)
-m,--mixer     redirect mixer, argument is:
               SRC_SLAVE_ID(PLAYBACK)[@DST_SLAVE_ID(CAPTURE)]
-O,--ossmixer  rescan and redirect oss mixer, argument is:
               ALSA_ID@OSS_ID (for example: "Master@VOLUME")
-e,--effect    apply an effect (bandpass filter sweep)
-v,--verbose   verbose mode (more -v means more verbose)
-w,--workaround use workaround (serialopen)
-U,--xrun      xrun profiling
-W,--wake      process wake timeout in ms
-z,--syslog    use syslog for errors

```

Recognized sample formats are: S8 U8 S16_LE S16_BE U16_LE U16_BE S24_LE S24_BE U24_LE U24_BE S32_LE S32_BE U32_LE U32_BE FLOAT_LE FLOAT_BE FLOAT64_LE FLOAT64_BE IEC958_SUBFRAME_LE IEC958_SUBFRAME_BE MU_LAW A_LAW IMA_ADPCM MPEG GSM SPECIAL S24_3LE S24_3BE U24_3LE U24_3BE S20_3LE S20_3BE U20_3LE U20_3BE S18_3LE S18_3BE U18_3LE U18_3BE G723_24 G723_24_1B G723_40 G723_40_1B DSD_U8 DSD_U16_LE DSD_U32_LE DSD_U16_BE

Tip #1 (usable 500ms latency, good CPU usage, superb xrun prevention):

```
alsaloop -t 500000
```

Tip #2 (superb 1ms latency, but heavy CPU usage):

```
alsaloop -t 1000
```

Sync mode specification for capture to playback stream:

- 0 or none - do not touch the stream
- 1 or simple - add or remove samples to keep both streams synchronized
- 2 or captshift - use driver for the capture device (if supported) to compensate the rate shift

```
3 or playshift - use driver for the playback device
                  (if supported) to compensate
                  the rate shift
4 or samplerate - use samplerate library to do rate resampling
5 or auto       - automatically selects the best method
                  in this order: captshift, playshift,
                  samplerate, simple
```

Example: The audio recorded by sound card 0 is played through sound card 1, and the synchronization mode use strategy 1 (adding or removing samples)

```
# alsaloop -C hw:0,0 -P hw:1,0 -t 10000 -A 3 -S 1 -b -v
```

Note:

If the clock source of sound card 0 and 1 are the same (e.g., the same OSC), there is no asynchronous cumulative error. If sound card 0 is a UAC (clock source from PC) and sound card 1 is a system sound card (clock source from device), because the clock sources are different, cumulative errors will inevitably occur over time, leading to audio dropout. In this case, software compensation (such as adding or subtracting samples) or hardware compensation (such as [audio clock compensation](#)) is required.

3.2.5 tiny-alsa

RK Android SDK comes with tiny-alsa tools by default.

3.2.5.1 tinypcminfo

Query the sampling rate, format, number of channels, etc. supported by the sound card.

```
Usage: tinypcminfo [-D card] [-d device]
```

Example:

```
# tinypcminfo -D 0
Info for card 0, device 0:

PCM out:
Access: 0x000009
Format0: 0x000044
Format1: 0x000010
Format Name: S16_LE, S24_LE, S32_LE
Subformat: 0x000001
Rate: min=16000Hz max=48000Hz
Channels: min=2 max=2
Sample bits: min=16 max=32
Period size: min=4 max=65536
Period count: min=2 max=4096
```

```
PCM in:
Access: 0x000009
Format0: 0x000044
Format1: 0x000010
Format Name: S16_LE, S24_LE, S32_LE
Subformat: 0x000001
Rate: min=16000Hz max=48000Hz
Channels: min=2 max=2
Sample bits: min=16 max=32
Period size: min=4 max=65536
Period count: min=2 max=4096
```

3.2.5.2 tinypplay

```
Usage: tinypplay file.wav [-D card] [-d device] [-p period_size] [-n n_periods]
```

Example: play 1k0 audio file

```
# tinypplay /sdcard/1k0.wav -D 0 -d 0 -p 1024 -n 3
Playing sample: 2 ch, 44100 hz, 32 bit
```

3.2.5.3 tinycap

```
Usage: tinycap file.wav [-D card] [-d device] [-c channels] [-r rate] [-b bits] [-p
period_size] [-n n_periods]
```

Example: Recording audio at 44.1k sample rate

```
# tinycap /sdcard/rec.wav -D 0 -d 0 -c 2 -r 44100 -b 16 -p 1024 -n 3
```

3.2.5.4 tinymix

Control the internal path switch of the codec, volume control, etc. The effect is equivalent to [amixer](#)

```
usage: tinymix [-D card]
```

Example: Turn on the Mono path switch

```
# tinymix
Mixer name: 'rockchip,rt5640-codec'
Number of controls: 123
ctl      type    num    name                                value
0        BOOL    1      Mono Playback Switch              Off
1        INT     2      Mono DAC Playback Volume          175 175
2        BOOL    2      Speaker Channel Switch            Off Off
3        INT     2      Speaker Playback Volume           31 31
4        BOOL    2      HP Channel Switch                  Off Off
...
# tinymix "Mono Playback Switch" 1
Mono Playback Switch: On
```

3.2.6 xrun profiling

In the context of audio processing, an xrun is an error condition that occurs when the audio data flow is interrupted or disrupted, leading to a loss of synchronization between the audio output and input. There are two types of xrun: underruns and overruns.

Underruns occur when the audio buffer is not filled with data in time for the audio device to play it back, resulting in a gap or silence in the audio output. Overruns occur when the audio buffer is not read in time, causing the audio device to discard some of the incoming audio data.

In the Linux kernel, the ALSA (Advanced Linux Sound Architecture) framework provides support for handling xruns. ALSA provides a buffer management system to ensure a continuous flow of audio data and to prevent xruns from occurring. When an xrun occurs, ALSA generates an interrupt to notify the audio device driver that the buffer is empty or full, allowing the driver to refill or flush the buffer as needed to prevent the xrun from recurring.

To handle xruns effectively, audio device drivers should be designed to support real-time audio processing with low latency and high throughput. This involves using efficient buffering techniques, such as pre-fetching and double buffering, to ensure that audio data is always available for playback or recording. Additionally, audio device drivers should be optimized to minimize the latency of audio data transmission, and should implement error handling routines to recover from xruns as quickly as possible.

3.2.6.1 xrun kmsg

1. Enable XRUN CONFIG

```
CONFIG_SND_DEBUG
CONFIG_SND_PCM_XRUN_DEBUG
CONFIG_SND_VERBOSE_PROCFs
```

The xrun debugging switches are shown in Table 3-1 below. If you need to support all switches, just take the sum.

Bit Value	Description
1	Basic debugging - show xruns in ksyslog interface
2	Dump stack - dump stack for basic debugging
4	Jiffies check - compare the position with jiffies (a sort of in-kernel monotonic clock), show what's changed when basic debugging is enabled

Table 3-1 xrun debugging switch

2. Enable all xrun debug switches for sound card 0 playback devices

```
# echo 7 > /proc/asound/card0/pcm0p/xrun_debug
```

3. When the dma ringbuffer of playback is underrun, similar log examples are as follows:

```
asoc-simple-card rk809-sound: XRUN: pcmC0D0p:0
CPU: 3 PID: 657 Comm: sh Not tainted 4.19.161 #509
Hardware name: Generic DT based system
[<b010f47c>] (unwind_backtrace) from [<b010b9a8>] (show_stack+0x10/0x14)
[<b010b9a8>] (show_stack) from [<b0850b58>] (dump_stack+0x90/0xa4)
[<b0850b58>] (dump_stack) from [<b06a39c4>] (__snd_pcm_xrun+0xa0/0x114)
[<b06a39c4>] (__snd_pcm_xrun) from [<b069dac4>] (snd_pcm_stop_xrun+0x64/0x68)
[<b069dac4>] (snd_pcm_stop_xrun) from [<b0695c4c>] (snd_info_text_entry_release+0x34/0x7c)
[<b0695c4c>] (snd_info_text_entry_release) from [<b02694a4>] (close_pdeo+0x54/0x100)
[<b02694a4>] (close_pdeo) from [<b02695c0>] (proc_reg_release+0x70/0x78)
[<b02695c0>] (proc_reg_release) from [<b0210ac8>] (__fput+0x88/0x1c4)
[<b0210ac8>] (__fput) from [<b01412d4>] (task_work_run+0x94/0xb4)
[<b01412d4>] (task_work_run) from [<b010b48c>] (do_work_pending+0xc8/0xd0)
[<b010b48c>] (do_work_pending) from [<b0101064>] (slow_work_pending+0xc/0x20)
```

3.2.6.2 xrun ftrace

In addition to kernel log debugging information, xrun's trace event provides more detailed debugging information, such as hwptr and applptr. This section requires enabling kernel trace debug. The kernel trace events supported by ALSA are shown in Table 3-2

Trace Event	Description
snd_pcm:applptr	Update APP pointer
snd_pcm:hw_ptr_error	DMA pointer error
snd_pcm:xrun	xrun
snd_pcm:hwptr	Update DMA pointer

1. Enable FTRACE CONFIG

```
CONFIG_FUNCTION_TRACER
CONFIG_FUNCTION_GRAPH_TRACER
CONFIG_STACK_TRACER
CONFIG_DYNAMIC_FTRACE
```

2. Play audio in the background

```
# aplay -D hw:0,0 --period-size=128 --buffer-size=256 -r 48000 -f dat /dev/zero &
```

3. Enabling audio trace events can analyze detailed read/write information of buffer producers and consumers, making it easier to locate issues.

```
# cd /sys/kernel/debug/tracing
# echo "snd_pcm:applptr" >> set_event
# echo "snd_pcm:hwptr" >> set_event
# echo "snd_pcm:xrun" >> set_event
# cat trace | head -20
...
178.109942: applptr: pcmC0D0p/sub0: prev=0, curr=128, avail=128, period=128, buf=256
178.109981: applptr: pcmC0D0p/sub0: prev=128, curr=256, avail=0, period=128, buf=256
178.110224: hwptr: pcmC0D0p/sub0: POS: pos=24, old=0, base=0, period=128, buf=256
178.110234: applptr: pcmC0D0p/sub0: prev=256, curr=280, avail=0, period=128, buf=256
178.112441: hwptr: pcmC0D0p/sub0: IRQ: pos=128, old=24, base=0, period=128, buf=256
178.112510: applptr: pcmC0D0p/sub0: prev=280, curr=384, avail=0, period=128, buf=256
178.112553: hwptr: pcmC0D0p/sub0: POS: pos=136, old=128, base=0, period=128, buf=256
178.112556: applptr: pcmC0D0p/sub0: prev=384, curr=392, avail=0, period=128, buf=256
178.115176: hwptr: pcmC0D0p/sub0: IRQ: pos=0, old=136, base=0, period=128, buf=256
178.115270: applptr: pcmC0D0p/sub0: prev=392, curr=512, avail=0, period=128, buf=256
178.115321: hwptr: pcmC0D0p/sub0: POS: pos=8, old=256, base=256, period=128, buf=256
178.115327: applptr: pcmC0D0p/sub0: prev=512, curr=520, avail=0, period=128, buf=256
```

For more details, please refer to: [kernel/Documentation/trace/*](#)

3.2.6.3 trace-cmd

trace-cmd is the front-end application of ftrace, which simplifies the operation steps of `ftrace`, as shown in the following example:

```
# trace-cmd record -e snd_pcm:hwptr -e snd_pcm:applptr -e snd_pcm:xrun
# trace-cmd report
```

For more details, please refer to: [trace-cmd](#)

3.2.6.4 KernelShark

KernelShark is the front-end application of `trace-cmd`, which graphically presents the data of `trace-cmd`. Please refer to: [KernelShark](#)

3.3 PC Tools

Audacity and Audition are both audio analysis and processing tools for the PC platform, which can be used to analyze audio problems such as dropouts, noise, distortion, and constant frequency interference.

4. FAQ

4.1 Audio interface support

Please refer to [Rockchip Audio Features](#) and the chip datasheet.

4.2 Failed to register sound cards

- Confirm that the sound card driver configuration is compiled into the system according to [Example of adding a sound card](#)
- According to `kmsg` to locate problem: DAI, CODEC or Machine, for example, the following log indicates that DAI is not registered

```
[ 0.584114] rk-multicodecs vad-sound: ASoC: CPU DAI (null) not registered
```
- To check if it is DAI fail: When the DMA channel resources are insufficient, the DAI registration fails, close other modules that use DMA, and confirm again
- To check if it is CODEC fail: use [Multimeter](#) and [Oscilloscope](#) to measure CODEC voltage and clock, meanwhile confirm whether i2c device communication is normal with [i2c-tools](#).

4.3 Playback has no sound

- Confirm that the audio source is not a muted file.
- Use [aplay](#) or [tinyplay](#) to play, determine whether the problem occurs in userspace or kernel.
- Waiting for more than 10 seconds during playback to determine if it is an [I/O error](#) problem caused by timeout.
- Use [amixer](#) or [tinymix](#) to check whether the internal DAC path of the CODEC is turned on and whether the volume is muted.
- Check the configuration of [register](#), and confirm whether the configuration is correct with the chip manual or CODEC manual: IOMUX, DAI, CODEC.

- Use [Multimeter](#) and [Oscilloscope](#) to measure voltage, clock, data. Confirm the voltage, the clock is normal, and there is a waveform on the data line; measure whether the analog output signal at the near end of the CODEC is normal, measure the level of the gpio enabled by the PA, and locate the problem step by step.

4.4 Playback Distortion

- Use [aplay](#) or [tinyply](#) to play 1k0 audio files.
- Adjust the volume to see if distortion is related to volume level.
- Use [oscilloscope](#) to check the CODEC output signal for clipping or other distortion phenomena. Check if the clock of the CODEC or input source is stable.
- Use [Multimeter](#) to check if the power supply is normal and ensure it meets the power specifications described in the chip manual.
- Adjust the DMA buffer's cycle count and buffer size to see if there is any improvement.
- Step-by-step to inspect nodes that may contribute to the distortion.

4.5 Record has no Sound

- Generate a 1kHz waveform signal using [Signal Generator](#) and then fed into the CODEC.
- Use [arecord](#) or [tincap](#) to record, and locate whether the problem occurs in userspace or kernel.
- Waiting for more than 10 seconds during capture to determine if it is an [I/O error](#) problem caused by timeout.
- Use [amixer](#) or [tinymix](#) to check whether the CODEC's internal ADC path is turned on and whether the volume is muted
- Check the configuration of [Register](#), and confirm whether the configuration is correct with the chip manual or CODEC manual: IOMUX, DAI, CODEC.
- Use [Multimeter](#) and [Oscilloscope](#) to measure voltage, clock, data. Confirm the voltage, the clock is normal, and there is a waveform on the data line; measure whether the analog input signal near the CODEC is normal, and locate the problem by level.

4.6 Record Distortion

- Generate a 1kHz waveform signal using [Signal Generator](#) and then fed into the CODEC.
- Record with [arecord](#) or [tincap](#), output data with [loopback](#), measure with [Oscilloscope](#); or analyze with [PC Tool](#).
- Adjust the digital or analog gain, observe the loopback waveform, and compare the measured data to the test data to see if they match.
- Step-by-step to inspect nodes that may contribute to the distortion.

4.7 Excessive or insufficient playback rate

- Check [clk summary](#) to confirm if the clocks (MCLK, BCLK, LRCK) are accurate.
- Use [Oscilloscope](#) to confirm that the clock signal is accurate.
- Use [PC Tool](#) to record the output signal, and confirm if there is data loss or addition.
- Use the logic analyzer to dump the chip output data to confirm if there is data loss or addition.

4.8 Regular dropouts

- Regular dropout issues usually occur in heterogeneous systems, such as UAC application scenarios, BT voice application scenarios, network audio streaming, etc.

The fundamental reason is that the clock is asynchronous, and accumulated errors occur over time. This type of problem can be solved by [Audio Clock Compensation](#).

- Abnormal processing of buffer boundaries can also cause regular dropouts and noise. The problem can be analyzed through [xrun profiling](#).

4.9 Noise

There are many reasons for noise, and some commonly used methods for locating noise are as follows:

- Confirm whether the clock signal is accurate and whether the jitter is too large. For example, for HDA audio, the jitter should be less than 0.5 ns.
- Confirm whether there are glitches on the clock signal, especially within the effective value judgment range of the edge. If glitches occur, they will be recognized by the chip as the clock, causing timing problems. The IO on the RK platform has a Smmitter trigger function (please refer to the chip manual for support, such as RV1126), which can effectively filter out glitches and solve the noise problem caused by random glitches.
- Confirm the power supply and ground of the CODEC. The CODEC is sensitive to power supply noise, and any noise coupled into the power supply or ground will cause the CODEC's performance to degrade, increase the noise floor, and cause noise.
- Use differential circuits in the hardware to suppress common-mode noise.
- Check the hardware PCB layout and investigate the source of the noise.

4.10 XRUN

For kernel xrun, refer to the [xrun profiling](#) section and list other profiling points as follows:

- Use multi-threaded programming on the application side, separate the read/write threads from the audio processing threads, and ensure that data interaction with the kernel is not interrupted.
- System scheduling issues can be analyzed through systrace or ftrace.
- Storage IO blocking may cause data reading to be blocked. Playing a RAM device file (such as /dev/zero)

can help determine if this is the case.

- Check if the clock is accurate, which may cause excessive data consumption. Refer to the [Excessive or insufficient playback rate](#), [Regular dropouts](#)

4.11 I/O error

When there is no response after playing or recording for more than 10 seconds, the kernel log prints:

```
playback/capture write error (DMA or IRQ trouble?).
```

- Check the DAI controller FIFO COUNT register using [Register](#), to see if counting has stopped.
- Check if the DMA interrupt is updated using [procfs](#): `cat /proc/interrupts | grep dma`.
- Check if the DMA controller channel status register (offset address: 0x100) is abnormally stopped using [Register](#).
- When the DAI works as a slave, ensure that the external device clock continuously provides during the DAI's entire lifecycle. If this cannot be guaranteed, keep it always on.