LCD1 LM016L ď®V1 5k U1 RESET PC0/SCL PC1/SDA PC2/TCK PC3/TMS PC4/TDO 22 23 24 25 26 27 28 29 13 12 XTAL1 XTAL2 PC5/TDI PC6/TOSC1 PA0/ADC0 39 PA1/ADC1 X1 38 37 36 PA2/ADC2 PC7/TOSC2 CRYSTAL PA3/ADC3 PA4/ADC4 PD0/RXD 14 15 16 17 18 19 20 21 35 PD1/TXD PD2/INT0 PD3/INT1 PA5/ADC5 34 PA6/ADC6 33 PA7/ADC7 PD4/OC1B meno LS1 PD5/OC1A PD6/ICP1 PB0/T0/XCK PB1/T1 3 PB2/AIN0/INT2 PD7/OC2 4 5 6 7 8 PB3/AIN1/OC0

PB4/SS

PB5/MOSI PB6/MISO

PB7/SCK ATMEGA32 - SOUNDER

32 30 AREF AVCC