

Lab Sheet for Week 5

Lab Instructor: RSP

Lab 1: AVR Stack Operations

Objectives

- Use Microchip Studio for AVR and the built-in simulator/debugger to analyze AVR assembly code.
- Use the simulator to debug programs and observe the internal state of the ATmega328P microcontroller during code execution.
- Use breakpoints effectively to control program execution and aid in debugging.
- Analyze the stack operations of the AVR.

Lab Procedure

1. Create a new project in **Microchip Studio for AVR** or **Microchip MPLAB X IDE**.

1.1 Select **AVR Assembly**, enter a project name, and choose a directory for the project.

1.2 Select **ATmega328P** as the target device and click the “OK” button.

1.3 Open the **.asm** file to edit the source code.

2. Write AVR assembly code in **main.asm** as follows:

2.1 Use the provided AVR assembly code as shown in **Code Listing 1**.

2.2 Build the project to produce the output files.

3. Use the built-in AVR simulator to simulate the assembly program.

3.1 Start a **debugging session** (choose **Debug** → **Start Debugging** and **Break** from the menu) using the simulator to begin the code execution.

3.2 Ensure that the built-in simulator is selected as the debugger.

3.3 Add some breakpoints to the code before starting the debug process (as shown in **Figure 1**).

3.4 Open the **Processor Status View**, **CPU Registers View**, **I/O View** and **Memory View** to observe the MCU state.

3.5 Step through the code repeatedly until the next breakpoint is reached.

3.6 Observe the following:

- The contents of the CPU registers during the **PUSH** and **POP** operations.
- How the **stack pointer (SP)** changes during program execution, including the stack growth direction.
- The number of clock cycles required to execute each instruction.

4. Capture screenshots of the Microchip Studio for AVR simulator showing the CPU registers and memory contents at different time steps for inclusion in the lab report.

```

.include "m328pdef.inc"
.cseg
.org 0x0000
    rjmp RESET           ; [2C] Reset vector

; Reset and Initialization
RESET:
    ; Initialize Stack Pointer (SP = RAMEND)
    ldi r16, high(RAMEND) ; [1C] load the high byte of RAMEND to R16
    out SPH, r16           ; [1C] SPH = R16
    ldi r16, low(RAMEND)  ; [1C] load the low byte of RAMEND to R16
    out SPL, r16           ; [1C] SPL = R16

; Push loop
    ldi r16, 10            ; [1C] R16 = 10 (push counter)
PUSH_LOOP:
    push r16               ; [2C] Push R16 onto stack
    dec r16                ; [1C] R16 = R16 - 1
    brne PUSH_LOOP         ; [1C/2C] Repeat until R16=0 (branch if not equal zero)

; Pop and accumulate loop
    clr r16                ; [1C] R16 = 0 (pop counter, count-up)
    clr r1                 ; [1C] R1 = 0 (used as the accumulator)
POP_LOOP:
    pop r2                 ; [2C] Pop stack value into R2
    add r1, r2              ; [1C] R1 = R1 + R2
    inc r16                ; [1C] R16 = R16 + 1
    cpi r16, 10             ; [1C] Compare R16 with 10
    brne POP_LOOP          ; [1C/2C] Repeat until R16=10

; Endless loop
DONE:
    rjmp DONE              ; [2C] Stop here

```

Code Listing 1: AVR assembly code template for Lab 1

```

1 .include "m328pdef.inc"
2 .cseg
3 .org 0x0000
4 rjmp RESET ; [2C] Reset vector
5 ; Reset and Initialization
6
7 ; Initialize Stack Pointer (SP = RAMEND)
8 ldi r16, high(RAMEND) ; [1C] load the high byte of RAMEND to R16
9 out SPH, r16 ; [1C] SPH = R16
10 ldi r16, low(RAMEND) ; [1C] load the low byte of RAMEND to R16
11 out SPL, r16 ; [1C] SPL = R16
12 ; Push loop
13 ldi r16, 10 ; [1C] R16 = 10 (push counter)
14
15 PUSH_LOOP:
16 push r16 ; [2C] Push R16 onto stack
17 dec r16 ; [1C] R16 = R16 - 1
18 brne PUSH_LOOP ; [1C/2C] Repeat until R16 = 0 (branch if not equal zero)
19 ; Pop and accumulate loop
20 clr r16 ; [1C] R16 = 0 (pop counter, count-up)
21 clr r1 ; [1C] R1 = 0 (used as the accumulator)
22
23 POP_LOOP:
24 pop r2 ; [2C] Pop stack value into R2
25 add r1, r2 ; [1C] R1 = R1 + R2
26 inc r16 ; [1C] R16 = R16 + 1
27 cpi r16, 10 ; [1C] Compare R16 with 10
28 brne POP_LOOP ; [1C/2C] Repeat until R16 = 10
29 ; Endless loop
30
31 rjmp DONE ; [2C] Stop here

```

Figure 1: Example of Breakpoint Settings

Address	Symbol	Hex	Decimal	Binary	Char
8E9		0x00 0	00000000	0000000000000000	'.'
8EA		0x00 0	00000000	0000000000000000	'.'
8EB		0x00 0	00000000	0000000000000000	'.'
8EC		0x00 0	00000000	0000000000000000	'.'
8ED		0x00 0	00000000	0000000000000000	'.'
8EE		0x00 0	00000000	0000000000000000	'.'
8EF		0x00 0	00000000	0000000000000000	'.'
8F0		0x00 0	00000000	0000000000000000	'.'
8F1		0x00 0	00000000	0000000000000000	'.'
8F2		0x00 0	00000000	0000000000000000	'.'
8F3		0x00 0	00000000	0000000000000000	'.'
8F4		0x00 0	00000000	0000000000000000	'.'
8F5		0x00 0	00000000	0000000000000000	'.'
8F6	0x01 1		00000001	0000000000000001	'.'
8F7	0x02 2		00000010	0000000000000010	'.'
8F8	0x03 3		00000011	0000000000000011	'.'
8F9	0x04 4		00000100	0000000000000100	'.'
8FA	0x05 5		00000101	0000000000000101	'.'
8FB	0x06 6		00000110	0000000000000110	'.'
8FC	0x07 7		00000111	0000000000000111	'.'
8FD	0x08 8		00001000	0000000000000100	'.'
8FE	0x09 9		00001001	0000000000000101	'.'
8FF	0x0A 10		00001010	0000000000000110	'.'

Figure 2: AVR SRAM Memory View (only some memory locations are shown)

Post-Experiment Questions

1. Which register pair is used to implement the stack pointer (SP) in the AVR architecture?
2. What are SPH and SPL?
3. Which I/O registers (Special Function Registers, SFRs) are used to store the high byte and low byte of the stack pointer?
4. During program execution, how does the stack pointer (SP) change when a PUSH instruction is executed?
5. How does the stack pointer (SP) change when a POP instruction is executed?
6. In which direction does the stack grow in the SRAM address space of an AVR microcontroller?
7. How many machine cycles are required to execute a PUSH instruction?
8. How many machine cycles are required to execute a POP instruction?
9. What is the highest possible value of the stack pointer after reset, and why is this value used?
10. What is the value of RAMEND for the ATmega328P device?
11. Why is it necessary to initialize the stack pointer before using PUSH or POP instructions?
12. When program execution reaches the instruction "rjmp DONE", what is the final content of register R1? Explain how this value is obtained.
13. If the simulator executes the program starting from the instruction " rjmp RESET" and then first halts at the instruction "rjmp DONE", how many CPU cycles have been executed up to that point? Explain how you calculate the total number of CPU cycles for your answer.
14. What is the program memory address (word address) of the instruction "rjmp DONE" in the program memory?
15. Based on the program memory listing shown in **Figure 3**. How many instructions does this program have? Which instructions are 16-bit and which are 32-bit?

Line	Address	Opcode	Label	DisAssy
1	0000	C000		RJMP RESET
2	0001	E008	RESET	LDI R16, 0x08
3	0002	BFOE		OUT 0x3E, R16
4	0003	EF0F		LDI R16, 0xFF
5	0004	BF0D		OUT 0x3D, R16
6	0005	E00A		LDI R16, 0x0A
7	0006	930F	PUSH_LOOP	PUSH R16
8	0007	950A		DEC R16
9	0008	F7E9		BRNE PUSH_LOOP
10	0009	2700		EOR R16, R16
11	000A	2411		EOR R1, R1
12	000B	902F	POP_LOOP	POP R2
13	000C	0C12		ADD R1, R2
14	000D	9503		INC R16
15	000E	300A		CPI R16, 0x0A
16	000F	F7D9		BRNE POP_LOOP
17	0010	CFFF	DONE	RJMP DONE
18	0011	FFFF		
19	0012	FFFF		

Figure 3: AVR Program Memory View

Lab 2: I/O Bit-Banging

Objectives

- Use Microchip Studio for AVR and the built-in simulator/debugger to analyze AVR assembly code.
- Use the simulator to debug programs and observe the internal state of the ATmega328P microcontroller during code execution.
- Use breakpoints effectively to control program execution and aid in debugging.
- Verify the program using real hardware.

Lab Procedure

1. Create a new project in **Microchip Studio for AVR** or **Microchip MPLAB X IDE**.

1.1 Select **AVR Assembly**, enter a project name, and choose a directory for the project.

1.2 Select **ATmega328P** as the target device and click the “OK” button.

1.3 Open the **.asm** file to edit the source code.

2. Write AVR assembly code in **main.asm** as follows:

2.1 Use the provided AVR assembly code as shown in **Code Listing 2**.

2.2 Build the project to produce the output files.

3. Use the built-in AVR simulator to simulate the assembly program.

4. Use the **AVRDUE** program to upload the **.hex** file to the Arduino board and use a digital oscilloscope or a USB logic analyzer to analyze the output waveform at the **PB5** pin.

4.1 Measure the positive pulse width and the frequency of the waveform.

4.2 Capture the signal waveforms for inclusion in the lab report.

5. Revise the AVR assembly program so that the **LSB is shifted out first** (instead of MSB first), and use the constant value **0xED** for **DATA_BYTE**.

5.1 Build the project and upload the **.hex file** to the Arduino board to verify the correctness of the program.

5.2 Measure the frequency of the waveform.

5.3 Capture the signal waveforms for inclusion in the lab report.

```

.include "m328pdef.inc"
.def BIT_COUNT = r17           ; bit counter
.def DATA_BYTE = r18            ; data byte to shift out

.cseg
.org 0x0000
rjmp RESET                   ; [2C] Reset vector

; Reset and Initialization
RESET:
; Initialize Stack Pointer (SP = RAMEND)
ldi r16, high(RAMEND)      ; [1C]
out SPH, r16                 ; [1C]
ldi r16, low(RAMEND)        ; [1C]
out SPL, r16                 ; [1C]

; Configure PB5 as output
sbi DDRB, PB5                ; [2C]

; Main loop: shift out the MSB first on PB5
MAIN_LOOP:
cbi PORTB, PB5               ; [2C] clear PB5
ldi DATA_BYTE, 0x80            ; [1C] load DATA_BYTE
ldi BIT_COUNT, 8               ; [1C] set BIT_COUNT (8 bits)
nop                         ; [1C] no operation
nop                         ; [1C] no operation

SHIFT_LOOP:
; Output MSB of DATA_BYTE to PB5
sbrc DATA_BYTE, 7              ; [1C/2C] skip next if MSB = 0
sbi PORTB, PB5                ; [2C] set PB5 (output logic 1)
sbrs DATA_BYTE, 7              ; [1C/2C] skip next if MSB = 1
cbi PORTB, PB5                ; [2C] clear PB5 (output logic 0)

lsl DATA_BYTE                 ; [1C] logical shift left the data byte
dec BIT_COUNT                  ; [1C] BIT_COUNT--
brne SHIFT_LOOP                ; [1C/2C] loop until BIT_COUNT is zero

rjmp MAIN_LOOP                 ; [2C] repeat the main loop

```

Code Listing 2: AVR assembly code template for Lab 2




Figure 4: Period Measurement using FX2 USB Logic Analyzer / PulseView




Figure 5: Positive Pulse Width Measurement using FX2 USB Logic Analyzer / PulseView

Post-Experiment Questions

1. How many machine cycles does the CPU take to complete one iteration of the MAIN loop? How is this number of cycles related to the period and frequency of the output signal?
2. If the CPU clock frequency is 16 MHz, what is the output signal frequency at the **PB5** pin? What are the duty cycle and the positive pulse width of the signal?
3. If the data byte is changed from **0x80** to **0xFE**, what is the positive pulse width of the output signal at the **PB5** pin? Confirm your answer by capturing and analyzing the signal waveforms using a digital oscilloscope or a USB logic analyzer.