TTP229 keypad overlay - all layouts

Print on A4 at 100% (Actual size, no 'Fit to page'). Board 49.3 x 64.5 mm. Pins at top. Cut on dashed line.

TTP229 - Numpad (original)

pins side (top)

1	2	3	
4	5	6	
7	8	9	
C	0	OK	

TTP229 - Calculator

pins side (top)

7	8	9	÷
4	5	6	×
1	2	3	-
C	0	=	+

TTP229 - Classic 4x4 keypad

pins side (top)

1	2	3	A
4	5	6	B
7	8	9	C
*	0	#	D

TTP229 - Hexadecimal 0-F

pins side (top)

0	1	2	3
4	5	6	7
8	9	A	B
C	D	E	F

TTP229 - Phone + menu

pins side (top)

1	2	3	▲
4	5	6	▼
7	8	9	ESC
*	0	#	OK

TTP229 - Alarm / door lock

pins side (top)

1	2	3	ARM
4	5	6	STAY
7	8	9	OFF
C	0	OK	SOS

TTP229 - Smart home

pins side (top)

L1	L2	L3	L4
FAN	AC	TV	PLUG
OPEN	STOP	CLOSE	NIGHT
SCENE 1	SCENE 2	ALL ON	ALL OFF

TTP229 - Game pad

pins side (top)

L1	▲	R1	X
◀	OK	▶	Y
L2	▼	R2	A
SEL	HOME	START	B

TTP229 - Media remote

pins side (top)

⏮	⏯	⏭	■
VOL-	MUTE	VOL+	●
1	2	3	4
BACK	HOME	MENU	PWR



Check: this ruler must measure exactly 100 mm. If not, printer scaling is wrong.

TTP229 keypad overlay - all layouts

Print on A4 at 100% (Actual size, no 'Fit to page'). Board 49.3 x 64.5 mm. Pins at top. Cut on dashed line.



Check: this ruler must measure exactly 100 mm. If not, printer scaling is wrong.