

qTop Cell LTE GNSS BG95/BG96 AFC/AMC shield

User Manual

Abstract

User Manual provides information how to build simple IOT solution to publish data to ThingsBoard Cloud using the qTop Cell LTE GNSS BG95/BG96 AFC/AMC shield.





Table of Contents

Revision History	2
OVERVIEW	3
HW SETUP	3
THINGSBOARD CLOUD	6
CONCLUSION	18
TRADEMARK NOTICE	18






Revision History

NºNº	Version	Date	Author	Description
1	1.0	03.30.2021	lotbotscom	Initial
2				
3				



OVERVIEW

So, let us share our experience of setting up in a minute local condition DIY IOT monitoring demo project. IOT hardware, embedded firmware and Cloud Dashboard will be setup and configured. Local temperature, humidity and pressure, as well as device vital data, like a battery level and cellular RSSI, and, location info were obtained and published to ThingsBoard cloud.



ESP32 WiFi IOT controller board, Quectel BG96 cellular modem based Feather compatible shield with LTE and GNSS antennas attached, and, BME280 sensor module were used. ThingsBoard Local Condition IOT Dashboard was created.

HW SETUP

IOT board

Adafruit HAZZAH32 ESP32 controller board with Stacking Headers was used.





This was a nice and powerful IOT board with WiFi and BT/BLE wireless embedded. We used this board for Demo because of its popularity and availability.

Connectivity

As we planned, we would like to build remote device monitoring DIY IOT solution, so, we had decided to use cellular connectivity and wanted to demonstrate our newest product - qTop Cell BG96 Feather compatible shield (by IOT-BOTS.COM).



This device was the part of qTop family, which included Quectel and uBlox Cellular, LoRa, GNSS and sensor shield to be used together with Feather and Arduino MKR Compatible IOT boards. This board would be available in the beginning of Q2 2021.


qTop BG96 shield was plugged to controller board Feather Compatible Interface connectors. We set modem to function in GSM (2G) mode because of several reasons, so any 2G SIM card would perfectly worked - we used SpeedTalk Mobile SIM Card.

LTE and GNSS internal antennas with u.FL connectors were applied to BG96 modem board.

<u>Sensor</u>

To make this Demo alive, we brought local condition monitoring feature and qJam BME280 sensor module was used for it.






qJam Temperature / Humidity / Pressure BME280 module was part of the newest <u>qJam</u> IOT device line, developed and manufactures by IOT-BOTS.COM. Module was plugged to appropriate connector of qTop shield. I2C interface was used to communicate with module.

BTW, any other BME280 sensor module could be used as option - you just needed to connect 3,3V power and I2C bus and check the module I2C address and change it in source code if required.

<u>Power</u>

To power the system, 3,7V 750 mA LiPol battery was used (any 3,7V 500...1000 mA LiPol battery could be fine, for example, <u>this one</u>). The battery was connected to IOT controller board as usual. Battery can be charged by connecting Feather board to PC or USB power adapter through USB cable.

So, this was a whole HW setup used for this Demo: Adafruit HAZZAH32 ESP32 controller board with qTop BG96 AFC shield plugged in. qJam BME280 sensor module and SIM card, both inserted into qTop shield board and LTE and GNSS internal antennas attached to appropriate u.FL connectors there. LiPol battery provided a power.





THINGSBOARD CLOUD

ThingsBoard IOT open-source platform was chosen as IOT Cloud Dashboard. We created dashboard that all sensors and device data were shown there:

- Temperature, humidity, pressure sensors data gauges;
- Battery level and cellular RSSI;
- Location, speed and GNSS info;
- Temperature, humidity, pressure sensors data timeseries charts;
- Map with device location.

You don't need to build this dashboard from scratch - ThingsBoard.io platform allows to reuse made early dashboards through Import-Export JSON format feature. So, to get this Demo dashboard you just need to make these simple steps:

create ThingsBoard account


If you don't have ThingsBoard account, you need to proceed to ThingsBoard website <u>login</u> <u>page</u>. As soon as you complete this step, you will receive confirmation email and will be able to login there.







Add device

Next step is adding device and getting device token. We used "qTop-Modem" as device name.











As soon device added, please save token received - it will be used later.


Import Demo dashboard JSON file.


Now we need to import <u>Demo dashboard</u>. Please go step by step as shown at pics below:













Finally, you will see empty dashboard and now you need to set aliases.


Edit aliases



Now, we need to "connect" Demo dashboard imported with "qTop-Modem" device added before:












After saving all changes, you will be able to see Demo Dashboard fully setup and ready to go.



EMBEDDED FW

Demo firmware was created using Arduino IDE. Demo sketch could be found <u>here</u>. It was created and built for Adafruit HAZZAH32 board as target HW.

These components and libs (we used the latest versions) to be installed for Arduino IDE to get sketch built and flashed to target HW:

- Arduino core for the ESP32;
- Adafruit BME280 Library;
- TinyGSM Lib;
- StreamDebugger Lib (if you want to turn modem AT command debug On);



- ArduinoJSON Lib.

All items could be installed through Arduino IDE or manually. You can find a lot of info on the Internet how to make installations mentioned above, so please let us skip this step.

As soon as all preparation completed, just open the <u>sketch</u> in IDE. To make system properly working, you need to make these changes in sketch opened:


- enter / edit APN info (check your SIM card provider);
- enter / edit ThingsBoard token (use token, copied from ThingsBoard "Token Step" completed before).

Picture below shows these places in the sketch:

```
qTop_BG96_AFC_ThingsBoard §
#endif
// Initialize GSM client
TinyGsmClient client (modem);
// BME280 sensor
Adafruit_BME280 bme280;
 / GPRS credentials
 onst char apn[] = "wholesale";
 const char user[] = "";
 onet cher pass[] = "";
// See https://thingsboard.io/docs/getting-started-guides/helloworld/
   to understand how to obtain an access toker
#define CLOUD_TOKEN "pb7Vclgo03M2TmAdvrYe"
#define CLOUD_SERVER "thingsboard.cloud
#define CLOUD_PORT 80
// JSON a HTTP
DynamicJsonDocument jsonbuf(1024);
String regtstr = "";
```

FW developed could be run in two modes: "Always On" and "One Shot". In "Always On" mode system continuously published data with interval defined. For "One Shot" mode, system made single publishing and moved to Deep Sleep. By default, Demo run in "Always On" mode with 5 seconds publish delay interval (not actual publishing data interval).

To set mode wanted, "demo_mode" variable should be INITed with appropriate mode define.



FW functionality:

- After power up, GPIO config was done;
- Check that qJam sensor was connected: BME280 sensor found and data received;
- and, final setup() step was modem on.

In the main loop ("Always On" mode):

- getting BME280 sensor data;
- collecting modem / network status;
- requesting GNSS info;
- opening TCP/IP session (if not opened yet);
- publishing info received to a cloud;
- waiting for 5 sec.

In the main loop ("One Shot" mode):

- getting BME280 sensor data;
- collecting modem / network status;
- requesting GNSS info;
- opening TCP/IP session;
- publishing info received to a cloud;
- closing session opened;
- turn modem off;
- move to Deep Sleep.

HTTP and RESTful API option was used to publish data to ThingsBoard cloud.

We provided enough comments in source code, so, we hoped, it could be easily read and understood. Moreover, we put "printf" logging for all major execution steps - please see run logs below.



```
**** IOT-BOTS.COM ****
**** qTop Quectel BG96 Shield ThingsBoard Demo ****
---- Setup Started ----
BME280 Sensor Found!
Modem Initializing...
[6178] ### TinyGSM Version: 0.10.9
[6178] ### TinyGSM Compiled Module: TinyGsmClientBG96
[9484] ### Modem: Quectel BG96
[9484] ### Modem: Quectel BG96
Modem: Quectel BG96 Revision: BG96MAR02A07M1G
IMEI: 86703504799XXXX
IMSI: 31026094158XXXX
CCID: 8901260941115897457F
---- Setup Done ----
---- Loop Cycle ----
Waiting for network...: Network connected
Connecting to "wholesale"...: GPRS connected
Get Network Time:
Year: 2021
Month: 2
Day: 14
Hour: 22
Minute: 51
Second: 33
Time Zone: -5.00
[16987] ### Unhandled: OK
Connecting to "thingsboard.cloud"...: Cloud connected
Battery:
Voltage, mV: 3849
Voltage, %: 56
BME280 Sensor:
Temperature, F: 78.30
Pressure, hPa: 990.76
```





Humidity, %: 15.17 Modem Power: Voltage, mV: 4015 Signal Quality: **RSSI: 18 GNSS**: ...No Data Available! **HTTP Request:** POST /api/v1/psExmXxbIXajWD3Voxnu/telemetry HTTP/1.1 Host: thingsboard.cloud Accept: */* Content-Type: application/json Content-Length: 104 {"Bat.voltage":56,"Ext.voltage":0,"RSSI":18,"Temperature":78.296,"Humidity":15.1748,"Pres sure":990.7645} HTTP Reply: [18092] ### URC RECV: 0 [18111] ### DATA AVAILABLE: 73 on 0 [18127] ### DATA AVAILABLE: 10 on 0 HTTP/1.1 200 content-length: 0 date: Mon, 15 Feb 2021 03:51:36 GMT ---- Loop Cycle ----In case, if no BME280 found, or, GNSS data was not available, that data were not published. "All data received" log is below: ---- Loop Cycle ----

Get Network Time :

Year : 2021 Month : 2



Day: 13 Hour: 21 Minute: 2 Second: 48 Time Zone: -5.00

Battery:

Voltage, mV: 3852 Voltage, %: 56

BME280 Sensor: Temperature, F: 91.47 Pressure, hPa: 990.07 Humidity, %: 11.82

Modem Power: Voltage, mV: 4013

Signal Quality: RSSI: 17

GNSS: Quality: 2 Date: 140221 Time: 020249 Latitude: 42.48779 Longitude: -83.43078 Altitude, m: 271 Speed, km/h: 74

Heading: 234 HDOP: 0.7 Sats In Use: 09

HTTP Request:

POST /api/v1/psExmXxbIXajWD3Voxnu/telemetry HTTP/1.1

Host: thingsboard.cloud

Accept: */*

Content-Type: application/json

Content-Length: 254

{"Bat.voltage":56,"Ext.voltage":0,"RSSI":17,"Temperature":91.472,"Humidity":11.82129,"Pre ssure":990.0728,"latitude":"42.48779","longitude":"-83.43078","altitude":"271","speed":"74","heading":"234","nsat":"09","hdop":"0.7","date":"140 221","time":"020249"}

HTTP Reply:





[28206] ### URC RECV: 0

[28226] ### DATA AVAILABLE: 73 on 0 [28242] ### DATA AVAILABLE: 10 on 0


HTTP/1.1 200 content-length: 0

date: Sun, 14 Feb 2021 02:02:50 GMT

---- Loop Cycle ----

Using logging prompts incorporated, you can see what it is happening with a system: check that all HW parts found properly working, see sensor and GNSS data, get connection results and data publishing status.

To check data receiving by cloud, you can verify it on "Latest Telemetry" tab for "qTop-Modem" device added.



As soon as all preparations completed and device turned on you would be able to see Demo dashboard with all data displayed.





Now you can play with your IOT dashboard, widgets and embedded source code to make your own version of this DIY IOT solution.

Enjoy!

CONCLUSION

It was shown how to easily setup nice looking DIY IOT Cloud Dashboard for remote local condition monitoring. To see sensor data, as well as vital data, like Battery, RSSI and location of cellular connected device.

ThingsBoard DIY IOT Dashboard was created.

ESP32 WiFi IOT controller board, Quectel BG96 cellular module based qTop Feather compatible shield with LTE and GNSS antennas attached, and, qJam BME280 sensor module were used.

TRADEMARK NOTICE

All referenced brands, product names, service names, and trademarks are the property of their respective owners.