



# Chapter 3: Using the WICED Real Time Operating System (RTOS)

After completing chapter 3 you will have a fundamental understanding of the role of the WICED RTOS in building WICED projects. You will be able to use the WICED RTOS abstraction layer to create and use threads, semaphores, mutexes, queues, and timers.

<b>3.1</b>	<b>AN INTRODUCTION TO RTOS .....</b>	<b>2</b>
<b>3.2</b>	<b>WICED RTOS ABSTRACTION LAYER .....</b>	<b>3</b>
<b>3.3</b>	<b>PROBLEMS WITH RTOSS.....</b>	<b>4</b>
<b>3.4</b>	<b>THREADS .....</b>	<b>5</b>
3.4.1	STACK USAGE.....	7
<b>3.5</b>	<b>SEMAPHORE.....</b>	<b>8</b>
<b>3.6</b>	<b>MUTEX.....</b>	<b>9</b>
<b>3.7</b>	<b>QUEUE .....</b>	<b>10</b>
<b>3.8</b>	<b>EXERCISE(S) .....</b>	<b>12</b>
	EXERCISE - 3.1 SEMAPHORE .....	12
	EXERCISE - 3.2 (ADVANCED) MUTEX .....	13
	EXERCISE - 3.3 (ADVANCED) QUEUES .....	14
	EXERCISE - 3.4 (ADVANCED) PRINT THE THREAD STACK USAGE.....	14



### 3.1 An Introduction to RTOS

The [purpose of an RTOS](#) is to reduce the complexity of writing embedded firmware that has multiple asynchronous, response-time-critical tasks that have overlapping resource requirements. For example, you might have a device that is reading and writing data to a connected network, reading and writing data to an external filesystem, and reading and writing data from peripherals. Making sure that you deal with the timing requirement of responding to network requests while continuing to support the peripherals can be complex and therefore error prone. By using an RTOS you can separate the system functions into separate tasks (called **threads**) and develop them in a somewhat independent fashion.

The RTOS maintains a list of threads that are idle, halted or running and which task needs to run next (based on priority) and at what time. This function in the RTOS is called the scheduler. There are two major schemes for managing which threads/tasks/processes are active in operating systems: preemptive and co-operative.

In preemptive multitasking the CPU completely controls which task is running and has the ability to stop and start them as required. In this scheme the scheduler uses CPU protected modes to wrest control from active tasks, halt them, and move onto the next task. Preemptive multitasking is the scheme that is used in Windows, Linux etc.

In co-operative multitasking each process has to be a good citizen and yield control back to the RTOS. There are a number of mechanisms for yielding control such as `rtos_delay`, semaphores, mutexes, and queues (which we will discuss later in this document).

The WICED RTOSs are preemptive. However, higher priority tasks will always run at the expense of lower priority tasks so it is still important to yield control to give lower priority tasks a turn. If not, tasks that don't yield control will prevent lower or equal priority tasks from running at all. It is good practice to have some form of yield control mechanism in every thread to prevent such situations.



## 3.2 WICED RTOS Abstraction Layer

Currently WICED Studio supports multiple RTOSs, but [ThreadX](#) by [Express Logic](#) is built into the device ROM and the license is included for anyone using WICED chips so that is by far the best choice.

In order to simplify using multiple RTOSs, the WICED SDK has a built-in abstraction layer that provides a unified interface to the fundamental RTOS functions. You can find the documentation for the WICED RTOS APIs under the API Guide→Components→RTOS.

Main Page	Components	Globals
<ul style="list-style-type: none"><li>▼ Cypress WICED Studio API Reference Guide<ul style="list-style-type: none"><li>WICED Studio Documentation</li><li>WICED Website</li><li>Bluetooth References</li><li>WICED Community</li><li>WICED Studio Licensing Information</li></ul></li><li>▼ Components<ul style="list-style-type: none"><li>► WICED trace utils</li><li>► Bluetooth</li></ul></li><li>▼ RTOS<ul style="list-style-type: none"><li>► Threads</li><li>► Semaphores</li><li>► Mutexes</li><li>► Queues</li><li>► RTOS timers</li><li>► Worker Threads</li><li>► Events</li><li>► Event Flags</li><li>► WICED Firmware Upgrade</li><li>► Hardware Drivers</li><li>► HID Events</li><li>► WICED Result Codes</li></ul></li><li>► Globals</li></ul>	<p><b>RTOS</b></p> <p>WICED Real-Time Operating System Functions. <a href="#">More...</a></p> <p><b>Modules</b></p> <p><b>Threads</b> Thread management functions.</p> <p><b>Semaphores</b> Semaphore management functions.</p> <p><b>Mutexes</b> Mutex management functions.</p> <p><b>Queues</b> Queue management functions.</p> <p><b>RTOS timers</b> RTOS timer management functions These timers are based on scheduling, so are not highly accurate.</p> <p><b>Worker Threads</b> Worker thread management functions.</p> <p><b>Events</b> Event management functions.</p> <p><b>Event Flags</b> Event flags management functions.</p>	



### 3.3 Problems with RTOSs

All of this sounds great, but everything is not peaches and cream (or whatever your favorite metaphor for a perfect situation might be). There are three serious bugs which can easily be created in these types of systems and these bugs can be very hard to find. These bugs are all caused by side effects of interactions between the threads. The big three are:

- Cyclic dependencies which can cause deadlocks
- Resource conflicts when sharing memory and sharing peripherals which can cause erratic non-deterministic behavior
- Difficulties in executing inter-process communication.

But all hope is not lost. The WICED RTOSs give you mechanisms to deal with these problems, specifically semaphores, mutexes, queues and timers. These functions generally all work the same way. The basic process is:

1. Include the `wiced_rtos.h` header file so that you have access to the RTOS functions.
2. Declare a pointer of the right type (e.g. `wiced_mutex_t*`)
3. Call the appropriate create function to allocate memory and return the pointer.
4. Call the appropriate RTOS initialize function (e.g. `wiced_rtos_init_mutex()`). Provide it with the pointer that was created in the first step.
5. Access the pointer using one of the access functions (e.g. `wiced_rtos_lock_mutex()`).
6. If you don't need it anymore, free up the pointer with the appropriate de-init function (e.g. `wiced_rtos_deinit_mutex()`).

All these functions need to have access to the pointer, so I generally declare these "shared" resources as static global variables within the file that they are used.



## 3.4 Threads

As we discussed earlier, threads are at the heart of an RTOS. It is easy to create a new thread by calling the function `wiced_rtos_create_thread()` and then `wiced_rtos_init_thread()` with the following arguments:

- `wiced_thread_t* thread` – A pointer to a thread handle data structure returned by the `wiced_rtos_create_thread()` function. This handle is used to identify the thread for other thread functions.
- `uint8_t priority` – This is the priority of the thread.
  - Priorities can be from 0 to 7 where 0 is the highest priority. User applications should typically use middle priorities of ~4.
  - If the scheduler knows that two threads are eligible to run, it will run the thread with the higher priority.
- `char *name` – A name for the thread. This name is only used by the debugger. You can give it any name or just use NULL if you don't want a specific name.
- `wiced_thread_function_t *thread` – A function pointer to the function that is the thread.
- `uint32_t stack size` – How many bytes should be in the thread's stack.
  - You should be careful here as running out of stack can cause erratic, difficult to debug behavior. Using 1024 is overkill but will work for any of the exercises we do in this class. If you want to see how much a given thread uses, we'll show you how you can do that below.
- `void *arg` – A generic argument which will be passed to the thread.
  - If you don't need to pass an argument to the thread, just use NULL.

As an example, if you want to create a thread that runs the function "mySpecialThread", the initialization might look something like this:

```
#define THREAD_PRIORITY      (4)
#define THREAD_STACK_SIZE    (1024)

.
.

wiced_thread_t* mySpecialThreadHandle; /* Typically defined as a global */

.
.

/* Typically inside the BTM_ENABLED_EVT */
mySpecialThreadHandle = wiced_rtos_create_thread();
wiced_rtos_init_thread(mySpecialThreadHandle, THREAD_PRIORITY, "mySpecialThreadName",
mySpecialThread, THREAD_STACK_SIZE, NULL);
```

The thread function must match type `wiced_thread_function_t`. It must take a single argument of type `uint32_t` and must have a `void` return.



The body of a thread looks just like the "main" function of a typical C application. Often a thread will run forever so it will have an initialization section and a while(1) loop that repeats forever. For example:

```
void mySpecialThread(uint32_t arg)
{
    /* Do any required one-time initialization here */
#define MY_THREAD_DELAY (100)

    while(1)
    {
        processData();
        wiced_rtos_delay_milliseconds(MY_THREAD_DELAY, ALLOW_THREAD_TO_SLEEP);
    }
}
```

Note: you should usually put a *wiced\_rtos\_delay\_milliseconds()* of some amount in every thread with the delay type of *ALLOW\_THREAD\_TO\_SLEEP* so that other threads get a chance to run. The exception is if you have some other thread control function such as a semaphore or queue that is guaranteed to cause the thread to periodically pause.

The functions available to manipulate a thread are in the "Component→RTOS→Threads" section of the WICED API reference.

The screenshot shows a web-based API documentation interface. On the left is a navigation sidebar with tabs for 'Main Page', 'Components', and 'Globals'. Below these are links to 'WICED Community' and 'WICED Studio Licensing Information'. Under 'Components', there are sections for 'WICED trace utils', 'Bluetooth', and 'RTOS'. The 'RTOS' section is expanded, and its 'Threads' sub-section is also expanded, showing a list of thread-related functions. To the right of the sidebar is the main content area. At the top of the content area is a title 'Threads' under the 'RTOS' heading. Below the title is a brief description: 'Thread management functions. More...'. The main content is titled 'Functions' and lists several functions with their descriptions. The listed functions are:

- wiced\_thread\_t \* [wiced\\_rtos\\_create\\_thread](#) (void)  
Creates a new instance of thread. More...
- wiced\_bool\_t [wiced\\_rtos\\_check\\_for\\_stack\\_overflow](#) (void)  
Checks if there is a stackoverflow. More...
- wiced\_queue\_t \* [wiced\\_rtos\\_create\\_queue](#) (void)  
Creates a new instance of queue. More...
- wiced\_mutex\_t \* [wiced\\_rtos\\_create\\_mutex](#) (void)  
Creates a new instance of mutex. More...
- wiced\_rtos\_timer\_t \* [wiced\\_rtos\\_create\\_timer](#) (void)  
Creates a new instance of timer. More...
- wiced\_semaphore\_t \* [wiced\\_rtos\\_create\\_semaphore](#) (void)  
Creates a new instance of semaphore. More...
- wiced\_event\_flags\_t \* [wiced\\_rtos\\_create\\_event\\_flags](#) (void)  
Creates a new instance of event flags. More...
- wiced\_worker\_thread\_t \* [wiced\\_rtos\\_create\\_worker\\_thread](#) (void)  
Creates a new instance of worker thread. More...
- wiced\_result\_t [wiced\\_rtos\\_init\\_thread](#) (wiced\_thread\_t \*thread, const char \*name, wiced\_thread\_function\_t function, stack\_size, void \*arg)



### 3.4.1 Stack Usage

If you want to see how much stack a thread is using, you need to use the underlying functions for the RTOS you are using. For example, if you are using ThreadX (the default RTOS in WICED) you first need to include the header to get access to the native ThreadX functions:

```
#include "tx_api.h"
```

Next, you could add this function to find the max stack size used by a given thread since it was started:

```
/* This will return the max amount of stack a thread has used */
/* This is ThreadX specific code so it will only work for ThreadX */
uint32_t maxStackUsage(TX_THREAD *thread)
{
    uint8_t *end = thread->tx_thread_stack_end;
    uint8_t *start = thread->tx_thread_stack_start;
    while(start < end)
    {
        if(*start != 0xEF)
        {
            return end-start;
        }
        start++;
    }
    return 0;
}
```

Finally, you can call the function occasionally in your project (e.g. in a timer or whenever a button is pressed) and then print the value. For example:

```
uint32_t size;
size = maxStackUsage((TX_THREAD*) mySpecialThreadHandle);
WICED_BT_TRACE("Max Stack Size: %d\n\r", size);
```

## 3.5 Semaphore

A [semaphore](#) is a signaling mechanism between threads. The name semaphore (originally sailing ship signal flags) was applied to computers by Dijkstra in a paper about synchronizing sequential processes. In the BT\_20819A1 SDK, semaphores are implemented as a simple unsigned integer. When you "set" a semaphore it increments the value of the semaphore. When you "get" a semaphore it decrements the value, but if the value is 0 the thread will SUSPEND itself until the semaphore is set. So, you can use a semaphore to signal between threads that something is ready. For instance, you could have a "sendData" thread and a "collectDataThread". The sendData thread will "get" the semaphore which will suspend the thread UNTIL the collectDataThread "sets" the semaphore when it has new data available that needs to be sent.

The get function requires a timeout parameter. This allows the thread to continue after a specified amount of time even if the semaphore doesn't get set. This can be useful in some cases to prevent a thread from stalling permanently if the semaphore is never set due to an error condition. The timeout is specified in milliseconds. If you want the thread to wait indefinitely for the semaphore to be set rather than timing out after a specific delay, use WICED\_WAIT\_FOREVER for the timeout.

The semaphore functions are available in the documentation under Components→RTOS→Semaphores.

Main Page	Components	Globals
-----------	------------	---------

Components

- ▶ WICED trace utils
- ▶ BLE Host Stack Management
- ▶ WICED Device Management
- ▶ Application Thread Serialization
- ▶ Bluetooth
- ▼ RTOS
  - Macro
  - Global Variables
  - Data Structures
  - ▶ Enumerated Types
  - ▼ Functions
    - ▶ Thread
    - ▶ Semaphore
    - ▶ Mutex
    - ▶ Queue
    - ▶ Worker Thread
    - ▶ Event Flag

**Semaphore**

Functions

Defines a group of APIs, which interface to RTOS semaphore functionality contained in ROM. More...

Functions

wiced_semaphore_t * <a href="#">wiced_rtos_create_semaphore</a> (void)	Allocates memory for a new semaphore instance and returns the pointer. More...
wiced_result_t <a href="#">wiced_rtos_init_semaphore</a> (wiced_semaphore_t *semaphore)	Initializes a counting semaphore created by <a href="#">wiced_rtos_create_semaphore</a> . More...
wiced_result_t <a href="#">wiced_rtos_set_semaphore</a> (wiced_semaphore_t *semaphore)	Set (post/put/increment) a semaphore. More...
wiced_result_t <a href="#">wiced_rtos_get_semaphore</a> (wiced_semaphore_t *semaphore, uint32_t timeout_ms)	Attempts to get (wait/decrement) a semaphore. More...

You should always create and initialize a semaphore before starting any threads that use it. Otherwise, you may see unpredictable behavior. For example:

```
wiced_semaphore_t* mySemaphore; /* Typically defined as a global */
.
.
mySemaphore = wiced_rtos_create_semaphore(); /* Typically inside the BTM_ENABLED_EVT */
wiced_rtos_init_semaphore( mySemaphore );
```

It is generally not a good idea to use a semaphore get inside an interrupt callback or a timer callback with a non-zero timeout since it may lock up your program waiting for a set that never occurs.

## 3.6 Mutex

Mutex is an abbreviation for "Mutual Exclusion". A mutex is a lock on a specific resource - if you request a mutex on a resource that is already locked by another thread, then your thread will go to sleep until the lock is released. In the exercises for this chapter you will create two different threads that blink the same LED at different rates. Without a mutex, you will see strange behavior. With a mutex, the threads are each given exclusive access to the LED.

The mutex functions are available in the documentation under Components→RTOS→Mutex.



The screenshot shows the Cypress WICED API documentation interface. The top navigation bar has tabs for Main Page, Components, and Globals. The Components tab is selected. On the left, there is a sidebar with a tree view of the API structure. The 'Mutex' node under the 'RTOS' section is currently selected. The main content area displays the 'Mutex' page, which includes a brief description: 'Defines a group of APIs, which interface to RTOS mutex functionality. More...' and a list of four functions: `wiced_mutex_t * wiced_rtos_create_mutex(void)`, `wiced_result_t wiced_rtos_init_mutex(wiced_mutex_t *mutex)`, `wiced_result_t wiced_rtos_lock_mutex(wiced_mutex_t *mutex)`, and `wiced_result_t wiced_rtos_unlock_mutex(wiced_mutex_t *mutex)`. Each function entry provides a brief description and a 'More...' link.

You should always create and initialize a mutex before starting any threads that use it. Otherwise, you may see unpredictable behavior. For example:

```
wiced_mutex_t* myMutex; /* Typically defined as a global */
.
.
myMutex = wiced_rtos_create_mutex(); /* Typically inside the BTM_ENABLED_EVT */
wiced_rtos_init_mutex( myMutex );
```

Note that a mutex can only be unlocked by the same thread that locked it.



### 3.7 Queue

A queue is a thread-safe mechanism to send data to another thread. The queue is a FIFO - you read from the front and you write to the back. If you try to read a queue that is empty your thread will suspend until something is written into it. The payload in a queue (size of each entry) and the size of the queue (number of entries) is user configurable at queue creation time.

The `wiced_rtos_push_to_queue()` requires a timeout parameter. This comes into play if the queue is full when you try to push into it. The timeout allows the thread to continue after a specified amount of time even if the queue stays full. This can be useful in some cases to prevent a thread from stalling permanently if the queue stays full due to an error condition. The timeout is specified in milliseconds. If you want the thread to wait indefinitely for room in the queue rather than timing out after a specific delay, use `WICED_WAIT_FOREVER` for the timeout. If you want the thread to continue immediately if there isn't room in the queue, then use `WICED_NO_WAIT`. Note that if the function times out, then the value is not added to the queue.

Likewise, the `wiced_rtos_pop_from_queue()` function requires a timeout parameter to specify how long the thread should wait if the queue is empty. If you want the thread to wait indefinitely for a value in the queue rather than continuing execution after a specific delay then use `WICED_WAIT_FOREVER`. If you want the project to continue immediately if there isn't anything in the queue then use `WICED_NO_WAIT`.

There are also functions to check to see if the queue is full or empty and to determine the number of entries in the queue.

The queue functions are available in the documentation under Components → RTOS → Queues.

Main Page	Components	Globals
-----------	------------	---------

DELL HOST Stack Management

- ▶ WICED Device Management
- ▶ Application Thread Serialization
- ▶ Bluetooth
- ▼ RTOS
  - Macro
  - Global Variables
  - Data Structures
  - ▶ Enumerated Types
  - ▼ Functions
    - ▶ Thread
    - ▶ Semaphore
    - ▶ Mutex
    - ▶ Queue
  - ▶ Worker Thread
  - ▶ Event Flag
  - ▶ Group\_rtos\_macros
  - ▶ Group\_rtos\_structures

## Queue

Functions

Defines a group of APIs, which interface to RTOS queues functionality contained in ROM. More...

### Functions

wiced_queue_t * <a href="#">wiced_rtos_create_queue</a> (void)	Allocates memory for a new queue instance and returns the pointer. More...
wiced_result_t <a href="#">wiced_rtos_init_queue</a> (wiced_queue_t *queue, const char *name, uint32_t me	Initializes queue instance created by <a href="#">wiced_rtos_create_queue</a> . More...
wiced_result_t <a href="#">wiced_rtos_push_to_queue</a> (wiced_queue_t *queue, void *message, uint32_t t	Enqueues an element. More...
wiced_result_t <a href="#">wiced_rtos_pop_from_queue</a> (wiced_queue_t *queue, void *message, uint32_t	Dequeues element and memcpy's it to given pointer. More...
wiced_bool_t <a href="#">wiced_rtos_is_queue_empty</a> (wiced_queue_t *queue)	Returns boolean value indicating whether queue is empty. More...
wiced_bool_t <a href="#">wiced_rtos_is_queue_full</a> (wiced_queue_t *queue)	Returns boolean value indicating whether queue is full. More...
wiced_result_t <a href="#">wiced_rtos_get_queue_occupancy</a> (wiced_queue_t *queue, uint32_t *count)	Read number of elements enqueued. More...

You should always create and initialize a queue before starting any threads that use it. Otherwise, you may see unpredictable behavior. For example:

```
wiced_queue_t* myQueue; /* Typically defined as a global */
.
.
myQueue = wiced_rtos_create_queue(); /* Typically inside the BTM_ENABLED_EVT */
wiced_rtos_init_queue( myQueue, "myQueue", sizeof(uint32_t), 5 );
```



## 3.8 Exercise(s)

### Exercise - 3.1 Semaphore

Create a program where an interrupt looks for a button press then sets a semaphore to communicate to the toggle LED thread.

1. Create a new application called **ch03\_ex01\_semaphore** using the template in the "templates/CYW920819EVB/ch03" folder.
2. Create a new semaphore pointer as a global variable, then create and initialize the semaphore when the Bluetooth stack is enabled.
  - a. Hint: You need both a create function call and an initialize function call.
  - b. Hint: Be sure to create and initialize the semaphore before starting the LED thread or the interrupt (added in the next step) since they use the semaphore.
3. Use the provided interrupt callback function to look for a button press and set the semaphore.
  - a. Hint: Refer to the interrupt exercise from the peripherals chapter.
4. Get the semaphore inside the LED thread so that it waits for the semaphore forever and then toggles the LED rather than blinking constantly.
  - a. Hint: Use WICED\_WAIT\_FOREVER so that the thread will wait until the button is pressed. The definition for this can be found at the top of wiced\_rtos.h.

Questions to answer:

1. Do you need wiced\_rtos\_delay\_milliseconds() in the LED thread? Why or why not?



### Exercise - 3.2 (Advanced) Mutex

An LED may behave strangely if two threads try to blink it at the same time. In this exercise we will use a mutex to lock access.

1. Create a new application called ch03\_ex02\_mutex using the template in the "templates/CYW920819EVB/ch03\_ex02\_mutex" folder.
2. The project has 2 threads – one thread blinks the LED at a rate of 2Hz and the other thread blinks the same LED at a rate of 5Hz when the button is being pressed.
3. Program the project as it is to your kit. What happens when you hold down the button? Does the LED blink at 5Hz?
4. Look at the TODO comments to add a mutex to the two threads so that each thread prevents the other from blinking the LED when it needs access.
5. Program the project to your kit. Now what happens when you hold down the button?

Questions to answer:

1. Before you added the mutex, how did the LED behave when you pressed the button?
2. What changed when you added the mutex?
3. What happens if you forget to unlock the mutex in one of the threads? Why?



### Exercise - 3.3 (Advanced) Queues

Use a queue to send a message to indicate the number of times to blink an LED.

1. Create a new application called ch03\_ex03\_queue using the template in the "templates/CYW920819EVB/ch03" folder (not the mutex template).
2. The queue API uses memory from the buffer pools that are defined in app\_bt\_cfg.c. By default, there are insufficient pools to support queues and so you need to modify the value of wiced\_bt\_cfg\_settings.max\_number\_of\_buffer\_pools to allocate more memory. You should add a buffer pool for each queue that your application will create (in this case, increase from 4 to 5).
3. In app.c, create a global pointer to a queue and, when the stack gets enabled, create and initialize the queue
  - a. Hint: Use a message size of 4 bytes (room for one uint32\_t) and a queue length of 10 so you can push messages while the thread is blinking without causing the queue to overflow.
4. Add a static variable to the interrupt callback that increments each time the button is pressed. Push the value onto the queue to give the LED thread access to it.
5. In the LED thread, pop the value from the queue to determine how many times to blink the LED.
  - a. Hint: Add a longer delay (e.g. 1 second) after the LED blinks the specified number of times so that you can tell the button press sequences apart.
6. Program your project to the board. Press the button a few times to see how the number of blinks is increased with each press. Note that you can press the button while it is currently blinking, and the new press will be added to the queue (provided that the queue is large enough).

### Exercise - 3.4 (Advanced) Print the Thread Stack Usage

Add a function to determine the amount of stack used by a thread and print it to the UART.

1. Create a new application called ch03\_ex04\_stack\_size using the template in the "templates/CYW920819EVB/ch03" folder.
2. Copy app.c from ch03\_ex01\_semaphore.
3. Configure the debug uart to output to the PUART.
  - a. Hint: See exercise 2 from the peripherals chapter if you need a reminder.
4. Add a function to calculate the max stack used by the LED thread.
5. Call the stack size function and print the value to the UART each time the LED is toggled (i.e. whenever the semaphore get function returns).