INTERFACING HOPERF RFM95W WITH ESP32

Schematic Diagram: