


IoT Starter Kit – Part 3b:

How to connect to Microsoft Azure


In this part, we will connect an IQRF gateway to Microsoft Azure. Microsoft Azure offers free services for developers for a limited time and in a limited amount. You will be asked to enter your credit card details. Your credit card will be used only if you exceed the services provided free of charge. It is one of the possible clouds that you can get connected to from your IQRF Gateway Daemon using the MQTT channel.

Microsoft Azure virtual device

First, log in to your Microsoft Azure account on <u>portal.azure.com</u>. Click on the **New item** in the left menu, go to the **Internet of Things** and select **IoT Hub**.




Setup the IoT Hub name and your pricing model. As a developer you can create one IoT Hub for free.




1



Set up a name of your **Resource group**. Click on the **Create** button.




In the **IoT Hub** find the **IoT Devices** item. Click on the **Add** button and create your new IoT device. This virtual device represents your UP board.



2




Copy the **Connection string primary key**. It will be used in the MQTT interface configuration.




Set the MQTT interface in the IQRF Gateway

Go to the IQRF Gateway Daemon web application, find **Clouds** and select **Microsoft Azure** in the menu.




Add a new MQTT interface. Paste here the connection string which you copied before and save the configuration.






Restart the IQRF Gateway Daemon service.



Use Device Explorer for MQTT connection test


In the IoT Hub find the Shared access policies menu. Copy the Connection string primary key for the iothubowner.




4



Insert this string into the connection information in **Device Explorer** application. We will use this application for sending DPA packets to our IQRF network. Click on the **Update** button.




In the Management tab we can see our virtual device that we've just set up.




5



In the **Data** tab, click on **Monitor**. This will enable you to read received events.




Go to the **Messages To Device** tab, insert a DPA packet in JSON format into the **Message** textbox and click on **Send**. We've just sent a command for turning on the red LED on the IQRF coordinator.




6



In the **Data** tab, you can see the incoming communication from the UP board. You can easily double check that the command has been executed.





In the same way, you can turn the red LED off as well as send any other DPA command to your network.