Ve.Can to See Level N2K sensor system

120
ohm

1

2

3

4

V -

CAN H

CAN L

1
2
3
4
5
6
7
8

RJ-45

3M 37104-2165-000 FL 100

Use twisted pair for CAN H and CAN L
Terminate both ends of the CAN
cable network
SeeLevel could be off a CAN stub
in which case the termination
would be elsewhere