ESO201A: THERMODYNAMICS 2021-22 Ist semester IIT Kanpur

Instructor: P.A.Apte

Lecture 25

Copyright: The instructor of this course (ESO201A) owns the copyright of all the course materials. The lecture material was distributed only to the students attending the course ESO201A of IIT Kanpur, and should not be distributed in print or through electronic media without the consent of the instructor. Students can make their own copies of the course materials for their use.

GAS POWER CYCLES

The devices or systems used to produce a net power output are often called *engines*, and the thermodynamic cycles they operate on are called *power cycles*.

Thermodynamic cycles can also be categorized as *gas cycles* and *vapor cycles*, depending on the *phase* of the working fluid. In gas cycles, the working fluid remains in the gaseous phase throughout the entire cycle, whereas in vapor cycles the working fluid exists in the vapor phase during one part of the cycle and in the liquid phase during another part.

Heat engines are categorized as *internal combustion* and *external combustion engines*, depending on how the heat is supplied to the working fluid. In external combustion engines (such as steam power plants), heat is supplied to the working fluid from an external source such as a furnace, a geothermal well, a nuclear reactor, or even the sun. In internal combustion engines (such as automobile engines), this is done by burning the fuel within the system boundaries.

BASIC CONSIDERATIONS IN THE ANALYSIS OF POWER CYCLES

A simple idealized model enables engineers to study the effects of the major parameters that dominate the cycle without getting bogged down in the details. The cycles discussed in this chapter are somewhat idealized, but they still retain the general characteristics of the actual cycles they represent.

The conclusions reached from the analysis of ideal cycles are also applicable to actual cycles. The thermal efficiency of the Otto cycle, the ideal cycle for spark-ignition automobile engines, for example, increases with the compression ratio. This is also the case for actual automobile engines. The numerical values obtained from the analysis of an ideal cycle, however, are not necessarily representative of the actual cycles, and care should be exercised in their interpretation. The simplified analysis presented in this chapter for various power cycles of practical interest may also serve as the starting point for a more in-depth study.

Heat engines are designed for the purpose of converting thermal energy to work, and their performance is expressed in terms of the **thermal efficiency** η_{th} , which is the ratio of the net work produced by the engine to the total heat input:

$$\eta_{ ext{th}} = rac{W_{ ext{net}}}{Q_{ ext{in}}} \quad ext{or} \quad \eta_{ ext{th}} = rac{w_{ ext{net}}}{q_{ ext{in}}}$$



An automotive engine with the combustion chamber exposed.

The idealizations and simplifications commonly employed in the analysis of power cycles can be summarized as follows:


- The cycle does not involve any friction. Therefore, the working fluid does not experience any pressure drop as it flows in pipes or devices such as heat exchangers.
- All expansion and compression processes take place in a quasiequilibrium manner.
- **3.** The pipes connecting the various components of a system are well insulated, and *heat transfer* through them is negligible.

Neglecting the changes in *kinetic* and *potential energies* of the working fluid is another commonly utilized simplification in the analysis of power cycles.

Ref. Cengel and Boles, 8th Edition (2015)

THE CARNOT CYCLE AND ITS VALUE IN ENGINEERING

$$\eta_{\text{th,Carnot}} = 1 - \frac{T_L}{T_H}$$



Thermal efficiency increases with an increase in the average temperature at which heat is supplied to the system or with a decrease in the average temperature at which heat is rejected from the system. Why is Carnot cycle not used as ideal cycle for SI and CI engines?

Due to hard-ware (equipment design) limitations, actual cycles deviate from Carnot cycle significantly.

Unlike the Carnot cycle, the ideal cycles used for SI and CI engines are only internally reversible.

There can be irreversibilities external to the system. For example, heat transfer can occur through finite temerature difference.

As a result the thermal efficiencies of ideal cycles is lower than that of Carnot cycle.


AIR-STANDARD ASSUMPTIONS

The actual gas power cycles are rather complex. To reduce the analysis to a manageable level, we utilize the following approximations, commonly known as the **air-standard assumptions**:

- The working fluid is air, which continuously circulates in a closed loop and always behaves as an ideal gas.
- 2. All the processes that make up the cycle are internally reversible.
- The combustion process is replaced by a heat-addition process from an external source (Fig. 9–8).
- 4. The exhaust process is replaced by a heat-rejection process that restores the working fluid to its initial state.


Another assumption that is often utilized to simplify the analysis even more is that air has constant specific heats whose values are determined at *room temperature* (25°C, or 77°F). When this assumption is utilized, the air-standard assumptions are called the **cold-air-standard assumptions**.

AN OVERVIEW OF RECIPROCATING ENGINES



The piston reciprocates in the cylinder between two fixed positions called the **top dead center** (TDC)—the position of the piston when it forms the smallest volume in the cylinder—and the **bottom dead center** (BDC)—the position of the piston when it forms the largest volume in the cylinder. The distance between the TDC and the BDC is the largest distance that the piston can travel in one direction, and it is called the **stroke** of the engine. The diameter of the piston is called the **bore**. The air or air—fuel mixture is drawn into the cylinder through the **intake valve**, and the combustion products are expelled from the cylinder through the **exhaust valve**.


Ref. Cengel and Boles, 8th Edition (2015)



The minimum volume formed in the cylinder when the piston is at TDC is called the **clearance volume**The volume displaced by the piston as it moves between TDC and BDC is called the **displacement volume**. The ratio of the maximum volume formed in the cylinder to the minimum (clearance) volume is called the **compression ratio** r of the engine:

$$r = \frac{V_{\text{max}}}{V_{\text{min}}} = \frac{V_{\text{BDC}}}{V_{\text{TDC}}}$$

Ref. Cengel and Boles, 8th Edition (2015)



Another term frequently used in conjunction with reciprocating engines is the **mean effective pressure** (MEP). It is a fictitious pressure that, if it acted on the piston during the entire power stroke, would produce the same amount of net work as that produced during the actual cycle That is,

$$W_{\rm net} = {\rm MEP} \times {\rm Piston~area} \times {\rm Stroke} = {\rm MEP} \times {\rm Displacement~volume}$$

or

$$MEP = \frac{W_{\text{net}}}{V_{\text{max}} - V_{\text{min}}} = \frac{w_{\text{net}}}{v_{\text{max}} - v_{\text{min}}}$$
 (kPa)

The mean effective pressure can be used as a parameter to compare the performances of reciprocating engines of equal size. The engine with a larger value of MEP delivers more net work per cycle and thus performs better.

Reciprocating engines are classified as **spark-ignition** (**SI**) **engines** or **compression-ignition** (**CI**) **engines**, depending on how the combustion process in the cylinder is initiated. In SI engines, the combustion of the air–fuel mixture is initiated by a spark plug. In CI engines, the air–fuel mixture is self-ignited as a result of compressing the mixture above its self-ignition temperature.