

Ground recovery authorization and preparation

SIM-SOP-REC-R1 | Revision 1 | SOP

Operator SIM-AIR | ALL | ALL | Station ALL

Status ACTIVE | Trust TRUSTED | Effective 2026-09-01 to 2027-09-01

1. Scope

SIMULATION ONLY. Original fictional planning document. Not an OEM manual, approved MEL, maintenance instruction, flight-safety assessment or release authorization. Ground workflow activation is an operator-configured application authorization, not a universal aviation message field.

2. Authorization

Accept an event only from the trusted simulator adapter in the demo. A current MCC authorization enables read-only planning. Missing, expired or revoked authorization suspends new planning and prevents preparation writes.

3. Human review

An MCC reviewer approves a specific plan hash and case version. Approval covers only draft work order, simulated notifications and a reversible component hold. No purchase, shipment booking, tail swap or aircraft release is executed.

4. Change handling

Destination changes, revoked permission or a new event version invalidate existing recommendations. Release unused local holds and require new planning. No advice is sent to the flight crew.