


Analog USB TV Tuner

TV110 User Manual

INTRODUCTION

This analog USB TV tuner can connect to your laptop or desktop computer in order to enable you to watch and record TV programs.



REMOTE CONTROLLER



- 1. ON/ OFF button
- 2. Mute button
- 3. Numeric buttons to switch channels
- 4. Return to previous channel
- 5. Change the screen display
- 6. Previous / next channel
- 7. Increase / decrease volume
- 8. Input source (DTV, ATV, AV, etc.)
- 9. Screenshot button
- 10. Recording

INSTALLATION

Before using the analog USB TV tuner, ensure the device with which you would like to use it has Windows 7, 8 or 10 installed." Once connected, insert the installation disk into your computer. At this stage, click "autorun.exe" if necessary, and an installation window will appear.



The installation interface includes 4 options:

- ▼ Directx 9.0: click to intall Directx 9.0 on your computer
- ▼ Install: click to install the software and start using the TV tuner
- ▼ Browse CD: click to preview the CD content
- Exit: click to exit the software installation window

TECHNICAL SPECIFICATIONS

- ¥ Video record format: MPEG1/2, VCD DVD
- ▼ Compatibility: Windows 7 / 8 / 10
- ➡ Dimensions: 8.8 X 2.7 X 0.8cm(L x W x H)
- Net weight: 66g

FEATURES

- ▼ Enables your computer to receive TV signal
- Connects to your DVD player or game console
 10-bit video decoder for vivid image
- + 10-bit video decoder for vivia in
- * SDR, DAB and FM support
- * Record scheduler and screenshot support
 - ▼ PAL I, PAL-BG, PAL-DK, SECAM and NTSC support

PACKAGE CONTENT

- ▼ 1 x USB TV Tuner
- ▼ 1 x Installation disk
 - ¥ 1 x antenna
 - ¥ 1 x mini USB to A/V adapter
- # 1 x USB cable
- # 1 x remote controller