ISA/IEC 62443-3-3 / 4-2 • SL-3 TESTING CHEAT SHEET

Schneider Electric PowerLogic PM5560 Power Meter (PM5500 series) · Component type: **Embedded Device (EDR) - power meter** · Target SL = SL 3

Where to work	The embedded **web server** (browse the meter IP; log in) - **Settings › Security / User Accounts** (accounts + permissions, account **lockout policy**, passwords); the meter **front-panel display** (setup **passcode** lock); **ION Setup** for config/firmware. Default web users **Web Master** + **Product Master** - change the defaults.
Ports / paths	Modbus/**TCP 502** (+ RTU); **EtherNet/IP 44818**; **BACnet/IP UDP 47808**; **HTTP 80** (web server); **SMTP 25** (email on alarms); **SNMP 161**; NTP/SNTP 123. Web is HTTP (no built-in HTTPS on most firmware) - front with a TLS proxy or segment.
Notes	EDR - power meter, PowerLogic PM5560 (PM5500 series). Confirm firmware and that the **default Web Master / Product Master passwords** were changed and the **account lockout policy** is set. The web server is HTTP - rely on segmentation + upstream TLS for confidentiality. No secure-boot published - those rows route to compensating provenance controls. Patch the PM5560 firmware CVEs.
How to read	Default read-only (web read-only account, front-panel, read-only Modbus/BACnet). Each row = native step-by-step (web / front panel) + command-level external-tool validation + pass. Write/exploit tools = isolated env + written authorization.

FR 1 — Identification & Authentication Control (IAC)

Req (3-3 / 4-2)	Requirement	Where & how to verify (native steps + Ext. tools)	Pass criteria / evidence	Notes / firmware
SR/CR 1.1	Human user identification & auth	Confirm every access path authenticates: the **web server** requires login (change the default **Web Master** / **Product Master** passwords); the **front panel** setup is gated by the **passcode**. In **Settings › Security / User Accounts** confirm named accounts with permissions - not just the shared defaults. **Test:** browse the meter web without creds -> login required; attempt a front-panel setup change without the passcode -> denied. **Ext. tools:** Web browser to `http://<ip>` (login prompt; confirm defaults changed); `nmap -p 80,502,44818 <ip>` (services in scope).	Web + front-panel authenticate; default passwords changed; named accounts in use.	
SR/CR 1.2	Software process / device identification	Confirm a unique device identity: unique **IP**, Modbus unit ID, BACnet Device instance, and meter serial; each meter distinct on the network. **Ext. tools:** `nmap --script modbus-discover -p 502 <ip>`; `nmap -sU -p 47808 --script bacnet-info <ip>`; web device info.	Unique IP + Modbus/BACnet ID + serial; no reuse.	
SR/CR 1.3	Account management	In **Settings › Security / User Accounts** review accounts + permissions - least privilege, named users, remove/rename the default Web Master/Product Master where possible, no shared logins. **Ext. tools:** Web (user-account/permission review); credential-custody record.	Named, least-privilege accounts; defaults changed; no shared logins.	
SR/CR 1.4	Identifier management	Confirm unique user identifiers (web accounts) and a unique device identity (IP/Modbus/BACnet ID/serial); no reuse across meters. **Ext. tools:** Web account list; `nmap --script modbus-discover -p 502`; inventory.	Unique user and device identifiers; no reuse.	
SR/CR 1.5	Authenticator management	Set strong, complex passwords for all web accounts and the front-panel passcode (per the Schneider cybersecurity best practice); change all defaults; store in the credential vault. **Ext. tools:** Web (password policy / accounts); confirm defaults replaced.	Strong non-default passwords/passcode set; policy applied.	
SR 1.6	Wireless access management	**N/A.** Wired meter with no native wireless interface. **Ext. tools:** Confirm no wireless module.	N/A - justification recorded (wired device).	N/A
SR/CR 1.7	Strength of password-based authentication	Confirm the password-strength policy (length/complexity/lifetime) meets SL-3. **Steps:** for this product this is assessed with the same evidence as **SR/CR 1.5** above (shared steps); confirm this requirement individually and adjudicate it separately.	Strength of password-based authentication verified individually.	

Req (3-3 / 4-2)	Requirement	Where & how to verify (native steps + Ext. tools)	Pass criteria / evidence	Notes / firmware
SR/CR 1.8	Public key infrastructure (PKI) certificates	**N/A / limited.** The PM5560 web server is HTTP (no built-in device TLS on most firmware). Record N/A; provide confidentiality/integrity via segmentation and a TLS reverse proxy / TLS at the SCADA layer. If the installed firmware offers HTTPS, verify it. **Ext. tools:** `nmap -p 443 <ip>` (closed on HTTP-only firmware); if HTTPS: `testssl.sh https://<ip>`.	N/A/limited device PKI; compensating TLS/segmentation upstream.	N/A/Partial.
SR/CR 1.9	Strength of public key-based authentication	Confirm public-key authentication uses strong, current keys/algorithms. **Steps:** for this product this is assessed with the same evidence as **SR/CR 1.8** above (shared steps); confirm this requirement individually and adjudicate it separately.	Strength of public key-based authentication verified individually.	
SR/CR 1.10	Authenticator feedback	Confirm the web login and front-panel passcode entry mask the secret (no cleartext echo). **Ext. tools:** Visual verification; note HTTP transmits the login in cleartext -> segment / TLS-proxy.	Authenticators obscured at entry; HTTP login compensated by segmentation.	
SR/CR 1.11	Unsuccessful login attempts	The PM5560 supports an **account lockout policy** - in Settings › Security confirm it is enabled (lockout threshold/duration) so repeated failed web logins lock the account; monitor via the event log / SCADA. **Test:** exceed the failed-login threshold (authorized) -> account locks per policy. **Ext. tools:** Web (lockout-policy config); Hydra (ISOLATED, authorized) to confirm lockout engages.	Account lockout policy enabled and effective; failures logged.	
SR/CR 1.12	System use notification	No native banner; enforce the approved use notice on the ION Setup/EWS (GPO) and any SCADA front-end (compensating). **Ext. tools:** EWS GPO / SCADA banner review.	Use notice at EWS/SCADA (compensating at meter).	Compensating.
SR 1.13	Access via untrusted networks	Segment the meter; firewall **80/502/44818/47808/25/161**; remote access via VPN/jump host; no direct meter access from untrusted networks. **Test:** from an untrusted VLAN, reach the web/502 -> must fail. **Ext. tools:** `nmap -Pn -p 80,502,44818,47808,25,161 <ip>` from the untrusted side (expect filtered); firewall review.	Untrusted-network access denied; remote via VPN.	

FR 2 — Use Control (UC)

Req (3-3 / 4-2)	Requirement	Where & how to verify (native steps + Ext. tools)	Pass criteria / evidence	Notes / firmware
SR/CR 2.1	Authorization enforcement	Confirm per-account **permissions** (read vs configure vs reset) follow least privilege; the front-panel passcode restricts local setup. A read-only web user cannot change configuration or reset energy. **Test:** as a read-only user, attempt a config change / energy reset -> denied. **Ext. tools:** Web (permission review); attempt a privileged action as a read-only user (isolated).	Least privilege enforced; privileged actions denied.	
SR/CR 2.2	Wireless use control	**N/A.** No wireless interface. **Ext. tools:** Confirm no wireless.	N/A - justification recorded.	N/A
SR/CR 2.3	Use control for portable/mobile devices	Control the ION Setup laptop and any optical/serial config head; removable-media policy on the EWS; only authorized templates/firmware loaded. **Ext. tools:** EWS removable-media policy; physical inspection of the config port.	Portable/engineering media controlled.	
SR/EDR 2.4	Mobile code	No general-purpose mobile code; confirm only the meter firmware/config run and the web content is vendor read-only. **Ext. tools:** Web review (vendor content only); ION Setup config review.	Only trusted firmware/config runs; no untrusted mobile code.	EDR-specific.
SR/CR 2.5	Session lock	Confirm the web session and the front panel return to a login/locked state after inactivity (web session timeout; front-panel passcode re-prompt). **Ext. tools:** Web/front-panel idle test.	Sessions revert to login on inactivity.	
SR/CR 2.6	Remote session termination	Confirm web sessions can be ended and idle sessions close; the meter bounds concurrent web/Modbus connections so simultaneous conflicting configuration is prevented. **Ext. tools:** Web session review; Wireshark (session teardown / connection count).	Sessions terminable; concurrency bounded.	

Req (3-3 / 4-2)	Requirement	Where & how to verify (native steps + Ext. tools)	Pass criteria / evidence	Notes / firmware
SR/CR 2.7	Concurrent session control	Confirm concurrent sessions are bounded/limited and monitored. **Steps:** for this product this is assessed with the same evidence as **SR/CR 2.6** above (shared steps); confirm this requirement individually and adjudicate it separately.	Concurrent session control verified individually.	
SR/CR 2.8	Auditable events	The meter keeps an **alarm/event log** but has **no native syslog**. Capture setup changes and attribution via the web/ION Setup and log meter/comms events at the SCADA + a network IDS; forward to the SIEM. Named accounts give per-user attribution. **Ext. tools:** Web/ION Setup (event log / change review); SCADA/IDS/SIEM on the meter segment.	Setup changes attributable (named accounts); events captured off-device.	No native syslog - Compensating.
SR/CR 2.9	Audit storage capacity	The on-meter event log is finite - offload to the SCADA/SIEM for retention and confirm alerting if collection fails. **Ext. tools:** SCADA/SIEM retention + source-silent alert.	Events offloaded/retained; audit-failure alerting defined.	
SR/CR 2.10	Response to audit processing failures	Confirm a defined response to audit-processing/forwarding failures (alerting; no silent loss). **Steps:** for this product this is assessed with the same evidence as **SR/CR 2.9** above (shared steps); confirm this requirement individually and adjudicate it separately.	Response to audit processing failures verified individually.	
SR/CR 2.11	Timestamps	Confirm the meter clock is synced (NTP/SNTP) so event-log timestamps are accurate and correlate. **Ext. tools:** Web (time/NTP config); `nmap -sU -p 123` / Wireshark `ntp`.	Reliable, synchronized timestamps (NTP/SNTP).	
SR/CR 2.12	Non-repudiation	Confirm actions are attributable to a specific user (non-repudiation). **Steps:** for this product this is assessed with the same evidence as **SR/CR 2.8** above (shared steps); confirm this requirement individually and adjudicate it separately.	Non-repudiation verified individually.	
EDR 2.13	Physical diagnostic & test interfaces	Control physical interfaces: lock the enclosure / secure the DIN-rail unit; engage anti-tamper seals; secure the optical/serial port; set the front-panel **passcode**; disable the web server if unused. **Ext. tools:** Physical inspection (enclosure/seal); web/front panel (passcode set; disable web if unused); `nmap -p 80 <ip>`.	Enclosure/port controlled; passcode set; web disabled if unused.	EDR-specific.

FR 3 — System Integrity (SI)

Req (3-3 / 4-2)	Requirement	Where & how to verify (native steps + Ext. tools)	Pass criteria / evidence	Notes / firmware
SR/CR 3.1	Communication integrity	Modbus/EtherNet-IP/BACnet and the web are **unauthenticated cleartext** (HTTP) - so integrity/confidentiality come from **containment**: disable unused protocols, keep the meter in a segmented zone, front the web with a TLS reverse proxy, and terminate TLS at the SCADA layer. No cleartext across a zone boundary. **Test:** confirm Modbus/EtherNet-IP/BACnet/web stay in-zone. **Ext. tools:** Wireshark `modbus || enip || bacnet || http` (cleartext, in-zone only); firewall review.	Control comms contained/segmented; unused protocols disabled; no crossing the boundary.	HTTP - Compensating.
SR/EDR 3.2	Protection from malicious code (component)	Confirm only Schneider firmware runs and there is no code path beyond the configuration. Patch the PM5560 firmware CVEs; obtain firmware from Schneider and verify provenance (no signed-boot guarantee published - provenance discipline is the control). **Ext. tools:** ION Setup/web (firmware version); Schneider provenance/hash; Schneider SEVD advisory.	Only vendor firmware runs; CVE-patched; provenance verified.	EDR-specific/Partial.
SR/CR 3.3	Security functionality verification	After any change re-verify: default passwords changed, lockout policy on, permissions, disabled protocols (EtherNet-IP/BACnet/SNMP/SMTP as unused), passcode, and firmware, against the hardening baseline; compare the ION Setup config. **Ext. tools:** Web/ION Setup (settings vs baseline); `nmap -p 80,502,44818,47808,161,25 <ip>` (only required reachable).	Security-relevant settings match the baseline after change.	
SR/CR 3.4	Software & information integrity	Archive the ION Setup configuration/template, enable change control, and rely on the accounts + lockout + passcode so unauthorized config/firmware change is detected. Compare online-vs-saved. **Ext. tools:** ION Setup (save/compare configuration); change-management record.	Config integrity controlled; unauthorized change detected.	

Req (3-3 / 4-2)	Requirement	Where & how to verify (native steps + Ext. tools)	Pass criteria / evidence	Notes / firmware
SR/CR 3.5	Input validation	Confirm the meter tolerates malformed Modbus/EtherNet-IP/BACnet frames and web requests without malfunction. **ISOLATED only:** fuzz the interfaces on a bench meter and watch measurement/comms. **Ext. tools:** Protocol fuzzer (`boofuzz`) + web fuzz on a bench meter; Wireshark; watch the event log.	No malfunction on malformed input.	Do NOT fuzz an in-service meter.
SR/CR 3.6	Deterministic output	Confirm defined behavior of any control/alarm relays and data outputs on comm loss (defined/last-known state), and that measurement continues; primarily a measurement device. **Ext. tools:** Web/ION Setup (relay/output + comm-loss behavior); simulate comm loss -> defined state.	Outputs/data assume a defined state on comm loss; measurement continues.	
SR/CR 3.7	Error handling	Confirm graceful diagnostics/status handling without info leak; review meter self-diagnostics / status. **Ext. tools:** Web/front-panel (diagnostics/status review).	Graceful error handling; no unsafe state or info leak.	
SR/CR 3.8	Session integrity	**N/A / limited.** No secured (authenticated/encrypted) session (cleartext protocols + HTTP); integrity provided by containment. Record N/A + compensating segmentation (or a TLS reverse proxy for the web). **Ext. tools:** Wireshark (confirm in-zone containment).	N/A/limited at device; compensating segmentation/proxy recorded.	N/A/Partial.
SR/CR 3.9	Protection of audit information	Since audit is off-device, protect the SCADA/SIEM store and the config records; restrict who can clear the on-meter event log (account permissions). **Ext. tools:** SCADA/SIEM access review; confirm clearing the log requires privilege.	Audit records protected from unauthorized read/modify/delete.	
EDR 3.10	Support for updates	Update firmware via ION Setup / DLF with firmware from Schneider; verify version/provenance; plan a maintenance window with rollback; apply the CVE-fix firmware. (No on-meter signature verification - provenance discipline is the control.) **Ext. tools:** ION Setup (firmware update); Schneider provenance/version + SEVD advisory.	Controlled updates from a verified source, CVE-patched, with rollback.	EDR-specific/Partial.
EDR 3.11	Physical tamper resistance/detection	Keep the meter in a locked panel / secure the DIN-rail unit; engage anti-tamper seals; the event log records setup changes as tamper evidence; verify seals intact. **Ext. tools:** Physical inspection (lock/seals); web/ION Setup event-log review.	Enclosure/seals engaged; interfaces controlled; changes logged.	EDR-specific.
EDR 3.12	Provisioning product-supplier roots of trust	**Partial/N-A at device.** No signed-boot supplier root of trust published. Record the gap; compensate via firmware-provenance discipline (3.10), CVE patching, physical control, and segmentation. **Ext. tools:** Confirm no secure-boot/signed-firmware root; provenance review.	No documented supplier RoT; compensating controls recorded.	Partial/N-A.
EDR 3.13	Provisioning asset-owner roots of trust	**Partial/N-A at device.** No asset-owner certificate provisioning (HTTP, no device PKI). Record the gap; asset-owner trust enforced at the SCADA/network layer and by segmentation. **Ext. tools:** Confirm no device certificate capability; segmentation review.	No asset-owner RoT; compensating controls recorded.	Partial/N-A.
EDR 3.14	Integrity of the boot process	**Partial/N-A at device.** No published verified/secure boot. Record the gap; mitigate via firmware provenance (3.10), CVE patching, physical control, and monitoring. **Ext. tools:** Confirm no secure-boot capability; firmware version.	No documented verified boot; compensating controls recorded.	Partial/N-A.

FR 4 — Data Confidentiality (DC)

Req (3-3 / 4-2)	Requirement	Where & how to verify (native steps + Ext. tools)	Pass criteria / evidence	Notes / firmware
SR/CR 4.1	Information confidentiality	Confirm information confidentiality — sensitive data is protected in transit and at rest. **Steps:** for this product this is assessed with the same evidence as **SR/CR 3.1** above (shared steps); confirm this requirement individually and adjudicate it separately.	Information confidentiality verified individually.	
SR/CR 4.2	Information persistence	On decommission/repurpose, reset the meter configuration to defaults and clear user accounts (web / ION Setup) so configuration/credentials are not recoverable. **Ext. tools:** Web/ION Setup (reset config / clear accounts).	Config and credentials purged on decommission.	
SR/CR 4.3	Use of cryptography	**N/A / limited.** No native comms crypto (cleartext protocols, HTTP web). Disable unused services; use a TLS reverse proxy for the web and TLS at the SCADA layer; segment. **Ext. tools:** Confirm no device crypto; TLS proxy / segmentation review.	N/A/limited; compensating TLS/segmentation upstream.	N/A/Partial.

FR 5 — Restricted Data Flow (RDF)

Req (3-3 / 4-2)	Requirement	Where & how to verify (native steps + Ext. tools)	Pass criteria / evidence	Notes / firmware
SR/CR 5.1	Network segmentation	Primary control. Confirm the meter sits in a segmented metering/OT zone behind a firewall; only required protocols cross (Modbus 502 / BACnet 47808 / EtherNet-IP 44818 to authorized head-ends); the web/SMTP/SNMP are blocked at the boundary; no flat convergence with IT; VPN for cross-zone. **Ext. tools:** `nmap -p 80,502,44818,47808,25,161 <ip>` per zone; firewall rule review.	Meter in a segmented zone; only required flows cross the boundary.	
SR 5.2	Zone boundary protection	Confirm zone-boundary protection — only required flows cross the boundary (system SR / network device). **Steps:** for this product this is assessed with the same evidence as **SR/CR 5.1** above (shared steps); confirm this requirement individually and adjudicate it separately.	Zone boundary protection verified individually.	
SR 5.3	General-purpose person-to-person comms restrictions	Largely **N/A**, but the meter can send **SMTP email (port 25)** on alarms; if unused disable it, or restrict SMTP so the meter originates no general-purpose messaging. **Ext. tools:** Web (email/SMTP config) - confirm disabled/restricted.	N/A / SMTP email disabled or restricted.	N/A
SR 5.4	Application partitioning	**N/A.** Single-purpose meter; no separable applications to partition. **Ext. tools:** Confirm single-function device.	N/A - justification recorded.	N/A

FR 6 — Timely Response to Events (TRE)

Req (3-3 / 4-2)	Requirement	Where & how to verify (native steps + Ext. tools)	Pass criteria / evidence	Notes / firmware
SR/CR 6.1	Audit log accessibility	Confirm the on-meter alarm/event log is readable/exportable (web / ION Setup) and forwarded to the SCADA/SIEM; a passive OT IDS (Modbus/BACnet-aware) on the metering segment gives continuous monitoring (no native syslog). **Ext. tools:** Web/ION Setup export; SCADA historian; passive OT IDS (Nozomi/Dragos) on a SPAN.	Events accessible/exportable and monitored in near-real-time.	No native syslog - Compensating.
SR/CR 6.2	Continuous monitoring	Confirm continuous monitoring — events forwarded to and monitored by a SIEM/OT-IDS in near-real-time. **Steps:** for this product this is assessed with the same evidence as **SR/CR 6.1** above (shared steps); confirm this requirement individually and adjudicate it separately.	Continuous monitoring verified individually.	

FR 7 — Resource Availability (RA)

Req (3-3 / 4-2)	Requirement	Where & how to verify (native steps + Ext. tools)	Pass criteria / evidence	Notes / firmware
SR/CR 7.1	Denial-of-service protection	Confirm the meter tolerates Modbus/BACnet/scan floods without losing measurement; the cell firewall rate-limits. Monitor comms while testing. **Ext. tools:** ISOLATED bench: `hping3 --flood -p 502 <ip>` / Modbus/BACnet storm; watch measurement + comms status.	Measurement continues under load; resources bounded.	
SR/CR 7.2	Resource management	Confirm bounded resources (web/Modbus connection limits) so a single service cannot starve the meter. **Ext. tools:** Web/connection review; bench load test.	Resources bounded; no exhaustion-based loss of service.	
SR/CR 7.3	Control system backup	Confirm the ION Setup configuration/template is backed up (versioned, offline) and a restore is tested on a spare meter for a known-good rebuild. **Ext. tools:** ION Setup backup repository; restore test (spare meter).	Backups current and recovery validated.	
SR/CR 7.4	Control system recovery & reconstitution	Confirm recovery/reconstitution — a restore to a known-good state is tested. **Steps:** for this product this is assessed with the same evidence as **SR/CR 7.3** above (shared steps); confirm this requirement individually and adjudicate it separately.	Control system recovery & reconstitution verified individually.	
SR/CR 7.5	Emergency Power	**N/A.** Emergency/backup power is provided at the facility/UPS level, not the device; confirm the device retains its security state across a power transfer.	N/A - justification recorded (not assessed as a control).	N/A

Req (3-3 / 4-2)	Requirement	Where & how to verify (native steps + Ext. tools)	Pass criteria / evidence	Notes / firmware
SR/CR 7.6	Network & security configuration settings	Harden per the PM5500 user manual: change default passwords, enable the lockout policy, set the passcode, and **disable unused protocols** - EtherNet/IP, BACnet, SNMP, SMTP, and the web server if unused - keeping only what is required. **Ext. tools:** Web/front panel (protocol enable-disable); `nmap -sTU -p 80,502,44818,47808,25,161 <ip>` (only required reachable).	Least functionality; unused protocols/services disabled.	
SR/CR 7.7	Least functionality	Confirm least functionality — unused services/ports/protocols are disabled. **Steps:** for this product this is assessed with the same evidence as **SR/CR 7.6** above (shared steps); confirm this requirement individually and adjudicate it separately.	Least functionality verified individually.	
SR/CR 7.8	Component inventory	Confirm the meter (model PM5560, firmware, comms) is inventoried so vulnerabilities track against Schneider SEVD / CISA advisories (PM5560 has CVEs). **Ext. tools:** `nmap --script modbus-discover -p 502`; ION Setup/web inventory; Schneider SEVD feed.	Accurate meter/firmware inventory maintained; advisories tracked.	

External Test Tools — how to use

Tool / method	Verifies	How to use — steps / example	Constraints
Embedded web server (browser)	Native security & config review (all FRs)	Browse http://<ip>; log in (confirm Web Master/Product Master defaults changed); Settings › Security / User Accounts (accounts, permissions, lockout policy); protocol enable/disable; event log; disable the web if unused.	Read-only unless authorized to change.
Front-panel display	Local access & passcode review (1.1, 2.13)	Confirm the setup passcode lock and anti-tamper seals at the meter.	Physical; authorized.
ION Setup	Config, backup & firmware (2.3, 3.3, 3.4, 7.3, 3.10)	Read the configuration, back up/compare the template, and perform controlled firmware updates.	Read/authorized project copy.
nmap	Protocol/port exposure, Modbus/BACnet ID & segmentation (1.x, 3.1, 5.x, 7.6, 7.8)	`nmap -p 80,502,44818,47808,25,161 <ip>`; `nmap --script modbus-discover -p 502`; `nmap -sU -p 47808 --script bacnet-info`; scan per zone.	Read-only; authorized.
Wireshark / tcpdump	Comms integrity & identity (1.2, 3.1, 3.8)	Filter `modbus || enip || bacnet || http`; confirm cleartext stays in-zone; inspect the web login (HTTP cleartext).	Passive; SPAN/tap only.
Hydra	Account-lockout verification (1.11)	Authorized repeated web logins to confirm the account lockout policy engages.	ISOLATED/authorized only.
Protocol fuzzer / hping3	Input validation & DoS resilience (3.5, 7.1)	`boofuzz` Modbus/BACnet + web fuzz on a bench meter; `hping3 --flood -p 502 <ip>` storm; watch measurement + comms.	ISOLATED bench; never in-service.
Passive OT IDS (Modbus/BACnet-aware)	Monitoring (2.8, 6.x) - replaces native syslog	Nozomi/Dragos on a SPAN to capture Modbus/BACnet connection/write and anomalies; forward to the SIEM.	Passive; coordinate with SOC.
Schneider SEVD / CISA advisories	Vuln tracking (3.2, 3.10, 7.8)	Track PM5560 advisories and required firmware.	Reference.

Controlled - Project Use · Independent Assurance Services · ISA/IEC 62443-3-3 / 4-2 · Product-specific companion to the 62443 assessment tool; confirm exact menu paths / CLI against the deployed firmware and the project hardening baseline. ISOLATED tools run only in a representative/lab environment with written authorization.