ISA/IEC 62443-3-3 / 4-2 • SL-3 TESTING CHEAT SHEET

Cisco Catalyst IE3300 Rugged Series Switch (IOS-XE 17.x) · Component type: **Network Device (NDR) - industrial Ethernet switch** · Target SL = SL 3

Where to work	**IOS-XE CLI** via console and **SSHv2**; **HTTPS WebUI** (modern Day-n GUI) / RESTCONF; NETCONF; RADIUS/TACACS+ (ISE); optional **Cisco Cyber Vision** network sensor + Industrial Network Director / DNA Center. Review with `show` commands (read-only); config archive for change tracking.
Ports / paths	**SSH 22**; **HTTPS 443** (WebUI/RESTCONF); **Telnet 23** + **HTTP 80** (must be OFF); **NETCONF 830**; **SNMPv3 161**; RADIUS 1812/1813; TACACS+ 49; NTP 123; Syslog 514. Physical: RJ45/mini-USB **console**, **USB** type-A, **SD flash** card, **Express Setup** button, alarm I/O; DIN-rail/IP30.
Firmware / license	IOS-XE **17.x**. MACsec / advanced features need the **Network Advantage** (DNA) license. Confirm model (IE-3300-xx, base vs expansion) and version with `show version` / `show license summary`.
CLI syntax (IOS-XE — differs from classic IOS)	This is **IOS-XE** (like the Stratix 5800/5200; unlike the classic-IOS IE4010 / Stratix 5400/5700). MACsec verify = `show macsec interface <if>` / `show macsec summary` + `show mka sessions`. 802.1X = `show access-session` (current) **or** `show authentication sessions` (legacy alias — both work). Boot/image trust adds Trust-Anchor `show platform hardware authentication status` / `show platform software integrity` on top of `show software authenticity running`. Ring redundancy = `show rep topology` / `show dlr ring` / `show mrp ring` (there is no StackWise here — `show switch` is Catalyst-9300 only). Change audit = `show archive log config all`.
How to read	Default read-only (`show` commands). Each row = native CLI/WebUI step-by-step + command-level external-tool validation + pass. Write/exploit tools = isolated/representative env + written authorization. Never run intrusive tests on a live control ring.

Session setup & evidence handling

Do this BEFORE running any command so the evidence is complete, attributable, and protected:
1. Start a full session log first. PuTTY: Session › Logging → select **All session output** → set **Log file name** (browse to the encrypted evidence folder) → under "if the log file already exists" pick **Always append** → tick **Include header** and (Logging › Options) **Flush log frequently**; put `&Y&M&D_&T` in the name for an auto timestamp. (SecureCRT: File › Log Session; Tera Term: File › Log; macOS/Linux: `script -a <file>.log` or `ssh user@host | tee <file>.log`.)
2. Name the file to the evidence convention (one file per device): `<site>_<zone>_<assetTag>_<vendor>_<model>_<mgmtIP>_<YYYYMMDD-HHMM>_<testerInitials>.log`.
3. Disable paging so full output is captured (it resets each login): disable paging: `terminal length 0` (also `terminal exec prompt timestamp` to stamp each command); restore with `terminal length 24` when done.
4. Self-document the log - capture identity/time first: `show clock` then `show version`, so the file proves what/when/who.
5. Close out: restore paging, stop the log (PuTTY closes it when the session ends), and verify the file opened/saved.
6. Protect the evidence file. It contains running-config and may hold hashes, SNMP community strings, or keys: store **only** on the encrypted assessment share, follow the project data-classification/retention policy, redact secrets before sharing, and **never** email it in cleartext. **Do not save the device password in the PuTTY/SecureCRT saved session** - authenticate interactively or via the approved password manager.

FR 1 — Identification & Authentication Control (IAC)

Req (3-3 / 4-2)	Requirement	Where & how to verify (native steps + Ext. tools)	Pass criteria / evidence	Notes / license
SR/CR 1.1	Human user I&A	Confirm AAA is on: `show run | sec aaa` shows `aaa new-model` + `aaa authentication login default group tacacs+ local`. SSH-only: `show ip ssh` (v2); lines use `transport input ssh` with **no** `transport input telnet`; `no ip http server` + `ip http secure-server`. **Test:** console/SSH/WebUI without creds -> denied; Telnet/HTTP refused. **Ext. tools:** `ssh -v admin@<sw>`; `nmap -p 22,23,80,443 <sw>` (only 22/443 answer); RADIUS/TACACS+ test client (ISE).	All mgmt interfaces authenticate; invalid creds rejected; no Telnet/HTTP/anonymous path.	Telnet+HTTP off for SL-3.

Req (3-3 / 4-2)	Requirement	Where & how to verify (native steps + Ext. tools)	Pass criteria / evidence	Notes / license
SR/CR 1.2	Device & software-process I&A	Port authentication: `show authentication sessions` / `show dot1x all` for **802.1X / MAB**; switch-to-switch **MACsec**: `show mka sessions` / `show macsec summary` / `show macsec interface <if>`; SNMP requires v3 auth. **Test:** a rogue endpoint on an 802.1X port lands in the restricted/critical VLAN or is denied. **Ext. tools:** 802.1X test supplicant + rogue device; Wireshark filter `eapol || mka`; ISE live logs.	Only authenticated devices/peers connect; unknown endpoints quarantined; MACsec up on trunks.	MACsec needs Network Advantage.
SR/CR 1.3	Account management	Named accounts + privilege: `show run | sec username|aaa`; AAA-managed identities, distinct privilege levels, **no shared/default** accounts (no bare `username cisco`). **Ext. tools:** TACACS+/ISE account export; `show users`.	Individually attributable, least-privilege, lifecycle-managed accounts; no shared logins.	
SR/CR 1.4	Identifier management	Confirm unique user identifiers (`show run | incl username`) and a unique device identity (hostname, SUDI/serial from `show version` / `show platform sudi certificate`); no reuse across switches. **Ext. tools:** Config review; `show platform sudi certificate`; asset inventory.	Unique user and device identifiers; no reuse.	
SR/CR 1.5	Authenticator management	`service password-encryption` on; secrets type 8/9: `enable secret` and `username x privilege 15 secret` - **no** type-0/7 (`show run | incl secret|password`). Manage SSH keys/certs. **Ext. tools:** Config grep for weak hash types; `ssh-audit <sw>`.	Strong password hashes; no cleartext/type-7; keys/certs rotate.	
SR/NDR 1.6	Wireless access management	**N/A.** Wired industrial switch with no native wireless interface; wireless is managed at the network layer. **Ext. tools:** Confirm no WLAN interface on the platform.	N/A - justification recorded (wired network device).	N/A
SR/CR 1.7	Strength of password auth	Verify the configured policy with `show running-config | include security passwords` (shows `security passwords min-length`) and `show running-config | section aaa` (any `aaa common-criteria policy` with min-length/complexity/lifetime). Enforce a strong policy locally (`security passwords min-length 14` + `aaa common-criteria policy`) or via ISE/AAA. **Ext. tools:** `show running-config | include security passwords`; `show running-config | section aaa`; ISE/AAA policy screenshot.	Configurable strong password policy enforced (local or AAA).	
SR/CR 1.8	Public key infrastructure (PKI) certificates	`show crypto pki certificates` for CA-signed device certs (WebUI/RESTCONF/802.1X/MACsec); `show ip ssh` for KEX/host-key/cipher strength; strong RSA(>=2048)/ECC; the platform SUDI provides device identity. **Ext. tools:** `sslscan <sw>:443` / `testssl.sh https://<sw>`; `ssh-audit <sw>`.	CA-signed certs, strong keys/ciphers; SUDI present; weak/expired rejected.	
SR/CR 1.9	Strength of public key-based authentication	Confirm public-key authentication uses strong, current keys/algorithms. **Steps:** for this product this is assessed with the same evidence as **SR/CR 1.8** above (shared steps); confirm this requirement individually and adjudicate it separately.	Strength of public key-based authentication verified individually.	
SR/CR 1.10	Authenticator feedback	Confirm password/secret entry is not echoed in cleartext at the CLI or WebUI login, and `service password-encryption` hides stored strings in `show run`. **Ext. tools:** Visual verification (CLI/WebUI); `show run` (no cleartext passwords).	Authenticators obscured during entry and in config.	
SR/CR 1.11	Unsuccessful login attempts	Login throttling: `login block-for 100 attempts 3 within 60` + `login on-failure log`; AAA/ISE lockout. Verify `show login`. **Ext. tools:** Hydra/Medusa (ISOLATED, authorized) to confirm quiet-mode/lockout engages.	Excess failures trigger lockout/quiet-mode and are logged.	
SR/CR 1.12	System use notification	Login banner on all paths: `banner login` / `banner motd` (also on WebUI). Confirm the approved notice at console/SSH/WebUI. **Ext. tools:** Console/SSH; browser (HTTPS); `show run | incl banner`.	Approved system-use banner on all mgmt interfaces.	
SR/NDR 1.13	Access via untrusted networks	Restrict mgmt: `line vty 0 15` with `access-class MGMT in`, management VRF / OOB, `control-plane` protection; SSH-only; MFA via ISE for remote. No mgmt reachable from process/untrusted VLANs. **Test:** from an untrusted VLAN, reach 22/443 -> must fail. **Ext. tools:** `nmap -Pn -p 22,443,161 <sw>` from each VLAN; ACL review.	Mgmt-plane unreachable from untrusted networks; MFA for remote admin.	

FR 2 — Use Control (UC)

Req (3-3 / 4-2)	Requirement	Where & how to verify (native steps + Ext. tools)	Pass criteria / evidence	Notes / license
SR/CR 2.1	Authorization enforcement	Command authorization: `aaa authorization commands 15 default group tacacs+` and/or role-based CLI `parser view`; privilege levels. **Test:** a low-priv user cannot enter config or run privileged clear/show. **Ext. tools:** TACACS+ command-authorization logs; login as a low-priv account.	Least privilege enforced; unauthorized commands denied and logged.	
SR/CR 2.2	Wireless Use Control	**N/A.** No wireless interface on this device; wireless access is managed at the network layer.	N/A - justification recorded (not assessed as a control).	N/A
SR 2.3	Use Control for Portable and Mobile Devices	**N/A.** Device does not host portable/mobile-media use; USB/portable-device use is controlled at the engineering host (EWS).	N/A - justification recorded (not assessed as a control).	N/A
SR/NDR 2.4	Mobile code	No general-purpose mobile code; restrict on-box automation (Guest Shell / Python / EEM / app-hosting IOx) to signed, required apps only - `show app-hosting list`; disable IOx if unused. **Ext. tools:** `show app-hosting list`; confirm no untrusted IOx app; disable if unused.	Only signed/required on-box apps run; IOx disabled if unused.	NDR-specific.
SR/CR 2.5	Session lock / timeout	Idle timeout on all lines: `line con 0` / `line vty 0 15` -> `exec-timeout 10 0`; `service tcp-keepalives-in`. **Ext. tools:** Manual idle test; `show run | sec line`	Idle sessions time out on console and vty.	
SR/CR 2.6	Remote session termination	View/terminate sessions: `show users` + `clear line vty <n>` / `disconnect ssh <n>`; bound concurrent access with `line vty 0 15` + `session-limit` and `ip ssh maxstartups`; idle sessions close via `exec-timeout`. **Ext. tools:** `show users` / `show ssh`; Wireshark (session teardown).	Sessions terminable on demand and on inactivity; concurrency bounded.	
SR/CR 2.7	Concurrent session control	Confirm concurrent sessions are bounded/limited and monitored. **Steps:** for this product this is assessed with the same evidence as **SR/CR 2.6** above (shared steps); confirm this requirement individually and adjudicate it separately.	Concurrent session control verified individually.	
SR/CR 2.8	Auditable events	AAA accounting + config-change logging: `aaa accounting commands 15 default start-stop group tacacs+`; `archive` -> `log config` -> `logging enable / notify syslog`. **Test:** change config -> syslog + `show archive log config all` entry with the username. **Ext. tools:** Syslog server; `show logging`	Login/config/command events logged with user + timestamp.	
SR/CR 2.9	Audit storage capacity	Size + offload logs: `logging buffered <size> informational` plus central `logging host`; confirm behavior if the syslog server is unreachable (local buffer retained, SNMP/health alert) so events are not silently lost. **Ext. tools:** `show logging` (buffer size/use); SIEM source-silent alert.	Logs sized/offloaded; audit-failure alerting defined; events not lost.	
SR/CR 2.10	Response to audit processing failures	Confirm a defined response to audit-processing/forwarding failures (alerting; no silent loss). **Steps:** for this product this is assessed with the same evidence as **SR/CR 2.9** above (shared steps); confirm this requirement individually and adjudicate it separately.	Response to audit processing failures verified individually.	
SR/CR 2.11	Timestamps	`service timestamps log datetime msec localtime show-timezone`; authenticated NTP: `ntp authenticate` + `ntp authentication-key` + `ntp server <ip> key <n>`. **Ext. tools:** Wireshark `ntp`; `show ntp status` / `show ntp associations`	Accurate authenticated time; logs carry synced timestamps.	
SR/CR 2.12	Non-repudiation	AAA command accounting + config archive record the **username** per change; confirm in `show archive log config all` and TACACS+ logs. **Ext. tools:** TACACS+ accounting review.	Every change attributable to a named user.	
NDR 2.13	Physical & diagnostic interfaces	Control physical interfaces: locked cabinet; secure the **console**; disable **USB** (`platform usb disable`); protect/remove the **SD flash**; guard the **Express Setup** button (a long press can factory-reset - restrict physical access); shut unused ports. **Ext. tools:** Physical inspection; `show inventory`; confirm USB disabled + SD access controlled.	Physical/diagnostic interfaces controlled; USB off; Express Setup button protected.	NDR-specific.

FR 3 — System Integrity (SI)

Req (3-3 / 4-2)	Requirement	Where & how to verify (native steps + Ext. tools)	Pass criteria / evidence	Notes / license
SR/CR 3.1	Communication integrity	Mgmt via SSH/HTTPS/SNMPv3 (auth+priv) only; data-plane integrity via **MACsec** on trunks/uplinks; `control-plane` policing. No cleartext mgmt (no Telnet/HTTP/SNMPv1-2c). **Ext. tools:** Wireshark (encrypted mgmt; MACsec on links); `nmap -p 23,80,161 <sw>` (closed).	All mgmt/data integrity-protected; cleartext protocols disabled.	
SR/NDR 3.2	Protection from malicious code	Image authenticity + **secure boot** (Trust Anchor): `show software authenticity running` and `show platform integrity`; load only Cisco-signed IOS-XE from CCO; `verify /md5 flash:<image>`. **Ext. tools:** Signature/hash cross-check vs Cisco.com; `show platform integrity`	Only signed IOS-XE runs; secure-boot/Trust-Anchor integrity intact.	
SR/CR 3.3	Security functionality verification	Compare running-config to the hardened baseline; protect + hash the image; `configure replace` from a trusted archive; detect drift. **Ext. tools:** Config diff vs baseline; RANCID/Oxidized; `verify`	Config matches baseline; image integrity verified; drift detected.	
SR/CR 3.4	Software & information integrity	Confirm software & information (config/program) integrity; unauthorized change prevented/detected. **Steps:** for this product this is assessed with the same evidence as **SR/CR 3.3** above (shared steps); confirm this requirement individually and adjudicate it separately.	Software & information integrity verified individually.	
SR/CR 3.5	Input validation	Confirm the control plane tolerates malformed/oversized frames without instability: CoPP + hardening protect the CPU. **ISOLATED only:** fuzz mgmt/protocol stacks on a bench switch and watch CPU/CoPP drops. **Ext. tools:** Protocol fuzzer (ISOLATED); `show policy-map control-plane` drop counters; `show processes cpu`	No instability on malformed input; CoPP absorbs/blocks.	
SR/CR 3.6	Deterministic output	**N/A.** A switch does not drive a physical process output; deterministic/fail-safe output is a device-layer control. Confirm the configured behavior of ports/links on failure (e.g. UDLD, err-disable) is deliberate. **Ext. tools:** `show udld` / `show interfaces status err-disabled` (defined failure behavior).	N/A - justification recorded (network device).	N/A
SR/CR 3.7	Error handling	Confirm graceful error handling without info leak: `show logging` / crashinfo review; err-disable recovery configured; no sensitive data in banners/SNMP. **Ext. tools:** `show logging`; `show errdisable recovery`	Graceful error handling; no crash-loop or info leak.	
SR/CR 3.8	Session integrity	SSH/TLS protect against hijack/replay; disable weak SSH algos: `ip ssh server algorithm encryption aes256-gcm` / `mac` / `kex` (strong only). **Ext. tools:** `ssh-audit <sw>`; `sslscan <sw>:443`	Strong session crypto; weak algorithms disabled.	
SR/CR 3.9	Protection of audit information	Protect logs: restrict who can `clear logging` (command authorization), send syslog over a protected path/TLS where supported, and lock down the SIEM store. **Ext. tools:** TACACS+ authz on clear-logging; syslog transport review; SIEM access review.	Audit records protected from unauthorized read/modify/delete.	
NDR 3.10	Support for updates	Signed IOS-XE upgrade + rollback via `install add file ... / activate / commit`; verify the rollback path (`install rollback`). **Ext. tools:** Lab upgrade/rollback test; confirm signature enforced.	Signed updates with tested rollback; authenticity enforced.	NDR-specific.
NDR 3.11	Physical tamper resistance/detection	Locked cabinet; control console/USB/SD/Express Setup button; tamper evidence in syslog + `show logging`; seal where required. **Ext. tools:** Physical inspection (locks/seals); `show logging` for unexpected reloads/config changes.	Physical access controlled; tamper logged.	NDR-specific.
NDR 3.12	Provisioning product-supplier roots of trust	Cisco Trust Anchor + SUDI provide the supplier root of trust; the platform runs only Cisco-signed IOS-XE and secure boot rejects unsigned/altered images. **Ext. tools:** `show platform integrity` / `show software authenticity keys`; attempt an unsigned image (isolated) -> rejected.	Supplier root of trust (Trust Anchor/SUDI) intact; unsigned images rejected.	NDR-specific.
NDR 3.13	Provisioning asset-owner roots of trust	Asset owner provisions its own trust: install the enterprise CA for WebUI/RESTCONF/802.1X/MACsec (`crypto pki trustpoint` + enrollment); manage the trust list. **Ext. tools:** `show crypto pki trustpoints` / `show crypto pki certificates`; confirm enterprise CA enrolled, defaults replaced.	Asset-owner CA provisioned and enrolled; trust list managed.	NDR-specific.
NDR 3.14	Integrity of the boot process	Verify measured/secure boot via the Trust Anchor before execution: `show platform integrity` shows boot-stage hashes matching the Cisco known-good; only signed IOS-XE boots. **Ext. tools:** `show platform integrity` (hashes match known-good); `show software authenticity running`	Secure boot verified; only signed IOS-XE boots.	NDR-specific.

FR 4 — Data Confidentiality (DC)

Req (3-3 / 4-2)	Requirement	Where & how to verify (native steps + Ext. tools)	Pass criteria / evidence	Notes / license
SR/CR 4.1	Information confidentiality	SNMPv3 priv (AES), SSH/HTTPS/MACsec; disable SSHv1 + weak ciphers/KEX (`ip ssh server algorithm encryption aes256-gcm`); TLS 1.2/1.3 on WebUI/RESTCONF. **Ext. tools:** `sslscan <sw>:443` / `testssl.sh`; `ssh-audit`; Wireshark.	Modern TLS/SSH ciphers; SNMPv3 priv; weak protocols disabled.	
SR/CR 4.2	Information persistence	On decommission/RMA, wipe config + credentials: `write erase` / `delete /force flash:` (certs/keys, vlan.dat, config), remove/erase the **SD flash**, and clear the startup so nothing sensitive is recoverable. **Ext. tools:** `write erase` + reload; confirm SD removed/sanitized.	Config, keys, and certs purged on decommission or reuse.	
SR/CR 4.3	Use of cryptography	Confirm use of modern cryptography (strong suites, managed keys; weak/legacy disabled). **Steps:** for this product this is assessed with the same evidence as **SR/CR 4.1** above (shared steps); confirm this requirement individually and adjudicate it separately.	Use of cryptography verified individually.	

FR 5 — Restricted Data Flow (RDF)

Req (3-3 / 4-2)	Requirement	Where & how to verify (native steps + Ext. tools)	Pass criteria / evidence	Notes / license
SR/CR 5.1	Network segmentation	VLAN/PVLAN + ACL segmentation and VRFs isolate cell/zone; `show vlan brief`, `show access-lists`, private-VLAN config; unused ports in a black-hole VLAN + `shutdown`. **Ext. tools:** `nmap -sT -p- <host>` across VLANs; ACL review.	Effective segmentation; inter-zone flows restricted to policy.	
SR/NDR 5.2	Zone boundary protection	ACLs / CoPP at boundaries; VTY `access-class`; `show policy-map control-plane`. Only required flows cross the boundary. **Ext. tools:** Nmap at boundary; ACL/CoPP review.	Boundary enforces least-flow; control-plane protected.	
SR/NDR 5.3	General-purpose person-to-person comms restrictions	**N/A.** Network switch with no general-purpose person-to-person messaging. **Ext. tools:** Confirm no such services on the switch.	N/A - justification recorded.	N/A
SR 5.4	Application Partitioning	**N/A.** Single-purpose device; no separable applications to partition (handled at the host/SCADA layer).	N/A - justification recorded (not assessed as a control).	N/A

FR 6 — Timely Response to Events (TRE)

Req (3-3 / 4-2)	Requirement	Where & how to verify (native steps + Ext. tools)	Pass criteria / evidence	Notes / license
SR/CR 6.1	Audit log accessibility	Central syslog: `logging host <server>` + `logging trap informational`; `show logging` readable/exportable by authorized staff. **Ext. tools:** Syslog server; log export.	Logs centralized and accessible/exportable to authorized users.	
SR/CR 6.2	Continuous monitoring	Ship syslog + SNMPv3 traps to the SIEM; **Flexible NetFlow** (`flow monitor`) to a collector; a **Cyber Vision** sensor gives OT asset/flow visibility; monitor CoPP/security counters. **Ext. tools:** Syslog listener (`nc -lu 514`); NetFlow collector; Cyber Vision / SIEM.	Logs/flows/traps monitored; alerting on security events.	

FR 7 — Resource Availability (RA)

Req (3-3 / 4-2)	Requirement	Where & how to verify (native steps + Ext. tools)	Pass criteria / evidence	Notes / license
SR/CR 7.1	Denial-of-service protection	Control-plane policing (CoPP), `storm-control`, `ip dhcp snooping`, dynamic ARP inspection, `spanning-tree bpduguard`, `switchport port-security`. Verify `show policy-map control-plane`. **Ext. tools:** Traffic generator / flood (ISOLATED); `show policy-map control-plane` counters.	Switch stays manageable/forwarding under storm; protections active.	
SR/CR 7.2	Resource management	Monitor `show processes cpu sorted` + `show processes memory sorted` and TCAM (`show platform hardware fed active fwd-asic resource tcam utilization`); enforce rate limits at boundary. **Ext. tools:** SNMP/telemetry monitoring.	CPU/memory/TCAM within bounds under peak; no exhaustion.	
SR/CR 7.3	Control system backup	Config archive: `archive` + `path` + scheduled save; back up via SCP; recover with `configure replace` or reload from archive; test on a spare. **Ext. tools:** SCP backup; `sha256sum` of config; lab restore.	Recent verified config backup; restore/rollback tested.	
SR/CR 7.4	Control system recovery & reconstitution	Confirm recovery/reconstitution — a restore to a known-good state is tested. **Steps:** for this product this is assessed with the same evidence as **SR/CR 7.3** above (shared steps); confirm this requirement individually and adjudicate it separately.	Control system recovery & reconstitution verified individually.	
SR 7.5	Emergency Power	**N/A.** Emergency/backup power is provided at the facility/UPS level, not the device; confirm the device retains its security state across a power transfer.	N/A - justification recorded (not assessed as a control).	N/A
SR/CR 7.6	Network & security config settings	Document + baseline all security settings; capture in the archive; changes via change control (`show archive`). **Ext. tools:** RANCID/Oxidized baseline compare.	Settings documented, baselined, change-controlled.	
SR/CR 7.7	Least functionality	Disable unused services: `no ip http server`, Telnet, `no cdp run` where not needed, `no ip source-route`, `no service pad`; disable unused RESTCONF/NETCONF; `shutdown` unused ports; SNMPv3-only. **Ext. tools:** `nmap -sTU -p- <sw>` (open services); config review.	Only required services/ports enabled; insecure services disabled.	
SR/CR 7.8	Component inventory	`show version`, `show inventory`, `show license summary`, `show module` capture model, IOS-XE version, license, and expansion modules. **Ext. tools:** ReadOnlyEnum; Cyber Vision passive inventory.	Complete model/version/license inventory captured.	

External Test Tools — how to use

Tool / method	Verifies	How to use — steps / example	Constraints
Console / SSH (IOS-XE CLI)	Native config review (all)	Authenticated CLI via console or SSHv2; run `show` commands read-only with a least-privilege account.	Read-only; no changes on production.
WebUI (HTTPS)	Config review via browser (1.1, 4.x)	Browse the WebUI over HTTPS; review users, banner, certificate, and services.	HTTPS only; authorized account.
RADIUS / TACACS+ (ISE)	AAA authn/authz/accounting (1.1, 2.1, 2.8)	Test identities; verify authentication, command authorization, and accounting in server logs.	Test identities; review logs.
nmap	Port/service exposure & segmentation (1.1, 1.13, 5.x, 7.7)	`nmap -sT -p 22,23,80,443,161,830 -T2 <sw>`; scan from each VLAN to prove segmentation; confirm 23/80 closed.	Tune timing on production.
sslscan / testssl.sh	WebUI/RESTCONF TLS strength (1.8, 3.8, 4.3)	`sslscan <sw>:443` / `testssl.sh https://<sw>`; TLS1.2/1.3 only, strong ciphers, valid cert.	Read-only/safe.
ssh-audit	SSH algorithm strength (1.5, 1.8, 3.8, 4.3)	`ssh-audit <sw>`; strong KEX/cipher/MAC; SSHv1/weak algos disabled.	Read-only.

Tool / method	Verifies	How to use — steps / example	Constraints
Wireshark / tcpdump	Comm integrity, MACsec, monitoring (1.2, 3.1, 6.2)	SPAN/tap; confirm mgmt encrypted, MACsec on trunks, EAPOL/MKA on 802.1X ports; inspect NTP.	Passive; SPAN/tap only.
802.1X supplicant / rogue device	Port authentication (1.2)	Present authorized then unauthorized endpoints on an 802.1X/MAB port; confirm grant + rogue quarantine.	Coordinate with NAC team.
Syslog/SIEM + NetFlow + Cyber Vision	Audit & monitoring (2.8, 6.1, 6.2)	Confirm logs/command-accounting/flows arrive; Cyber Vision sensor for OT asset/flow visibility; trigger an event and verify.	Coordinate with SIEM team.
RANCID / Oxidized	Config integrity & drift (3.3, 3.4, 7.6)	Automated config capture; diff running-config vs the hardened baseline.	Read-only.
Hydra / Medusa	Login lockout behavior (1.11)	Authorized repeated SSH/WebUI logins to confirm login-block/quiet-mode engages.	ISOLATED/authorized only.
Traffic generator	DoS resilience (7.1)	Storm/flood to confirm CoPP/storm-control keep the switch manageable/forwarding.	ISOLATED; authorization.
Nessus / OpenVAS	Known-CVE scan (3.2, general)	Authenticated scan for IOS-XE CVEs; cross-check Cisco PSIRT.	ISOLATED/representative; authorization.

Controlled - Project Use · Independent Assurance Services · ISA/IEC 62443-3-3 / 4-2 · Product-specific companion to the 62443 assessment tool; confirm exact menu paths / CLI against the deployed firmware and the project hardening baseline. ISOLATED tools run only in a representative/lab environment with written authorization.