

1) **Dead load:**

- O.W of Concrete (Concrete density = 25 KN/m²)

2) **Live load:**

Live load & O.W. of Concrete = 2.40 KN/m²
ACI 347-06

ACI Committee 347 recommends that both vertical supports and horizontal framing components of formwork be designed for a minimum **live load** of 50 lb/ft² (2.4 kPa) of horizontal projection to provide for weight of workers, runways, screeds, and other equipment.

2.2—Loads

2.2.1 Vertical loads—Vertical loads consist of dead and live loads. The weight of formwork plus the weight of the reinforcement and freshly placed concrete is dead load. The live load includes the weight of the workers, equipment, material storage, runways, and impact.

Vertical loads assumed for shoring and reshoring design for multistory construction should include all loads transmitted from the floors above as dictated by the proposed construction schedule. Refer to **Section 2.5**.

The formwork should be designed for a live load of not less than 50 lb/ft² (2.4 kPa) of horizontal projection. When motorized carts are used, the live load should not be less than 75 lb/ft² (3.6 kPa).

The design load for combined dead and live loads should not be less than 100 lb/ft² (4.8 kPa) or 125 lb/ft² (6.0 kPa) if motorized carts are used.