Document Title: PM_FW Schedule Module design

description of Safety Control System

Document Number: 17-Q04-000618

Project Number: CT-RD-1601

Project Name: First phase of Safety Control System

Development Project

Material Number: N/A

Document Version: A

Classification Level: Highly secret

Document Status: CFC

Controlled Status: Under control

Prepared by: Liu Yue 2016-12-31

Checked by: Zhu Genghua 2017-1-10

Countersigned by: Li Qi, Wang Dong

Approved by: Wen Yiming 2017-1-10



Revision History

No.	Relevant Chapter	Change Description	Date	Version Before Change	Version After Change	Prepared by	Checked	Approved by
1		Document created	2016-12-31	None	A	Liu Yue	Zhu	Wen
							Genghua	Yiming
2								
3								
4								
5								

Relationship between this version and old versions: None.

康 吉 森 技 术 (Consen Tech.) 技 术 文 件

文件名称:安全控制系统 PM_FW 调度模块设计说明书

文件编号: 17-Q04-000618

项目编号: CT-RD-1601

项目名称:安全控制系统开发项目一期

物料编号:

版本号/修改码: A

文件密级: 机密

文件状态: CFC

受控标识: 受控

拟制: 刘跃 2016年12月31日

审核: 朱耿华 2017年1月10日

会签: 张磊

批准: 温宜明 2017年1月10日



修订页

编	章节	修订内容简述	修订	订前	订后	拟制	审核	批准
号	名称		日期	版本	版本			
1		创建	2016-12-31		A	刘跃	朱耿华	温宜明
2								
3								
4								
5								
6								
7								
8								
9								
10								
11								
12								
13								
14								
15								
16								

本版本与旧文件(版本)的关系:



Content 目录

1	Docu	ament ov	erview 文档概述	1
	1.1	Introdu	action 综述	1
	1.2	Refere	nce 参考文档	1
		1.2.1	Project documents 内部参考文档	1
	1.3	Terms	and abbreviations 术语和缩略语	1
		1.3.1	Terms 术语	1
		1.3.2	缩略语	2
2	Mod	ule overv	/iew 模块概述	3
3	Mod	ule desig	n 模块设计	4
	3.1	Function	on description 功能描述	4
	3.2	Design	n concept 设计思路	4
		3.2.1	TASK Management TASK 管理	4
		3.2.2	TASK Scheduling TASK 调度	5
		3.2.3	TASK Switching TASK 切换	7
	3.3	Interfa	ce function 接口函数	8
		3.3.1	TASK Management TASK 管理	8
		3.3.2	TASK Scheduling TASK 调度	9
		3.3.3	TASK Switching TASK 切换	9
	3.4	Global	variable 全局变量	10
	3.5	Data st	tructure 数据结构	10
	3.6	List of	sub-function 子功能列表	11
4	Desi	gn of sub	-function 子功能设计	12
	4.1	Task m	nanagement Task 管理	12
		4.1.1	os_create_task	12
	4.2	Task S	chedule 任务调度	13
		4.2.1	OSSchedule	13
		4.2.2	os_sched_rr	14
	4.3	Task S	witching Task 切换	15
		4.3.1	os_int_sw	15
		4.3.2	os time tick	16



1 Document overview 文档概述

1.1 Introduction 综述

This document describes the design description of task schedule of PM_FW of Safety Control System. The document describes the overall concept of the function of the module, and then the subfunction of the modules are described in detail.

This document is the output of schedule module design phase of PM_FW, and is the input for the follow-up coding phase.

本文档描述了安全控制系统中 PM_FW 任务调度模块的设计方案。文档首先描述了模块功能的总体设计思路,然后将模块功能划分为若干子功能并进行详细说明。

本文档是 PM FW 任务调度模块设计的输出,也是后续编码的输入。

1.2 Reference 参考文档

1.2.1 Project documents 内部参考文档

- [1] Embedded software safety concept of Safety Control System [505], 15-Q02-000059
- [1] 安全控制系统嵌入式软件安全概念说明书 [505], 15-Q02-000059
- [2] PM_FW software overall design description of safety control system [506], 15-Q02-000074
- [2] 安全控制系统 PM_FW 总体设计说明书 [506], 15-Q02-000074

1.3 Terms and abbreviations 术语和缩略语

1.3.1 Terms 术语

Table 1-1 Terms

表 1-1 术语

No.	Term	Description		
序号	术语	解释		
1.	IP_BUS	Communication between PM and IO modules.		
1.		PM 与 IO 模块之间的通讯总线。		
2.	CM_BUS	Communication between PM and CM.		
2.		PM 与 CM 之间的通讯总线。		
PM_BUS Communication between PMs.		Communication between PMs.		
J.		PM 之间的通讯总线。		
System Net Communication between control station and PC.		Communication between control station and PC.		
-[-,		控制站与上位机之间的通讯网络。		
5.	Safety Net Safe communication between control stations.			



		控制站之间的安全通讯。			
6.	Control station	A set of triple redundant control system, which includes triple redundant PMs			
0.	控制站	and IO modules under control.			
		一套三冗余的控制系统,包含三冗余 PM 和 PM 控制的各种 IO 模块。			
7. System response Time interval from the moment that transition of demand signated 7.		Time interval from the moment that transition of demand signal generated at			
'	time	input ETP to the moment that transition of response signal generated at output			
	系统响应时间	ETP.			
		从系统输入端子板上产生需求信号跳变的时刻到输出端子板上产生相应			
		的响应信号跳变之间的时间。			
8.	Control cycle	Time interval between adjacent two runs of user program execution.			
٥,	控制周期	PM 两次执行用户程序间隔时间。			
Project Files which contain configuration information for control states		Files which contain configuration information for control station and			
''	工程	generated by IEC 61131 configuration software. These files contain all the			
		information required by control station to implement control, including user			
		control program (binaries) to be loaded and executed as well as configuration			
		information of task, CM, PM and IO modules.			
		IEC 61131 组态软件在完成编译后,为控制站生成的组态信息文件,该			
		文件包含可加载执行的用户控制程序(二进制程序)、任务配置信息、			
		CM 配置信息、PM 配置信息和 IO 模块配置信息等各种控制站完成控制			
		所需的信息。			
10.	Source project	Source file of the project before compiling.			
10.	源工程文件	工程在编译前的源文件。			
11.	User program	Part of project which contain user control program (binaries) to be loaded and			
11.	用户程序	executed and configuration information of task.			
		工程中的一部分:可加载执行的用户控制程序(二进制程序)和任务配			
		置信息。			

1.3.2 缩略语

Table 1-2 Abbreviations

表 1-2 缩略语

No.	Abbreviation	English description	Chinese description
序号	缩略语	英文	中文
1.	PM	Processor Module	主处理器模块
2.	CM	Communication Module	通讯模块
3.	BI	Bus Interface Module	总线接口模块
4.	AI	Analog Input Module	模拟量输入模块
5.	AO	Analog Output Module	模拟量输出模块



6.	DI	Digital Input Module	数字量输入模块
7.	DO	Digital Output Module	数字量输出模块
8.	OSP	Over Speed Protect Module	超速保护模块
9.	SOE	Sequence Of Events	SOE 事件
10.	SIL	Safety Integrity Level	安全完整等级
11.	PW	Power Module	电源模块
12.	OPC	OLE for Process Control	用于过程控制的对象链接
			与嵌入式技术
13.	UP	User Program	用户程序
14.	TCB	Task control block	任务控制块

2 Module overview 模块概述

The location of the schedule module (marked red) in the software hierarchy is shown below.

调度模块(标红)在软件层次中的位置如下图所示。




Figure 2-1 the location of the module 图 2-1 模块位置

Schedule module is used to assign the running time of each task, and responsible for task switching.

任务调度模块主要是用于分配各任务的运行时间,以及任务切换。



3 Module design 模块设计

3.1 Function description 功能描述

This document describes three sub-functions, task management, task scheduling, and task switching.

本文档主要描述三个子功能,任务管理,任务调度,任务切换。

3.2 Design concept 设计思路

3.2.1 TASK Management TASK 管理

The design process of a real-time application generally involves splitting the work to be completed into tasks, and each task is responsible for a portion of the problem. A task (also called a thread) is a simple program that thinks it has the Central Processing Unit (CPU) all to itself. On a single CPU, only one task can execute at any given time.

实时应用设计过程中通常将工作分成几个任务,每个任务负责问题的一部分,任务(也称为线程)是一个简单的程序,运行在在单个 CPU上,在任何给定时间内只能执行一个任务。

For each task, a structure is defined to describe the task. The CPU execution context of the task describes the state of the processor running and the resource occupation of the task. Task management refers to the creation of a new task, and the steps of creating a new task is as follows:

- 1. Set the task priority.
- 2. Set the task stack.
- 3. Initialize task control block.
- 4. Load the context of task into CPU.

As shown in Figure 3-2-1, after creation of step 1, 2, 3, and 4, each task has a task entry function. When the task runs, the register state of the CPU is called task context.

对于每个任务,定义一个结构来对任务进行描述,任务的 CPU 运行上下文描述了任务在处理器执行过程中的,处理器运行状态和任务占用资源的情况,任务管理指的是创建一个新的任务,创建一个新任务的过程如下:

- 1. 设置任务优先级。
- 2. 设置任务堆栈。
- 3. 初始化任务控制块。
- 4. 装载任务运行。

如图 3-1 所示, 1,2,3,4 创建完成之后,每个任务有一个任务入口函数,任务运行时 CPU 的寄存器状态就称为任务上下文。






Figure 3-1 Creation of tasks 图 3-1 任务创建

3.2.2 TASK Scheduling TASK调度

Task scheduling determines the order of running tasks, and each task is assigned a priority that supports multiple tasks with the same priority. When an event occurs, the task is stopped if the event is ready for a high priority task, higher priority tasks get control of the CPU. When multiple tasks have the same priority, the system allows each task to run for the specified time slice. Of course, when the task does not run out of time slots allocated for it, it can give up CPU voluntarily; when the allocated time slice runs out, the system stops running the current task and switches to the next equal priority task to continue running.

任务调度决定了任务的运行顺序,每个任务都被分配了一个优先级,支持多任务有相同的优先级,当事件发生时候,如果事件让高优先级的任务就绪,当前任务就停止运行,更高优先级的任务获得 CPU 的控制权,当多个任务有相同的优先级时候,系统允许每个任务运行规定的时间片,当然任务没有用完分配给它的时间片时候,它可以自愿放弃 CPU,当分配的时间片用完时候,系统停止运行当前任务,切换下一个同等优先级的任务继续运行。

When two or more tasks have the same priority, system allows one task to run for a predetermined amount of time (called a Time Quanta) before selecting another task. This process is called Round-Robin scheduling or Time Slicing. If a task does not need to use its full time quanta it can voluntarily give up the CPU so that the next task can execute. System allows the user to enable or disable round robin scheduling at run time.

预定的时间量(称为 time quanta)。 此过程称为循环调度或时间轮转调度。如果任务不需要使用其全部时间片,它可以自愿放弃 CPU,以便下一个任务可以执行。允许用户在运行时启用或禁用循环调度。




Figure 3-2 the Round Robin scheduling

图 3-2 任务轮询

The figure below shows a timing diagram with tasks running at the same priority. There are three tasks that are ready-to-run at priority "X". For sake of illustration, the time quanta occurs every 4th clock tick. This is shown as a darker tick mark.

图 3-2 是相同优先级下任务运行的时序图,如图,有三个优先级都为X的任务,时间片长度都为4

- (1) Task 3 is running, during this time, the clock interrupt occurs, but the task 3 has not finished using the time slice,
- (2) Task 3 automatically gives up the time slice.
- (3) System Recovery Task 1, because it is the next task in Task 3 of the queue.
- (4) Task 1 is executed until the time slice assigned to it expires.
- (5) Task 3 is being executed, during that time the clock interrupt occurs, but task 3 has not expired.
- (6) Task 3 automatically gives up the time slice.
- (7) System reset the time slice of task 1 to 4.
- (8) Task 1 Execution.
 - (1) 任务 3 正在被运行,在这段时间内,时钟中断发生,但是任务 3 还没有使用完时间片



- (2) 任务 3 主动放弃时间片,
- (3) 系统恢复任务 1, 因为它是队列中任务 3 的下一个任务。
- (4) 任务 1 被执行直到分配给它的时间片到期。
- (5) 任务 3 正在被执行,在这段时间内,时钟中断会发生,但任务 3 还没有到期。
- (6) 任务 3 主动放弃剩下的时间片。
- (7) 系统重新设置任务1的时间片为4。
- (8) 任务1执行。

3.2.3 TASK Switching TASK切换

When the system turns to perform another task, it saves the current task's registers to the task stack and restores the context from the stack of other task to the CPU. This process is called task switching.

当系统转向去执行另一个任务的时候,它保存了当前的任务的寄存器到任务堆栈,并从其它任务的堆栈中恢复上下文到 CPU,这个过程叫任务切换。

An interrupt is a hardware mechanism used to inform the CPU that an asynchronous event occurred. When an interrupt is recognized, the CPU saves part (or all) of its context (i.e., registers) and jumps to a special subroutine called an Interrupt Service Routine (ISR). The ISR processes the event, and after completion of the ISR, the program either returns to the interrupted task, or the highest priority task, if the ISR made a higher priority task ready-to-run.

中断是硬件机制,用于通知 CPU 有异步事件发生,当中断被响应时,CPU 保存部分或者全部寄存器到任务的堆栈里,并跳转到中断服务程序 ISR 里,ISR 处理完成之后,程序会返回到中断前的任务或者更高优先级的任务。

If the high-priority task B is ready in the interrupt handler, the interrupt function does not return to the pre-interrupt task A, but directly executes the high-priority task B, at this time, due to interrupt generation, the task A State is stored in the task A's stack, so when the interrupt returns the state of A is not saved again but directly load the task B context to the hardware CPU.

如果高优先级任务 B 就绪了在中断处理函数里,中断函数返回时候不会回到中断前的任务 A,而是直接执行高优先级任务 B,此时,由于中断产生时,已经将任务 A 的状态保存在任务 A 的堆栈里,所以中断返回时无需再保存 A 的状态,直接载入任务 B 的上下文到硬件 CPU中。






Figure 3-3 Task switching timing diagram 图 3-3 任务切换

3.3 Interface function 接口函数

3.3.1 TASK Management TASK管理

The interface functions which is provided by this module is shown as follows:

模块提供的接口函数如下:

 int os_create_task(char *pname, void *ptask, void *parg, int prio,unsigned int tq, unsigned int *err)

Input argument	Output argument	Description
输入参数	输出参数	描述
char *pname, void		
*ptask, void *parg,		
int prio,unsigned int		
tq, unsigned int *err		
pname:任务名	Task id.	Create a new task
ptask :任务函数	任务 id	创建任务
parg:函数参数		
prio:任务优先级		
tq:时间片个数		
err:返回操作错误码		



3.3.2 TASK Scheduling TASK调度

The interface functions which is provided by this module is shown as follows:

模块提供的接口函数如下:

1. void os_scheduled(void)

Input argument 输入参数	Output argument 输出参数	Description 描述
No.	No.	Context schedule.
无。	无。	任务调度

void os_sched_rr(void)

Input argument 输入参数	Output argument 输出参数	Description 描述
刑八多奴 No.	制出参数 No.	照处 Round Robin schedule.
无。	无。	轮转调度

3.3.3 TASK Switching TASK切换

The interface functions which is provided by this module is shown as follows:

模块提供的接口函数如下:

1. void os_int_sw(void)

Input argument	Output argument	Description
输入参数	输出参数	描述
No.	No.	Context switching.
无。	无。	上下文切换

2. void os_time_tick(void)

Input argument	Output argument	Description
输入参数	输出参数	描述
No.	No.	ISR
无。	无。	中断服务程序



3.4 Global variable 全局变量

Table 3-1 Global variable list

表 3-1 全局变量列表

No.	Type	Name	Description
序号	变量类型	名称	描述
1	unsigned long	os_prio_cur	Priority of current task 当前任务的优先级 即将要被挂起的任务的优先级
2	unsigned long	os_prio_highrdy	Priority of highest priority task 指向即将要运行的任务的优先级
3	os_tcb *	os_tcb_cur	Pointer to currently running TCB 指向当前运行任务的控制块指针
4	os_tcb *	os_tcb_highrdy	Pointer to highest priority TCB R-to-R 指向切换后运行的任务的任务控制 块
5	os_tcb *	os_tcb_list	Pointer to doubly linked list of TCBs 任务控制块链表,指向最后最新建 立的任务
6	os_tcb *	os_tcb_prio_tbl[32]	Table of pointers to created TCBs 任务控制块优先级链表指针指向各 个优先级的任务控制块
7	os_tcb	os_tcb_tbl[32]	Table of TCBs 任务控制块数组

3.5 Data structure 数据结构

struct os_tcb {

INT32U *StkPtr; /* Pointer to current top of stack */

void *ExtPtr; /* Pointer to user definable data for TCB extension */

OSTCB *NextPtr; /* Pointer to next TCB in the TCB list */

17-Q04-000618

```
/* Pointer to previous TCB in the TCB list */
OSTCB
            *PrevPtr;
OSTCB
            *TickNextPtr;
OSTCB
            *TickPrevPtr;
                                        /* Pointer to tick list if task is in a tick list */
OSTICK_LIST
                  *TickListPtr;
                                        /* Pointer to base address of stack */
INT32U
                 *StkBasePtr;
OSPEND_DATA *PendDataTblPtr;
                                        /* Pointer to list containing objects pended on */
INT32U
                  PendOn;
                                        /* Indicates what task is pending on */
INT32U
                  PendStatus;
                                       /* Pend status */
                 Prio;
INT32U
                                       /* Task priority (0 == highest)*/
INT32U
                 StkSize;
                                   /* Size of task stack (in number of stack elements) */
                                       /* Task options as passed by TaskCreate() */
INT32U
                  Opt;
                  PendDataTblEntries; /* Size of array of objects to pend on */
OS_QTY
INT32U
                 TS:
                                       /* Timestamp */
INT32U
                 SemCtr;
                                         /* Task specific semaphore counter*/
INT32U
                 TickRemain;
                                         /* Number of ticks remaining */
                 TimeQuanta;
INT32U
INT32U
                 TimeQuantaCtr;
INT32U
                  Tconsuming;
char
                   *t name;
};
struct os_rdy_list {
    OSTCB
                  *HeadPtr;
                                     /* Pointer to task that will run at selected priority */
    OSTCB
                  *TailPtr;
                                      /* Pointer to last task at selected priority */
                                      /* Number of entries at selected priority */
    OSQTY
                  NbrEntries:
};
```

List of sub-function 子功能列表 3.6

The sub-functions list is shown as follows:

子功能列表如下。

Table 3-2 Sub function list

表 3-2 子功能列表

Sub function No.	Function description
子功能编号	功能描述
SWDD-PM-TS SafR NSecR A 001	TASK Management
3 1 2 3 3 3 3 2 3 3 3 2 3 3 3 3 3 3 3 3	TASK 管理
SWDD-PM-TS SafR NSecR A 002	TASK scheduling
	TASK 调度
SWDD-PM-TS SafR NSecR A 003	TASK switching
3 1 2 3 3 3 3 2 3 3 3 2 3 3 3 3 3 3 3 3	TASK 切换



4 Design of sub-function 子功能设计

4.1 Task management Task 管理

SWDD-PM-TS_SafR_NSecR_A_001

4.1.1 os_create_task

4.1.1.1 Function Description 功能描述

This function is used to create task.

本函数用于任务的创建。

4.1.1.2 Argument Description 参数说明

▶ Function Definition 函数定义

int os_create_task(char *pname, void *ptask, void *parg, int prio,unsigned int tq, unsigned int *err)

▶ Input argument 输入参数

pname: task name, 任务名, ptask: task entry function, 任务函数, parg: function parameter 函数参数, prio: task priority 任务优先级, tq: time slice 时间片个数, err: error code 返回操作错误码

▶ Output argument 输出参数

Task id: task identity 任务 id



4.1.1.3 Processing flow 处理流程




Figure 4-1-1-3 Task create process 任务创建流程

4.2 Task Schedule 任务调度

4.2.1 OSSchedule

SWDD-PM-TS_SafR_NSecR_A_002

4.2.1.1 Function Description 功能描述

This function is called by system services to determine whether a new, higher priority task has been made ready to run.

此函数由系统服务调用以确定新的高优先级任务是否已准备好运行。

4.2.1.2 Argument Description 参数说明

▶ Function Definition 函数定义

void os_scheduled(void)

▶ Input argument 输入参数

No.

无。



▶ Output argument 输出参数

No.

无。

4.2.1.3 处理流程



Figure 4-2-1-3 Task Schedule process 任务调度流程

4.2.2 os_sched_rr

SWDD-PM-TS_SafR_NSecR_A_002

4.2.2.1 Function Description 功能描述

This function is called on every tick ISR to determine if a new task of the same priority needs to execute.

在每个 Tick 的时钟中断处理函数上调用此函数,以确定是否需要执行相同优先级的新任务。

4.2.2.2 Argument Description 参数说明

▶ Function Definition 函数定义

void os_sched_rr(void)

▶ Input argument 输入参数

No.

无。

▶ Output argument 输出参数

No.

无。

4.2.2.3 Processing flow 处理流程




Figure 4-2-1-3 Task round robin schedule process 任务轮转调度过程

4.3 Task Switching Task 切换

SWDD-PM-TS_SafR_NSecR_A_003

4.3.1 os_int_sw

4.3.1.1 Function Description 功能描述

This function is used to perform task switching in the interrupt handler.

本函数用于进行任务切换在中断处理函数里。

4.3.1.2 Argument Description 参数说明

▶ Function Definition 函数定义

void os_int_sw(void)



▶ Input argument 输入参数

No.

无。

▶ Output argument 输出参数

No.

无。

4.3.1.3 Processing flow 处理流程




Figure 4-3-1-3 Task context switch process 任务上下文切换过程

4.3.2 os_time_tick

4.3.2.1 Function Description 功能描述

This function is used to signal to system the occurrence of a 'system tick' (also known as a 'clock tick').

本函数用于向系统发送"系统 tick"(也称为"时钟 tick"),此函数在系统中时钟断函数里调用。

4.3.2.2 Argument Description 参数说明

▶ Function Definition 函数定义

void os_time_tick(void)

▶ Input argument 输入参数

No.

无。



▶ Output argument 输出参数

No.

无。

4.3.2.3 Processing flow 处理流程

This function has no branch and the processing flow is omitted.

此函数无分支,流程图省略。

——以下无正文