


RF Front End Multiple Starting Diagrams

RF Front End of an AM Radio

The RF Front End is the part of the radio that receives the signal coming from the antenna and selects the desired station before sending it to the detector.


Answer 1




Explanation:

- CANT couples the antenna to the resonant circuit.
 - L1 and CVAR select the desired station.
 - RF OUT is sent to the detector.
-

Answer 2






Explanation:

- CCOUP transfers energy from the antenna.
- L1 and CTUNE form a parallel resonant tank.
- RF is taken from the resonant node.


Answer 3



Explanation:

- The antenna receives all radio stations.
- The input coupling transfers the signal.
- The tuned circuit selects the desired frequency.
- The selected signal is sent to the detector.


Answer 4



Explanation:

- The antenna is coupled through C1.
- L1 and C1 form the tuning network.
- RF OUT is connected to the tuned circuit.


Answer 5



Explanation:

- Cc couples the antenna.
- L and Cv determine the resonant frequency.
- Output is sent to the detector stage.


Answer 6



Explanation:

- The antenna feeds the tuned circuit.
- L and Cv select the station.
- RF OUT is taken from the resonant circuit.

Answer 7



Explanation:

- The antenna is magnetically coupled to the tuning circuit.

- The secondary coil and CTUNE form the resonant network.
- RF OUT is sent to the detector.