D03 · Production Quality & Compliance Systems

01 · Statistical Process Control (SPC) implementation

Supply Chain Reference Architecture v2.2 · mrsupplychain.ai

1 WHAT IT IS

SPC is the discipline of monitoring process variability against statistical control limits in real time, capturing common-cause vs. special-cause variation, and triggering operator response before drift becomes defect. It is the bridge between statistical theory and shop floor action — and the place where most quality programs reveal whether they are operating systems or reporting layers.

2 WHY IT MATTERS

SPC is the most economically rigorous quality tool available to a manufacturing operation — and the most consistently misapplied. **The standard practice is to run control charts as historical records reviewed weekly; the discipline is to use them as real-time control signals that drive response within the cycle**. The seminal reference quantifies the asymmetry clearly **(Montgomery, 2020 — peer-reviewed textbook, 8th ed.)**: a process operating in statistical control at Cpk = 1.67 produces ~0.6 defects per million opportunities; the same process at Cpk = 1.0 produces ~2,700 ppm — **a 4,500x increase in defect rate for a small shift in capability**. The economic case is unambiguous, but it depends on SPC being implemented as a control loop, not as a documentation exercise. Most plants do the documentation; few build the loop.

3 HOW IT IS DONE

1. **Identify the critical-to-quality (CTQ) characteristics before drawing any charts.** Not every measured dimension warrants SPC — only the ones whose variability drives functional failure or warranty exposure. A typical plant has 200+ measured dimensions and needs SPC on 20–30 of them. Choose deliberately; SPC on everything is SPC on nothing.
2. **Establish capability before deploying control.** Run a capability study (30+ subgroups under stable conditions) before drawing the X-bar and R chart. A process that is not capable (Cpk < 1.0) cannot be controlled by SPC — it can only be documented as out of control. Capability first; control second; never the reverse.
3. **Build out-of-control action plans (OCAPs) for each chart, before the chart goes live.** A chart without an OCAP is a chart that flags variation nobody knows how to respond to. Each control rule violation (Western Electric rules 1–8) must have an explicit response defined: who is notified, what they investigate, whether production stops or continues. No OCAP, no chart.
4. **Capture data inline, not by sampling clipboard.** Manual sampling at 30-minute intervals captures averages and misses excursions. Inline gauges, vision systems, and PLC-integrated measurement capture every part produced — and that is what makes the chart actionable within the cycle, not in retrospect.
5. **Recalibrate control limits when the process changes, not on a calendar.** Control limits are fixed during stable operation; they must be re-derived when equipment changes, materials change, or the operator population changes meaningfully. Limits that drift unchecked create false out-of-controls that erode operator trust — and a chart operators do not trust is a chart that does not work.
6. **Tie SPC violations to the andon system, not to the monthly QA report.** A Western Electric rule violation is a signal that needs response in minutes, not weeks. Integrating SPC alarms directly into the floor andon system closes the loop between detection and action. Without this integration, SPC remains reporting; with it, SPC becomes control.

WORKED EXAMPLE — ILLUSTRATIVE

A pharmaceutical tableting line runs 9 SKUs with tablet weight as the dominant critical-to-quality parameter (USP-905 uniformity ±5%). Baseline: weekly review of paper control charts, **Cpk = 0.94, weight-spec rejections = 2.3% of production (~$1.8M scrap annually)**. The implementation: inline checkweighers stream data to real-time SPC software at the cell; OCAPs defined for each Western Electric rule (rule 1 = 1 point beyond 3sigma -> stop the line; rule 2 = 9 consecutive points same side of centerline -> call the setup engineer); SPC alarms wired directly to the andon tower; quarterly limit recalibration after any tooling change. Results at 6 months: **Cpk = 1.67, weight rejections = 0.31%, scrap = $240K annualized (87% reduction)**. Payback on inline gauge + software: **5.2 months**. Operator-reported "phantom" out-of-controls drop to near-zero once quarterly recalibration becomes routine.

IN PRACTICE

Tie SPC violations to andon, not to dashboards

The discriminating question for any SPC program is not "do you have control charts?" but "what happens within 15 minutes when a control rule fires?" If the answer is "we log it for the weekly meeting," you have documentation; if it is "the cell stops and the setup engineer is paged," you have SPC.

OCAP before any chart goes live — no exceptions

An Out-of-Control Action Plan defines the exact operator response for each violation pattern before the control chart is deployed. Charts without OCAPs decay into alarms operators learn to ignore — and the program decays with them.

Establish process capability before deploying control

Cpk = 1.67 produces ~0.6 dpmo; Cpk = 1.0 produces ~2,700 dpmo — a 4,500× defect-rate increase for a modest capability shift **(Montgomery, 2020 — peer-reviewed textbook, 8th ed.)**. Confirm the process is capable before pretending to control it.

Quarterly SPC health audit with the rigor of a financial audit

Out-of-control rate with documented OCAP response. Active charts whose limits have been recalibrated in 90 days. Mean time from violation to first response. Without this audit, year-3 SPC is operators ignoring false alarms from limits set when the equipment was new.

WHAT YOU WOULD USE

SPC PLATFORMS

Minitab Statistical Software — The enterprise statistical workbench — deep capability analysis, SPC, DOE, and the dominant tool in formal Six Sigma certification programs **(Minitab — vendor)**.

JMP (SAS Institute) — Visual statistical platform with strong SPC, capability, and exploratory data analysis; the preferred choice where DOE and SPC live in the same analyst's hands **(SAS Institute — vendor)**.

InfinityQS, Northwest Analytics, WinSPC — Specialized real-time SPC platforms with native MES integration and configurable OCAP workflow — the right fit when SPC must operate at the cell, not at the analyst's desk **(InfinityQS — vendor; Northwest Analytics — vendor)**.

Native SPC modules in the MES (Siemens Opcenter, Rockwell FactoryTalk, AVEVA) — When the MES is already in place, native SPC is the path of lowest integration cost; the quality of the implementation depends entirely on configuration discipline.

4 SO WHAT

SPC that does not stop the cell is not control — it is statistical decoration. Select CTQs deliberately, establish capability before deploying control, build OCAPs before any chart goes live, capture data inline not by clipboard, recalibrate when the process changes, and tie violations to andon not to monthly reports. The technology is a century old; the difference between plants that prevent defects and plants that document them is whether the chart triggers action in the cycle or explanation in retrospect.

From the SCRA v2.2 reference architecture · mrsupplychain.ai · © 2026 Ismael López · Mr. Supply Chain® México