
Esquemático: Calculadora Hexadecimal



	Ρ	i	n	е	S	У	С	0	n	е	Х	i	0	n	е	s	
1.00					MOD 400					LOD							

MSP 430	LCD	MSP 430	LCD	MSP 430	PUSH BUT
	GND (1)	1.2	D2 (9)	2.2	# 1
VCC	VCC (2)	1.3	D3 (10)	2.3	# 2
	R=100K(CONTR) (3)	1.4	D4 (11)	2.4	#3
2.0	RS (4)	1.5	D5 (12)	2.5	# 4
	GND (W/R) (5)	1.6	D6 (13)		
2.1	ENABLE (6)	1.7	D7 (14)		
1.0	D0 (7)	VCC	NC (15)		
1.1	D1 (8)		GND (16)		