## **AERO 632: Design of Advance Flight Control System**

**Preliminaries** 


#### Raktim Bhattacharya

Laboratory For Uncertainty Quantification Aerospace Engineering, Texas A&M University.

place Transforms Transfer Functions System Interconnection Frequency Domain Analysis Desig


#### **Preliminaries**

- Signals & Systems
- Laplace transforms
- Transfer functions from ordinary linear differential equations
- System interconnections
- Block diagram algebra simplification of interconnections
- General feedback control system interconnection.




## Signals & Systems

#### Signals & Systems



- $\blacksquare$  Actuator applies u(t)
- Sensor provides y(t)
- Feedback controller takes y(t) and determines u(t) to achieve desired behavior
- The controller is typically implemented as software, running in a micro controller
- Imperfections exist in real world
  - sensors have noise
  - actuators have irregularities
  - plant P is not fully known

### **System Response to** u(t)



Given plant P and input u(t), what is y(t)?

- P is defined in terms of ordinary differential equations
- $\mathbf{v}(t)$  is the forced + initial condition response.

#### **Linear Dynamics**

Signals & Systems

#### **Nonlinear Dynamics**

$$m\ddot{x}+c\dot{x}+kx=u(t)$$
 dynamics  $y(t)=x(t)$  measurement

$$m\ddot{x}+c\dot{x}+kx=u(t)$$
 dynamics  $\ddot{x}-\mu(1-x^2)\dot{x}+x=u(t)$  dynamics  $y(t)=x(t)$  measurement  $y(t)=x(t)$  measurement

In this class we focus on linear systems

#### **Linear Systems**

Signals & Systems

$$\xrightarrow{u(t)} P \xrightarrow{y(t)}$$

- Dynamics is defined by linear ordinary differential equation
- Super position principle applies

$$\begin{array}{c} u_1(t) \mapsto y_1(t) \\ u_2(t) \mapsto y_2(t) \end{array} \Longrightarrow (u_1(t) + u_2(t)) \mapsto (y_1(t) + y_2(t))$$

## Laplace Transforms

### **Laplace Transforms**

**Given** signal u(t), Laplace transform is defined as

$$\mathcal{L}\left\{u(t)\right\} := \int_0^\infty u(t)e^{-st}dt$$

**Exists** when

Signals & Systems

$$\lim_{t\to\infty}|u(t)e^{-\sigma t}|=0, \text{ for some }\sigma>0$$

Very useful in studying linear dynamical systems and designing controllers

#### **Properties Laplace Transforms**

#### Linear operator

Signals & Systems

Additive

$$\mathcal{L}\{u_1(t) + u_2(t)\} = \int_0^\infty (u_1(t) + u_2(t)) e^{-st} dt$$

$$= \int_0^\infty u_1(t) e^{-st} dt + \int_0^\infty u_2(t) e^{-st} dt$$

$$= \mathcal{L}\{u_1(t)\} + \mathcal{L}\{u_2(t)\}$$

Superposition

$$\mathcal{L}\left\{au(t)\right\} = a\mathcal{L}\left\{u(t)\right\}, \ a \ \text{is a constant}$$

#### **Properties (contd.)**

- **1.**  $U(s) := \mathcal{L}\{u(t)\}$
- **2.**  $\mathcal{L}\{au_1(t)+bu_2(t)\}=a\mathcal{L}\{u_1(t)\}+b\mathcal{L}\{u_2(t)\}=aU_1(s)+bU_2(s)$
- 3.  $\frac{1}{s}U(s) \iff \int_{0}^{t} u(\tau)d\tau$
- **4.**  $U_1(s)U_2(s) \iff u_1(t) * u_2(t)$  Convolution
- **5.**  $\lim_{s\to 0} sU(s) \iff \lim_{t\to\infty} u(t)$  Final value theorem
- **6.**  $\lim_{s \to \infty} sU(s) \Longleftrightarrow u(0^+)$  Initial value theorem
- 7.  $-\frac{dU(s)}{ds} \iff tu(t)$
- **8.**  $\mathcal{L}\left\{\frac{du}{dt}\right\} \iff sU(s) su(0)$
- **9.**  $\mathcal{L}\{\ddot{u}\} \iff s^2U(s) su(0) \dot{u}(0)$


## **Important Signals**

- **1.**  $\mathcal{L}\left\{\delta(t)\right\} = 1 \ \delta(t)$  is impulse function
- **2.**  $\mathcal{L}\left\{1(t)\right\} = \frac{1}{s} \; \mathbf{1}(t)$  is unit step function at t=0
- **3.**  $\mathcal{L}\{t\} = \frac{1}{e^2}$
- **4.**  $\mathcal{L}\left\{\sin(\omega t)\right\} = \frac{\omega}{s^2 + \omega^2}$  **5.**  $\mathcal{L}\left\{\cos(\omega t)\right\} = \frac{s}{s^2 + \omega^2}$

## Transfer Functions

Signals & Systems

#### **Spring Mass Damper System**



#### **Equation of Motion**

$$m\ddot{x} + c\dot{x} + kx = u(t)$$

Take  $\mathcal{L}\left\{\cdot\right\}$  on both sides


$$\mathcal{L}\left\{m\ddot{x}+c\dot{x}+kx\right\} = \mathcal{L}\left\{u(t)\right\}$$

$$m\mathcal{L}\left\{\ddot{x}\right\}+c\mathcal{L}\left\{\dot{x}\right\}+k\mathcal{L}\left\{x\right\} = \mathcal{L}\left\{u(t)\right\}$$

$$m\left(s^2X(s)-sx(0)-\dot{x}(0)\right)+c\left(sX(s)-x(0)\right)+kX(s) = U(s)$$

$$(ms^2+cs+k)X(s)=U(s)\ \dot{x}(0)\ \text{and}\ x(0)\ \text{are assumed to be zero}$$

#### **Transfer Function**



$$(ms^2 + cs + k)X(s) = U(s) \implies \frac{X(s)}{U(s)} = \frac{1}{ms^2 + cs + k}$$

Choose output  $y(t) = x(t) \implies Y(s) = X(s)$ .

Therefore

$$P(s) := rac{Y(s)}{U(s)} = rac{1}{ms^2 + cs + k}$$
 Transfer function

#### **Transfer Function (contd.)**

#### In general

$$P(s) = \frac{N(s)}{D(s)}$$

where N(s) and D(s) are polynomials in s

- $\blacksquare$  Roots of N(s) are the zeros
- $\blacksquare$  Roots of D(s) are the poles determine stability

## **Response to** u(t)

#### Given

– input signal u(t) and transfer function P(s).

#### **Determine**

- output response y(t)

#### 1. Laplace transform

$$U(s) := \mathcal{L}\left\{u(t)\right\}$$

$$\xrightarrow{u(t)} P \xrightarrow{y(t)}$$

- 2. Determine Y(s) := P(s)U(s)
- 3. Laplace inverse

$$y(t) := \mathcal{L}^{-1} \{Y(s)\} = \mathcal{L}^{-1} \{P(s)U(s)\}$$

# System Interconnection


## **Block Diagram**


Representation of System Interconnections


- Series
- Parallel
- Feedback
- A simple example
- A complex example



#### **Series Connection**









ansforms Transfer Functions System Interconnection 00000 Frequency Domain Analysis Desi

## **Simple Example**



System Interconnection 0000000



## Frequency Response

$$\xrightarrow{u(t)} \mathbb{P} \xrightarrow{y(t)}$$

- Let  $u(t) = A_u \sin(\omega t)$
- Vary  $\omega$  from 0 to  $\infty$

A linear system's response to sinusoidal inputs is called the system's frequency response



Example

■ Let 
$$P(s) = \frac{1}{s+1}, u(t) = \frac{\sin(t)}{s+1}$$

$$y(t) = \frac{1}{2}e^{-t} - \frac{1}{2}\cos(t) + \frac{1}{2}\sin(t)$$

$$= \underbrace{\frac{1}{2}e^{-t}}_{\text{natural response}} + \underbrace{\frac{1}{\sqrt{2}}\sin(t - \frac{\pi}{4})}_{\text{forced response}}$$

- Forced response has form  $A_v \sin(\omega t + \phi)$
- $\blacksquare$   $A_u$  and  $\phi$  are functions of  $\omega$

Generalization

In general

$$Y(s) = G(s) \frac{\omega_0}{s^2 + \omega_0^2}$$

$$= \frac{\alpha_1}{s - p_1} + \dots + \frac{\alpha_n}{s - p_n} + \frac{\alpha_0}{s + j\omega_0} + \frac{\alpha_0^*}{s - j\omega_0}$$

$$\implies y(t) = \underbrace{\alpha_1 e^{p_1 t} + \dots + \alpha_n e^{p_n t}}_{\text{natural}} + \underbrace{A_y \sin(\omega_0 + \phi)}_{\text{forced}}$$

Forced response has same frequency, different amplitude and phase.

Generalization (contd.)

For a system P(s) and input

$$u(t) = A_u \sin(\omega_0 t),$$

forced response is

$$y(t) = A_u \mathbf{M} \sin(\omega_0 t + \mathbf{\phi}),$$

where

$$M(\omega_0)=|P(s)|_{s=j\omega_0}=|P(j\omega_0)|,$$
 magnitude  $\phi(\omega_0)=/\!\!\!/P(j\omega_0)$  phase

In polar form

$$P(j\omega_0) = Me^{j\phi}.$$

## Fourier Analysis

#### **Fourier Series Expansion**

Signals & Systems


Given a signal y(t) with periodicity T.


$$y(t) = \frac{a_0}{2} + \sum_{n=1,2,\dots} a_n \cos\left(\frac{2\pi nt}{T}\right) + b_n \sin\left(\frac{2\pi nt}{T}\right)$$
$$a_0 = \frac{2}{T} \int_0^T y(t) dt$$
$$a_n = \frac{2}{T} \int_0^T y(t) \cos\left(\frac{2\pi nt}{T}\right) dt$$
$$b_n = \frac{2}{T} \int_0^T y(t) \sin\left(\frac{2\pi nt}{T}\right) dt$$

aplace Transforms Transfer Functions System Interconnection Frequency Domain Analysis D

### **Fourier Series Expansion**

Approximation of step function






Frequency Domain Analysis 0000000000000000

#### **Fourier Transform**


Step function



Fourier transform reveals the frequency content of a signal

#### **Fourier Transform**

Step function - frequency content





#### Signals & Systems

#### **Input Output**

$$\begin{array}{c} u(t) \\ \hline \end{array} \begin{array}{c} y(t) \\ \hline \end{array}$$


#### **Fourier Series Expansion**

superposition principle

$$\begin{array}{c} \sum_{i} u_{i}(t) \\ \hline \end{array}$$

#### **Fourier Transform**

$$\xrightarrow{U(j\omega)} \mathsf{P} \xrightarrow{Y(j\omega)}$$



$$u_i(t) = a_i \sin(\omega_i t)$$


$$y_{i_{\text{forced}}}(t) = a_i M \sin(\omega_i t + \phi)$$

$$Y(j\omega) = P(j\omega)U(j\omega)$$

Suffices to study  $P(j\omega)$   $|P(j\omega)|,/P(j\omega)$ 


## Bode Plot

#### **First Order System**




$$P(s) = 1/(s+1)$$

- loglog scale
- $dB = 10 \log_{10}(\cdot)$
- $\bullet$  20dB =  $10 \log_{10}(100/1)$




- $u(t) = A\sin(\omega_0 t)$
- $y_{\text{forced}}(t) = AM \sin(\omega_0 t + \phi)$



$$P(s) = 1/(s^2 + 0.5s + 1)$$


$$\omega_n = 1 \text{ rad/s}$$




$$u(t) = A\sin(\omega_0 t)$$


$$y_{\text{forced}}(t) = AM \sin(\omega_0 t + \phi)$$

$$S(j\omega) + T(j\omega) = 1$$






- $P(s) = \frac{1}{(s+1)(s/2+1)}$
- C(s) = 10
- $S = G_{er} = \frac{1}{1+PC} = \frac{1}{1+10P}$
- $T = G_{yr} = \frac{PC}{1+PC} = \frac{10P}{1+10P}$



#### All transfer functions

With proportional controller



## Controller Design Considerations

Design

## **Design Using Bode Plot of** $P(j\omega)C(j\omega)$

Loop Shaping


Develop conditions on the Bode plot of the open loop transfer function

- Sensitivity  $\frac{1}{1+PC}$
- Steady-state errors: slope and magnitude at  $\lim_{\omega} \to 0$
- Robust to sensor noise
- Disturbance rejection
- $\blacksquare$  Controller roll off  $\implies$  not excite high-frequency modes of plant
- Robust to plant uncertainty


Look at Bode plot of  $L(j\omega) := P(j\omega)C(jw)$ 


#### **Frequency Domain Specifications**

Constraints on the shape of  $L(j\omega)$ 




- Choose  $C(j\omega)$  to ensure  $|L(j\omega)|$  does not violate the constraints
- Slope  $\approx -1$  at  $\omega_c$  ensures  $PM \approx 90^\circ$






#### **Sensor Characteristics**

Noise spectrum







$$G_{yn} = -\frac{PC}{1 + PC}$$

## **Reference Tracking**

Bandlimited else conflicts with noise rejection







$$G_{yr} = \frac{PC}{1 + PC}$$

$$G_{yn} = -\frac{PC}{1 + PC}$$

#### **Disturbance Rejection**

Bandlimited else conflicts with noise rejection





$$G_{yd} = \frac{P}{1 + PC}$$

$$G_{yn} = -\frac{PC}{1 + PC}$$