



Ants Assembly Instructions

Content

Bot	in default state (incl. Pull-Up Resistor)	3
	Preparation of the Ping-Sensor + Assembly	
	Bracket for Line-Follower	
	Preparation of the Line Follower	
	Assembly of the Line Follower	
5.	Wiring of the Line Follower	9
	Wiring of the Ultrasonic Distance Sensor	
7	Connection of the WiFi-Modul (FSP-8266)	12











Bot in default state (incl. Pull-Up Resistor)







1. Preparation of the Ping-Sensor + Assembly








2. Bracket for Line-Follower

Don't fully tighten screws yet!







3. Preparation of the Line Follower

STL-file for 3D-printing the schield can be found in the antshield-directory




Research-Module

<u>Jonas Wilfert</u> and <u>Niklas Paprotta</u>






4. Assembly of the Line Follower








After the assembly the highlighted screws from step 2 can be fully tightened.







5. Wiring of the Line Follower




Research-Module <u>Jonas Wilfert</u> and <u>Niklas Paprotta</u>






- 1. Connect powercable with 3pin wire to 5V delivery (Jumper has to be set to 5V)
- 2. Connect datacable to ports P0-P7 (S0 of the Line Followers into P0)







6. Wiring of the Ultrasonic Distance Sensor







7. Connection of the WiFi-Modul (ESP-8266)

- 1. WiFi-Module gets plugged on
- 2. Connect DI to P8 and DO to P9
- 3. Change the settings oft he WiFi-Moduls to AP-Mode with the name & password of the WiFi-Network in the web-interface

