
ACCUMULATOR ARCHITECTURE

Abbreviations

Accumulator	\rightarrow Acc
Carry Flag	\rightarrow CF
Over-flow flag	→ OF
Sign Flag	\rightarrow SF
Zero Flag	→ ZF
Parity Flag	→ PF
Instruction Pointer	\rightarrow IP

Instruction format

General Instruction format



Operand addressing modes and notations

$\begin{array}{ccc} 000 & \rightarrow & \text{Immediate} \\ 100 & \rightarrow & \text{Direct} \\ 101 & \rightarrow & \text{Indirect} \end{array}$	# default &
---	-------------------

Instruction Set Summary

Arithm	etic instructions	5
AD	O Addition	5
SUE	Subtraction	5
MU	L Signed multiplication	6
DIV	Signed division	6
INC	Increment Acc by 1	7
Logica	l instructions	7
AN	D Bit-wise And	7
OR	Bit-wise OR	8
XO	R Bit-wise XOR	8
SHI	Shift Acc left 1-bit	9
SHE	Shift Acc right 1-bit	9
ROI	rotate Acc left 1-bit	10
ROI	R rotate Acc right 1-bit	11
NO	One's compliment negation	11
Contro	l Transfer	12
Co	nditional Branches	12
	JC Jump if carry (CF = 1)	12
	JOF Jump if an over-flow (OF = 1)	12
	JS Jump if Sign (SF = 1)	13
	JP Jump if parity (PF = 1)	13
	JZ Jump if result is zero (ZF =0)	14
Un	conditional branch	14
	JUMP Jump	14
Loc	p Instructions	15
	LOOZ Loop while zero	15
Cal	Is and Returns	16
	CALL Call procedure	16
	RETURN Return from procedure	16
Miscel	laneous instructions	17
NO	No operation	17
Data M	lovement instructions	18
LO	ADacc Move to Acc	18
OTEC	DE M f A	10

Instruction set reference

Arithmetic instructions

ADD	Addition
Opcode	10000
Format	ADD AM operand
Description	Adds the operand specified and the Acc contents. Result modifies the Acc. The ADD instruction performs integer addition. It evaluates the results for both signed and unsigned integer operands and sets the CF and OF flags to indicate a carry in the signed or unsigned result, respectively. The SF indicates the sign of the signed result.
Operation	$Acc \leftarrow Acc + Operand$
AMs	Immediate, direct and indirect
Flags affected	ZF, OF, SF and PF are set according to the result.
SUB	Subtraction
SUB Opcode	Subtraction 10001
Opcode	10001
Opcode Format	SUB AM operand Subtracts the Acc contents from the operand specified. Result modifies the Acc. The SUB instruction performs integer subtraction. It evaluates the results for both signed and unsigned integer operands and sets the CF and OF to indicate a carry in the signed or unsigned result, respectively. The SF indicates the sign of the
Opcode Format Description	SUB AM operand Subtracts the Acc contents from the operand specified. Result modifies the Acc. The SUB instruction performs integer subtraction. It evaluates the results for both signed and unsigned integer operands and sets the CF and OF to indicate a carry in the signed or unsigned result, respectively. The SF indicates the sign of the signed result.

MUL	Signed multiplication
Opcode	11011
Format	MUL AM operand (lower 8-bit)
Description	Performs signed multiplication on lower 8-bits of accumulator and the operand. Mul instruction produces a 16-bit result in the accumulator.
Operation	$\begin{array}{ll} Acc & \leftarrow Acc * Operand \\ (16\text{-bit}) & (8 LSBs) & (8 LSBs) \end{array}$
AMs	Immediate, direct and indirect
Flags affected	ZF, SF and PF are set according the product. OF and CF is cleared, as no overflow occurs in this situation and no carry considered.
DIV	Signed division
Opcode	11100
Format	DIV AM operand
Description	Divides the accumulator by the operand. Div instruction produces an integer output. Result modifies the accumulator.
Operation	$Acc \leftarrow Acc / operand$
AMs	Immediate, direct and indirect
Flags affected	ZF, SF and PF are set according the product. OF and CF is cleared, as no overflow occurs in this situation and no carry considered.

INC	Increment Acc by 1
Opcode	10101
Format	INC
Description	Adds 1 to the Acc. Evaluates for both signed and unsigned operands.
Operation	$Acc \leftarrow Acc + 1$
AMs	Immediate, direct and indirect
Flags affected	the CF is not affected. The OF, SF, ZF and PF are set according to the result.

Logical instructions

AND	Bit-wise And
Opcode	10010
Format	AND AM operand
Description	Performs bit wise AND operation on the specified operand and the Acc. Each bit of the result is set to 1 if both corresponding bits of the operands are 1; otherwise, it is set to 0. Result replaces the Acc.
Operation	Acc ← Acc AND specified operand
AMs	Immediate, direct and indirect
Flags affected	OF and CF are cleared; SF, ZF and PF are set according to the result.

OR	Bit-wise OR
Opcode	10011
Format	OR AM operand
Description	Performs bit wise OR operation on the specified operand and the Acc. Each bit of the result is set to 0 if both corresponding bits of the operands are 0; otherwise, it is set to 1. Result replaces the Acc.
Operation	Acc ← Acc OR specified operand
AMs	Immediate, direct and indirect
Flags affected	OF and CF are cleared; SF, ZF and PF are set according to the result.
XOR	Bit-wise XOR
XOR Opcode	Bit-wise XOR 10100
Opcode	10100
Opcode Format	XOR AM operand Performs bit wise XOR operation on the specified operand and the Acc. Each bit of the result is set to 0 if both corresponding bits of the operands are 1 or if both corresponding bits of the operands are 0; otherwise, it is
Opcode Format Description	XOR AM operand Performs bit wise XOR operation on the specified operand and the Acc. Each bit of the result is set to 0 if both corresponding bits of the operands are 1 or if both corresponding bits of the operands are 0; otherwise, it is set to 1. result replaces the Acc.

SHL	Shift Acc left 1-bit
Opcode	10111
Format	SHL
Description	Shifts the bits in the Acc to the left by one bit. Bits beyond the boundary are first shifted in to the CF. At the end of the shift operation CF contains the MSB of the Acc. Least significant bit is cleared.
Operation	Acc ← Acc (MSB-1 down to 0) & "0" CF ← MSB (original operand)
AMs	Implied (accumulator)
Flags affected	The CF contains the value of the bit shifted out of the Acc. OF is set to zero if the value of the MSB of the Acc is same as the CF; otherwise it is set to 1. SF, ZF and PF are set according to the result.
SHR	Shift Acc right 1-bit
SHR Opcode	Shift Acc right 1-bit 01010
-	
Opcode	01010
Opcode Format	O1010 SHR Shifts the bits in the Acc to the right by one bit. Bits beyond the boundary are first shifted in to the CF. At the end of the shift operation CF contains the LSB of the
Opcode Format Description	O1010 SHR Shifts the bits in the Acc to the right by one bit. Bits beyond the boundary are first shifted in to the CF. At the end of the shift operation CF contains the LSB of the Acc. Most significant bit is cleared. Acc ← "0" & Acc (MSB down to 1)

ROL	rotate Acc left 1-bit
Opcode	11001
Format	ROL
Description	shifts (rotates) the bits of the Acc left by 1 bit. Instruction includes the CF in the rotation, first shifts the CF into the LSB. And shifts the MSB to the CF. The original value of the CF are not a part of the result, but the CF receives a copy of the bit that was shifted from one end to the other end. OF is set to the exclusive OR of the CF (after the rotate) and the MSB of the result.
Operation	tempCF ← MSB (operand) Acc ← Acc (msb-1 down to 0) & CF CF ← tempCF OF ← MSB (operand) XOR CF (after the rotation)
AMs	Implied (accumulator)
Flags affected	The CF contains the value of the bit shifted out of Acc. OF is set to the exclusive OR of the CF (after the rotate) and the MSB of the result. SF, ZF and PF are set according to the result.

ROR	rotate Acc right 1-bit
Opcode	11010
Format	ROR
Description	shifts (rotates) the bits of the Acc right by 1 bit. Instruction includes the CF in the rotation, first shifts the CF into the MSB and shifts the LSB to the CF. The original value of the CF is not a part of the result, but the CF receives a copy of the bit that was shifted from one end to the other end. OF is set to the exclusive OR of the two most significant bits of the Acc.
Operation	tempCF \leftarrow LSB (Acc) MSB (Acc) \leftarrow CF CF \leftarrow tempCF OF \leftarrow MSB (Acc) XOR CF
AMs	Implied (accumulator)
Flags affected	The CF contains the value of the bit shifted into it. OF is set to the exclusive-OR of the two most significant bits of the Acc. SF, ZF and PF are set according to the result.
NOT	One's compliment negation
Opcode	10110
Format	NOT
Description	Performs bit-wise NOT operation (each 1 is set to 0, and each 0 is set to 1) on the Acc and stores the result in it.
Operation	$Acc \leftarrow NOT Acc$
AMs	Implied (accumulator)

Flags affected

none

Control Transfer

Conditional Branches

JC	Jump if carry (CF = 1)
Opcode	00001
Format	JC {Signed offset (IP relative)}
Description	Check the state of the CF in the PSW (Programmer's Status Word register) and, if the flag is set, performs a jump to the target instruction specified by the operand. If the condition is not satisfied, the jump is not performed and execution continues with the instruction following the JC instruction. The target instruction is specified with a relative offset (a signed offset relative to the current value of the IP register). Machine code level the offset is encoded as a signed immediate value, which is added to the IP.
Operation	$IP \leftarrow IP + Operand$
AM	IP relative addressing is applied in the address calculation.
Flags affected	none
JOF	Jump if an over-flow (OF = 1)
Opcode	00010
Format	JOF {Signed offset (IP relative)}
Description	Check the state of the OF in the PSW (Programmer's Status Word register) and, if the flag is set, performs a jump to the target instruction specified by the operand. If the condition is not satisfied, the jump is not performed and execution continues with the instruction following the JOF instruction.
Operation	$IP \leftarrow IP + Operand$
AM	IP relative addressing is applied in the address calculation.
Flags affected	none

JS	Jump if Sign (SF = 1)
Opcode	00011
Format	JS {Signed offset (IP relative)}
Description	Check the state of the SF in the PSW (Programmer's Status Word register) and, if the flag is set, performs a jump to the target instruction specified by the operand. If the condition is not satisfied, the jump is not performed and execution continues with the instruction following the JS instruction
Operation	$IP \leftarrow IP + Operand$
AM	IP relative addressing is applied in the address calculation.
Flags affected	none
JP	Jump if parity (PF = 1)
JP Opcode	Jump if parity (PF = 1) 00100
Opcode	00100
Opcode Format	JP {Signed offset (IP relative)} Check the state of the PF in the PSW (Programmer's Status Word register) and, if the flag is set, performs a jump to the target instruction specified by the operand. If the condition is not satisfied, the jump is not performed and execution continues with the instruction following
Opcode Format Description	O0100 JP {Signed offset (IP relative)} Check the state of the PF in the PSW (Programmer's Status Word register) and, if the flag is set, performs a jump to the target instruction specified by the operand. If the condition is not satisfied, the jump is not performed and execution continues with the instruction following the JP instruction

JZ	Jump if result is zero (ZF =0)
Opcode	00101
Format	JZ {Signed offset (IP relative)}
Description	Check the state of the ZF (Programmer's Status Word register) and, if set, performs a jump to the target instruction specified by the operand. If the condition is not satisfied, the jump is not performed and execution continues with the instruction following the JZ instruction
Operation	$IP \leftarrow IP + Operand$
AM	IP relative addressing is applied in the address calculation.
Flags affected	none

Unconditional branch

JUMP	Jump
Opcode	01111
Format	JUMP {Signed offset (IP relative)}
Description	Transfers the program control to a different point of the instruction stream. The operand specified the signed offset being jumped to. This operand is an immediate signed offset
Operation	$IP \leftarrow IP + operand$
AM	IP relative addressing is applied in the address calculation.
Flags affected	none

Loop Instructions

LOOZ	Loop while zero
Opcode	01000
Format	LOOZ {Signed offset (IP relative)}
Description	Performs a loop operation using an implied memory location as a counter. Each time the LOOZ instruction executes, the counter is decremented, then checked for 0. If the count =0, the loop terminates and the program execution continues with the instruction following the LOOZ instruction. If the count is not 0, a jump is performed to the specified operand, (a signed offset is specified in the instruction) which is presumably the instruction at the beginning of the loop. The decremented counter value is written back to the implied memory location whenever it is nor zero.
Operation	Count \leftarrow Count -1 IF Count $=0$ Loop termination ELSE IP \leftarrow IP + operand END IF
AM	IP relative addressing is applied in the address calculation.
Flags affected	none

Calls and Returns

CALL	Call procedure
Opcode	01010
Format	CALL {Immediate address}
Description	Saves IP in the implied memory location and branches to the procedure (called procedure) specified by the operand. This operand is an immediate value. When executing a CALL, the processor pushes the value of the IP register on to the implied return address (For use latter as a return-instruction pointer). The processor then branches to the address specified with instruction.
Operation	implied address \leftarrow IP IP \leftarrow IP + Operand
AM	Immediate operand is used as the jumping location
Flags affected	none
RETURN	Return from procedure
Opcode	01011
Format	RET
Description	Transfers program control to a return address located in the implied return address. Return is made to the instruction that follows the CALL instruction.
Operation	$IP \leftarrow implied return address$
AM	Contents of the implied return address is used as the jumping location
Flags affected	none

Miscellaneous instructions

NOP	No operation
Opcode	01110
Format	NOP
Description	Performs no operation. Takes up space in the instruction stream but does not affect the context, except IP.
Flags affected	none

Data Movement instructions

LOADacc	Move to Acc
Opcode	11111
Format	LOADacc AM operand
Description	Immediate Addressing Copy the 16-bit immediate source operand to the accumulator.
	Direct Addressing Copy the contents of the source (operand) address (of memory) to the accumulator.
Operation	Immediate Addressing Acc ← 16-bit immediate Operand
	Direct Addressing Acc← memory (operand)
AMs	Immediate and direct
Flags affected	none
STOREacc	Move from Acc
STOREacc Opcode	Move from Acc 00110
Opcode	00110
Opcode Format	00110 STOREacc AM operand Direct Addressing Copy the accumulator to the destination memory address
Opcode Format	O0110 STOREacc AM operand Direct Addressing Copy the accumulator to the destination memory address (operand). Indirect Addressing Copy the contents of the accumulator to the destination
Opcode Format Description	O0110 STOREacc AM operand Direct Addressing Copy the accumulator to the destination memory address (operand). Indirect Addressing Copy the contents of the accumulator to the destination memory address found at operand (in memory). Direct Addressing
Opcode Format Description	STOREacc AM operand Direct Addressing Copy the accumulator to the destination memory address (operand). Indirect Addressing Copy the contents of the accumulator to the destination memory address found at operand (in memory). Direct Addressing Memory (operand) ← Acc Indirect Addressing