PT. YONGJIN JAVASUKA GARMENT	INSTRUKSI KERJA ACCESORIES ELASTIC	No .Dokumen : YJ-IK .WHS.0014 Tgl.Efektif : 25 January 2018 No. Revisi : 00 Halaman : 1		

A). INCOMING

1. Receive Packing list (import) / Invoice (Lokal) from Ana.
2. Check Total Carton Quantity based on Packing List/Invoice.

RECOMMENT :

RECEIVE DETAIL PACKING LIST/INVOICE:

1. Container & by Air = 1-2. day before material coming
2. Receive invoice immediately when material coming.
3. Courier when material coming.

B). INSPECTION QUANTITY

1. Check quantity 100% incoming material.
2. Scale weight all carton (kg).
3. Scale weight blank carton (kg).
4. Scale weight blank Polybag (kg).

> if using Polybag

5. Weighing material 1yds,4yds,4yds,4yds (gram)
6. Calculate average weight kg material per 1 yds (kg).

= weight total 4yds/12

7. Calculate quantity all carton.

= (weight of every Carton-Blank Carton-Blank Polybag) / weight 1yds (kg)

8. Elastic Shrinkage Test
   a. Steam elastic 1yds,4yds,4yds,4yds (change yds to inch") 1yds=36".
   b. Relax elastic 24 hour.
   c. Scale elastic weight 1yds,4yds,4yds,4yds after relax
   d. Measure elastic shrinkage per 1yds,4yds,4yds,4yds.
   e. Calculate shrinkage % every yds.
   f. Calculate average shrinkage every 1yds.
   g. Count total yds quantity shrinkage from total actual quantity.
   h. Countt balance quantity.

   = (Actual quantity-Sticker qty)-total shrinkage quantity.
9. Write down inspection result on Inspection Report Form.
10. Keep material in locker and give identity.

RECOMMENT :

1. For SMS order & small incoming material quantity, immediately counting actual.
2. Inspection report maximize 5 day from incoming.
3. Check sampling reject from total quantity if finding issue for report to supplier.
4. Immediately inform when finding issue in the material on the same day when issue found.

B). INSPECTION QUALITY

1. Inspect material use AQL 2.5 standard.
2. Reject material more than AQL reject standard, check 100%.
3. Relax elastic 3 day before production.

D). CHECK MS & CONSUMPTION

RECEIVE MS SIGN FROM ADM WH

1. Check MS with detail packing list & actual material.
2. Check material based on production schedule
3. Ask pattern. measurement to CAD Room.
4. Trial pattern measurement to sewing.
5. Revise pattern to CAD Room if sewing measurement not matching.
6. Check actual consumption & MS consumption.

RECOMMENT :

1. Get PP Meeting schedule from MD.
2. Pattern size can be get from CAD Room, 1-2 day after PP Meeting.
3. If order running in more than 1 line, make sure pattern measurement every size same in every line.
4. If pattern measurement every size different on each line, immediately get confirmation to VF QA.
5. Inform to MD immediately if actual con's more than MS con's.

E). OUTGOING TO PRODUCTION

1. Receive Daily Material Request from ADM Sewing by email.
2. Print Daily Material Request by ADM WH.
3. Give print-out of Material Request to outgoing PIC.
4. Prepare material based on request from outgoing PIC.
5. Keep material which already preserved in outgoing locker and give identity.
6. Material collecting by Sewing can be done 1 day after request.
7. Print IFMS invoice by ADM WH based on actual out qty.
8. ADM WH double check out material based on IFMS invoice.

RECOMMENT :

1. Material Request being made 1 day before collecting process and sign on 11 am by WH Manager.
2. Material Request already mention input garment qty, color & size.
3. Special for elastic normal relax:

48 / 72 hours, request 5 days before loading.

F). LEFT OVER/STOCK LIST

1. Check Balance summary in IFMS.
2. Double check balance qty IFMS with actual balance material.
3. Out all balance material according to balance actual outgoing production in IFMS by ADM WH.
4. For below reason, can't be out balance qty:
   * Cancel Order
   * Don't Use
   * MOQ
5. ADM WH update Weekly IFMS Check List.
6. Left over/stock material be given to stock PIC with the stock list.
7. For stock item which still used, input back to left over qty on IFMS (return) with NCV amount.

RECOMMENT :

1. Return balance qty in IFMS update Remark status at Inventory:
   * LEFT OVER
   * MOQ
   * CANCEL ORDER
   * PREBUILD
2. Give identity for material stock in carton:
   - Item - Art No
   - Supplier - Buyer
   - Size - Qty