SOP Jarum

Needle SOP

Process	Effective date : 2014 Revised :

Operator can change broken needle to needle adm

↓

Operator must use needle box to change the broken needle

↓

All broken needle part, must be complete

↓

Needle adm record all in-out and all needle fragment

1



Operator tukar jarum ke adm jarum

2



Operator harus menggunakan box saat menukar jarum

3



Patahan jarum harus lengkap

4



Adm jarum harus merecap semua data jarum

5 Langkah Pencarian Patahan Jarum

5 steps search of broken needle

Process	Effective date : 2023 Revised : 02

Step 1# search at machine area (Table)

↓

Step 2# Trace the floor around under the machine table (two meter to the right, left, front and back of the machine) using the floor magnet

↓

Step 3# Bring the panel that is being sewn and the panel in the table area at a distance of 2 meters to the right, left, front and back using a red bin box to the QC metal detector, and check using a hand detector

↓

Step 4# If the needle fragments still cannot be allocated and removed the garment must be destroyed.

↓

5# Made ‘investigation form” for new needle request

1



1# Telusuri meja mesin menggunakan pen detektor

2



2# Telusuri lantai di sekitar bawah meja mesin (dua meter ke kanan, kiri, depan, belakang dari mesin) menggunakan magnet lantai

3





3# Bawa panel yang sedang dijahit dan panel yang ada di area meja dengan jarak 2 metar kekanan, kekiri, kedepan dan belakang menggunakan red bin box ke QC metal detector,dan cek menggunakan hand detector

4



4# Jika patahan tidak ditemukan pisahkan panel ke tempat isolation box untuk dimusnahkan.

5



5# Buat “Berita Acara” untuk pergantian jarum baru