


Dependencies



Configuring Arduino with ROS



Install the arduino package and ros library



Controlling the robot arm by joint_state_publisher

