PLANT 2 · STANDARD OPERATING PROCEDURE

Line Start-Up

SOP-101
Rev E

Effective	Owner	Prepared by	Approved by
2025-06-16	**Production**	**M. Alvarez**	**D. Whitfield**

PURPOSE

Start a packaging line safely and reach approved production in the shortest time.

SCOPE

Lines 1, 2 and 3. Applies at the start of every shift and after any stop longer than 60 minutes.

ROLES

ROLE	RESPONSIBILITY
Line Lead	Owns the start-up and signs the checklist.
Operator	Carries out the machine checks.
QA Technician	Gives first-off approval.
Maintenance Technician	Removes locks after maintenance work.

PPE

- Safety glasses
- Safety shoes
- Hearing protection in the filling hall

TOOLS

None.

MATERIALS

- Bottles
- Caps
- Labels
- Shipper cases
- Hot-melt glue

PROCEDURE

Before start

STEP	WHO	ACTION
1	Line Lead	Read the previous shift's entry in FRM-PR-02 Shift Handover Log. Note any open problems.

2	Line Lead	Confirm with the Maintenance Technician that all locks and tags are removed as described in SP-402.
3	Operator	Walk the line from filler to palletizer. Remove tools, rags and loose parts. All guards closed.
4	Operator	Check compressed air at the line regulator: 6.2 bar minimum.
5	Operator	Confirm the correct bottles, caps, labels and cases are staged for the scheduled product.

Machine checks

STEP	WHO	ACTION
6	Operator	Filler (FIL-1, FIL-2, FIL-3): set up as described in WI-210.
7	Operator	Capper (CAP-1, CAP-2, CAP-3): set up as described in WI-211.
8	Operator	Labeler (LAB-1, LAB-2, LAB-3): set up as described in WI-212.
9	Operator	Case packer (CPK-1, CPK-2, CPK-3): set up as described in WI-213. Glue tank at temperature before starting.
10	Operator	Palletizer (PAL-1, PAL-2, PAL-3): light curtain test, correct pallet pattern selected.

Start and first-off

STEP	WHO	ACTION
11	Operator	Start conveyors (CNV-1, CNV-2, CNV-3), then the filler at 50% speed.
12	Operator	Run 20 bottles and stop. Take the first-off samples to the QA Technician.
13	QA Technician	Approve or reject the first-off as described in QP-306.
14	Operator	After approval, ramp to the scheduled rate over 5 minutes.
15	Operator	Take the first fill weight check within 15 minutes of start, then every 30 minutes for the rest of the shift, as described in QP-303.
16	Line Lead	Sign FRM-PR-01 Start-Up Checklist and file it at the line.

RELATED DOCUMENTS

- SP-402 Lockout/Tagout
- WI-210 Filler Setup and Nozzle Check
- WI-211 Capper Setup and Torque Check
- WI-212 Labeler Setup and Label Roll Change
- WI-213 Case Packer Setup and Glue Check
- QP-303 Fill Weight Checks

- QP-306 First-Off Approval

RECORDS

- FRM-PR-01 Start-Up Checklist
- FRM-PR-02 Shift Handover Log

REVISION HISTORY

REV	DATE	CHANGE
E	2025-06-16	Added air pressure check and 50% speed start.
D	2023-02-06	New template.