## **Shield Bluetooth Arduino**


## **Descrizione**

Questo shield permette ad Arduino e schede Arduino-compatibili, di comunicare via Bluetooth. E' possibile comunicare con il modulo Bluetooth attraverso la UART software scegliendo i pin da D0 a D7 o tramite la UART Hardware.

Il modulo Bluetooth è un V2.0+EDR 3MBps. Utilizza un chip CSR Bluecore.

## Caratteristiche:

- Compatibile con Arduino
- Sensibilità tipica: -80dbm
- Potenza di trasmissione fino a +4dbm
- Bluetooth V2.0+EDR con modulazione a 3Mbps
- Assorbimento contenuto
- Controllo PIO
- Interfaccia UART con baud rate programmabile
- Antenna integrata



## Codice di esempio

```
#include <SoftwareSerial.h> //Software Serial Port
               // Se funziona si vede il led rosso accesso
#define RxD 7
#define TxD 6
#define DEBUG ENABLED 1
SoftwareSerial blueToothSerial(RxD,TxD);
boolean enableComunication=false; // Flag che serve ad abilitare e disabilitare
lo scambio di dati
String stringa=""; // stringa ricevuta via bluetooth
void setup()
    Serial.begin (9600);
   pinMode(RxD, INPUT);
   pinMode(TxD, OUTPUT);
   setupBlueToothConnection();
}
void loop()
  char recvChar;
 if(blueToothSerial.available()) { //check if there's any data sent from the
remote bluetooth shield
   recvChar = blueToothSerial.read();
      Serial.println(recvChar);
 }
}
void setupBlueToothConnection()
   blueToothSerial.begin(38400);
                                                            // Set BluetoothBee
BaudRate to default baud rate 38400
   blueToothSerial.print("\r\n+STWMOD=0\r\n");
                                                            // set the bluetooth
work in slave mode
   blueToothSerial.print("\r\n+STNA=ArduinoBluetooth\r\n");  // set the
bluetooth name as "SeeedBTSlave"
   blueToothSerial.print("\r\n+STOAUT=1\r\n");
                                                            // Permit Paired
device to connect me
   blueToothSerial.print("\r\n+STAUTO=0\r\n");
                                                            // Auto-connection
should be forbidden here
   delay(2000);
                                                            // This delay is
required.
   blueToothSerial.print("\r\n+INQ=1\r\n");
                                                            // make the slave
bluetooth inquirable
   Serial.println("The slave bluetooth is inquirable!");
                                                            // This delay is
   delay(2000);
required.
   blueToothSerial.flush();
}
```

Scaricare ScanDevice dal PlayStore.