

Sample Gym Equipment Maintenance & Safety Manual

1. Equipment Identification

Model Name & Number: ProRun X200 Commercial Treadmill

Specifications:

- Dimensions: 210 x 90 x 150 cm
- Max User Weight: 160 kg
- Power Requirement: 220–240V, 50Hz

2. Maintenance Procedures

Routine Maintenance Schedule:

- Daily: Wipe console and handrails after use.
- Weekly: Lubricate running deck and inspect belt tension.
- Monthly: Check motor brushes, bolts, and electrical connections.

Cleaning Instructions:

Use a soft cloth with mild detergent. Avoid alcohol, ammonia, or abrasive cleaners.

Part Replacements:

- Running Belt: Replace every 18–24 months depending on usage.
- Drive Belt: Inspect quarterly and replace if frayed.

3. Troubleshooting Guide

Error Codes:

- E01 – Motor overload detected.
- E05 – Speed sensor malfunction.

Common Issues & Solutions:

- Belt Slipping: Tighten rear roller bolts evenly.
- Console Not Powering On: Check power cable and fuse.

4. Safety & Usage

Operational Instructions:

Adjust belt speed gradually. Always attach the safety key before use.

Safety Warnings:

- Do not use if power cable is damaged.
- Keep children away from moving parts.
- Stop immediately if unusual noise or vibration occurs.