




Punchdown MAX Module® Instructions




FLAT




KEYSTONE




ANGLED




Tools




Tools




Parts




Optional
Door




1




2




3




4



5









6









7

Punchdown MAX Module® Instructions



Punchdown MAX Module® Instructions



Punchdown MAX Module® Instructions

To assist safe installations, comply with the following:

- A. Use caution when installing or modifying telecommunications circuits.
- B. Never touch uninsulated wire terminals unless the circuit has been disconnected.
- C. Never install this device in a wet location.
- D. Never install wiring during a lightning storm.



Global Headquarters
Watertown, Connecticut USA
Tel: (1) 866-548-5814

For a complete listing of our global offices visit our web site

