# **MOODLIGHT**



## **FUNCTIONALITY OVERVIEW**

The Moodlight has five different modes, which can be selected on the app.



Displays the colour which is selected on the colour circle.

†† Slider-Mode

Displays the colour which is adjusted with the sliders.

Temperature-Mode

The colour spectrum is determined by the ambient temperature. The higher the temperature, the greater the red portion. The lower the temperature, the greater the blue portion.

Fade-Mode

The Moodlight continuously runs through the individual colour portions.

Strobo-Mode

The Moodlight generates random colour combinations every second.


#### **Illumination Settings**

The brightness of the Moodlight is proportional by the ambient light. This functionality can be inverted. This means the brighter the ambient light, the darker the Moodlight.


## **GETTING STARTED**

### Installing the Moodlight

Connect included power cable to the Moodlight



Connect the power cable to the power outlet




Turn the switch on to power the Moodlight



### Connect your device

Download the Moodlight-App from the Google Play Store



Start the Moodlight-App and allow to activate Bluetooth



Select your Moodlight device



The Moodlight is ready when the dot lights up green.



### Using the Moodlight app

Temperature of the Moodlight and the smartphone battery

Colour circle to adjust the Moodlight colour

Buttons for mode selection






Switches to enable/disable the illumination function and to invert/not invert the logic of this functionality

Sliders to adjust the colour of the Moodlight

Checkboxes to enable/disable the individual colour portions



#### Using the Moodlight app



#### Settings:

- Visuals:
  - Show/Hide the incoming temperature in transmission history
  - Show/Hide the transmission history
- Resolution:
  - Select the sensitivity of the illumination function
- Temp limit:
  - Select the operation range of the temperature mode

Transmission history

## **SUPPORT & FAQ**

#### **FAQ**

- What should I do if I can't connect to the Moodlight?

  Press the Restart-Button in the App. If it still doesn't work restart the Moodlight by unplugging it. Wait for 10 seconds and then start it again.
- Is it normal for my Moodlight to get warm?

  The Moodlight has an overtemperature monitoring, which allows temperature up to 50°C. If it reaches this limit, the Moodlight turns off until the temperature falls under 45°C. During overtemperature the device can't be use used.

#### **Support**

If you have any questions, please contact us via e-mail or visit our website:

- support@moodlight.ch
- www.moodlight.ch/support

Only few language slips. Direct, 'simple' language. 'Crisp', quite attractive. 5.375