
# Crazy Moodlight User Manual



**Enjoy the Craziness!** 

### **Functionality Overview**

#### **Standard Mode**

The standard Mode of your *Crazy Moodlight* device gives you the possibility to choose the light colour you desire. Control it either over Bluetooth by the smartphone application or with the integrated control knob interface right on the device. The *Crazy Moodlight* will light up the environment and can put you in the right mood for relaxing, working or having fun.

### **Bass Pulsing**


You love to feel the pass pulsing in your veins? This feature will be perfect for you when you listen to loud music. Activate it and the *Crazy Moodlight* will pulse to the bass of the music and fill the room with party vibes.

#### Rainbow


When this feature is activated the *Crazy Moodlight* will emit diversity! It can be used at any time and in any mood. The colours emerge into each other and cycle through all facets of the rainbow. You can adjust the light intensity and the speed in which the colours transition and create the atmosphere of your dreams.

# **Get Started with the Crazy Moodlight**

Package Content









Check for completeness and damage before proceeding with the instruction.

Placement and Safety




Place the Moodlight on a flat surface and keep a minimum safety distance to all sides of 5 cm.

4. Start the Moodlight



Start the *Crazy Moodlight* with a short single press on the control knob.

Connect Power Supply




2


Connect the cable with the power jack on the back of the device. Then put the adapter into the socket.


Operation

To operate the *Crazy Moodlight* with the app continue on the next page. For the instruction of the control knob interface go to point 9.

## **Smartphone Application**








### **Control Knob Interface**



### **Use the Crazy Moodlight Control Knob Interface**

- 1. Power LED
- 2. Control knob
- 3. Colour signal LEDs
- 4. Bass Pulsing LED
- 5. Rainbow LED
- 6. Speed/intensity LED (*Rainbow*)



A **short single press** of the control knob turns the *Crazy Moodlight* **on**. If turned on a **short single press** switches between the colours. The signal LED shows which colour is activated. The colour brightness can then be changed by turning the control knob.

A **short double press** of the control knob turns the *Bass Pulsing* **on** and **off**. While the 'Bass Pulsing' is on, the colours can still be changed.

A **short triple press** of the control knob turns the *Rainbow* **on** and **off**. If the *Rainbow* is activated a **short single press** will change between the speed and the intensity settings. If the white LED is off, the transition speed can be changed by turning the control knob. If the white LED is on, the intensity can be changed the same way. During the *Rainbow* the *Bass Pulsing* can be used as shown above.

**Press** the control knob **for 2 seconds** to turn **off** the Crazy Moodlight.

### **Support and Errors**

### **Support**

For support please contact:

opplimor@students.zhaw.ch (German support)

rufensim@students.zhaw.ch (English support)

Website:

www.crazymoodlight.ch/support

### **Error Handling**

When the *Crazy Moodlight* is not working as intended, turn it off by pressing the control knob for 2 seconds or by unplugging it. Wait for 10 seconds and start the *Crazy Moodlight* again. If the problem persists go to our website or contact the support.

For frequently asked questions go to: www.crazymoodlight.ch/faq