

Lecture #9

MIPS

Part III: Instruction Formats and Encoding





Lecture #9: MIPS Part 3: Instruction Formats

- 1. Overview and Motivation
- 2. MIPS Encoding: Basics
- 3. MIPS Instruction Classification
- 4. MIPS Registers (Recap)
- 5. R-Format
 - 5.1 R-Format: Example
 - 5.2 Try It Yourself #1



Lecture #9: MIPS Part 3: Instruction Formats

- 6. I-Format
 - 6.1 I-Format: Example
 - 6.2 Try It Yourself #2
 - 6.3 Instruction Address: Overview
 - 6.4 Branch: PC-Relative Addressing
 - 6.5 Branch: Example
 - 6.6 Try It Yourself #3
- 7. J-Format
 - 7.1 J-Format: Example9
 - 7.2 Branching Far Away: Challenge
- 8. Addressing Modes



1. Overview and Motivation

- Recap: Assembly instructions will be translated to machine code for actual execution
 - This section shows how to translate MIPS assembly code into binary patterns
- Explains some of the "strange facts" from earlier:
 - Why is *immediate* limited to 16 bits?
 - Why is **shift** amount only 5 bits?
 - etc.
- Prepare us to "build" a MIPS processor in later lectures!



2. MIPS Encoding: Basics

- Each MIPS instruction has a fixed-length of 32 bits
 - → All relevant information for an operation must be encoded with these bits!
- Additional challenge:
 - To reduce the complexity of processor design, the instruction encodings should be as regular as possible
 - → Small number of formats, i.e. as few variations as possible



3. MIPS Instruction Classification

- Instructions are classified according to their operands:
 - → Instructions with same operand types have same encoding

```
R-format (Register format: op $r1, $r2, $r3)
```

- Instructions which use 2 source registers and 1 destination register
- •e.g. add, sub, and, or, nor, slt, etc
- Special cases: srl, sll, etc.

I-format (Immediate format: op \$r1, \$r2, Immd)

- Instructions which use 1 source register, 1 immediate value and 1 destination register
- e.g. addi, andi, ori, slti, lw, sw, beq, bne, etc.

J-format (Jump format: op Immd)

• j instruction uses only one immediate value



4. MIPS Registers (Recap)

For simplicity, register numbers (\$0, \$1, ..., \$31) will be used in examples here instead of register names

Name	Register number	Usage
\$zero	0	Constant value 0
\$v0-\$v1	2-3	Values for results and expression evaluation
\$a0-\$a3	4-7	Arguments
\$t0-\$t7	8-15	Temporaries
\$s0-\$s7	16-23	Program variables

Name	Register number	Usage
\$t8-\$t9	24-25	More temporaries
\$gp	28	Global pointer
\$sp	29	Stack pointer
\$fp	30	Frame pointer
\$ra	31	Return address

\$at (register 1) is reserved for the assembler.

\$k0-\$k1 (registers 26-27) are reserved for the operation system.



5. R-Format (1/2)

Define fields with the following number of bits each:

$$\bullet$$
 6 + 5 + 5 + 5 + 5 + 6 = 32 bits

6 5	5	5	5	6
-----	---	---	---	---

Each field has a name:

I ADCAGE I TO I TO I SHAME I TI	ct
---------------------------------	----

- Each field is an independent 5- or 6-bit unsigned integer
 - A 5-bit field can represent any number 0 31
 - A 6-bit field can represent any number 0 63

NOTE:

There are only 32 registers, so 5 bits for each register is enough. Similarly, it is enough for **shamt** field since shifting 32 bits clears the entire register.



5. R-Format (2/2)

Fields	Meaning
opcode	Partially specifies the instructionEqual to 0 for all R-Format instructions
funct	- Combined with opcode exactly specifies the instruction
rs (Source Register)	- Specify register containing first operand
rt (Target Register)	- Specify register containing second operand
rd (Destination Register)	- Specify register which will receive result of computation
shamt	 Amount a shift instruction will shift by 5 bits (i.e. 0 to 31) Set to 0 in all non-shift instructions



5.1 R-Format: Example (1/3)

MIPS instruction

add \$8, \$9, \$10

NOTE:

Find the value of opcode and funct from the MIPS green sheet that contains all information.

R-Format Fields	Value	Remarks		
opcode	0	(textbook pg 94 - 101)		
funct	32	(textbook pg 94 - 101)		
rd	8	(destination register)		
rs	9	(first operand)		
rt	10	(second operand)		
shamt	0	(not a shift instruction)		



5.1 R-Format: Example (2/3)

MIPS instruction

\$8, \$9, \$10 add



Note the ordering of the 3 registers

Field representation in decimal:

opcode	rs	rt	rd	shamt	funct
0	9	10	8	0	32

Field representation in binary:

000000 | 01001 | 01010 | 01000 | 100000

Split into 4-bit groups for hexadecimal conversion:

0000 | 0001 | 0010 | 1010 | 0100 | 0000 | 0010 | 0000 |

 0_{16} 1_{16} 2_{16} A_{16} 4_{16} 0_{16} 2_{16}



5.1 R-Format: Example (3/3)

MIPS instruction

\$8, \$9, 4 sll



Note the placement of the source register

Field representation in decimal:

opcode	rs	rt	rd	shamt	funct
0	0	9	8	4	0

Field representation in binary:



Split into 4-bit groups for hexadecimal conversion:

0₁₆

 $0_{16} \quad 0_{16} \quad 9_{16} \quad 4_{16} \quad 1_{16}$



5.2 Try It Yourself #1

MIPS instruction

add \$10, \$7, \$5

Field representation in decimal:

opcode	rs	rt	rd	shamt	funct
0	7	5	10	0	32

Field representation in binary:

000000 00111 00101 01010 00000 100000

Hexadecimal representation of instruction:

0 0 E 5 5 0 2 0₁₆



5. R-Format: Summary

MIPS instruction

arith \$rd, \$rs, \$rt

NOTE:

opcode is always 0
shamt is always 0
arith is arithmetic operation

opcode	rs	rt	rd	shamt	funct
0	rs	rt	rd	0	XX

MIPS instruction

shift \$rd, \$rt, shamt

NOTE:

opcode is always 0
rs is always 0
shift is shift operation

opcode	rs	rt	rd	shamt	funct	
0	0	rt	rd	shamt	XX	



6. I-format (1/4)

- What about instructions with immediate values?
 - 5-bit shamt field can only represent 0 to 31
 - Immediates may be much larger than this
 - e.g. **1w**, **sw** instructions require bigger offset

- Compromise: Define a new instruction format partially consistent with R-format:
 - If instruction has immediate, then it uses at most 2 registers

NOTE:

The reason why we want to keep some fields in the same position (e.g., opcode) is that by looking at the <u>binary</u>, we can quickly identify the instruction format.

Also, we ensure that retrieving rs and rt will be consistent across R-format and I-format.



6. I-format (2/4)

Define fields with the following number of bits each:

$$\bullet$$
 6 + 5 + 5 + 16 = 32 bits

ľ	6	5	5	16

Again, each field has a name:

opcode rs	rt	immediate
-----------	----	-----------

- Only one field is inconsistent with R-format.
 - opcode, rs, and rt are still in the same locations.

opcode	rs	rt	rd	shamt	funct	
0	9	10	8	0	32	٦

NOTE:

We merge **rd**, **shamt** and **funct** to form a 16-bit field used for a constant value (**immediate**).

That is, 5 + 5 + 6 = 16 bits. Just nice!



6. I-format (3/4)

- opcode
 - Since there is no funct field, opcode uniquely specifies an instruction
- rs
 - specifies the source register operand (if any)
- rt
 - specifies register to receive result
 - note the difference from R-format instructions
- Continue on next slide......



6. I-format (4/4)

• immediate:

- Treated as a signed integer
 - Except for bitwise operations (andi, ori, xori)
- 16 bits → can be used to represent a constant up to 2¹⁶ different values
- Large enough to handle:
 - The offset in a typical lw or sw
 - Most of the values used in the addi, slti instructions

NOTE:

This should answer why we <u>cannot</u> put 32-bit constants in the instruction. Because the instruction itself is only 32-bit wide. So we can only use parts of it. Plus, we still need to encode opcode, rs and rt.



6.1 I-format: Example (1/2)

MIPS instruction

addi \$21, \$22, -50

I-Format Fields	Value	Remarks	
opcode	8	(textbook pg 94 - 101)	
rs	22	(the only source register)	
rt	21	(target register)	
immediate	-50	(in base 10)	



6.1 I-format: Example (2/2)

MIPS instruction

addi \$21, \$22, -50

Field representation in decimal:

8 22 **21** -50

Field representation in binary:

001000 10110 10101 1111111111001110

Hexadecimal representation of instruction:

2 2 D 5 F F C E₁₆



6.2 Try It Yourself #2

MIPS instruction

lw \$9, 12(\$8)

Field representation in decimal:

opcode	rs	rt	immediate
35	8	9	12

Field representation in binary:

100011 01000 01001 000000000001100

Hexadecimal representation of instruction:

8 D 0 9 0 0 0 C₁₆



6.3 Instruction Address: Overview

- As instructions are stored in memory, they too have addresses
 - Control flow instructions uses these addresses
 - E.g. beq, bne, j
- As instructions are 32-bit long, instruction addresses are word-aligned as well
- Program Counter (PC)
 - A special register that keeps address of instruction being executed in the processor



6.4 Branch: PC-Relative Addressing (1/5)


Use I-Format

- opcode specifies beq, bne
- rs and rt specify registers to compare
- What can immediate specify?
 - Immediate is only 16 bits
 - Memory address is 32 bits
 - immediate is not enough to specify the entire target address!



6.4 Branch: PC-Relative Addressing (2/5)

- How do we usually use branches?
 - Answer: if-else, while, for
 - Loops are generally small:
 - Typically up to 50 instructions
 - Unconditional jumps are done using jump instructions
 (j), not the branches
- Conclusion: A branch often changes PC by a small amount






6.4 Branch: PC-Relative Addressing (3/5)

Solution:

- Specify target address relative to the PC
- Target address is generated as:
 - PC + the 16-bit immediate field
 - The immediate field is a signed two's complement integer
- \rightarrow Can branch to $\pm 2^{15}$ bytes from the PC:
 - Should be enough to cover most loops





6.4 Branch: PC-Relative Addressing (4/5)

- Can the branch target range be enlarged?
- Observation: Instructions are word-aligned
 - Number of bytes to add to the PC will always be a multiple of 4.
 - → Interpret the **immediate** as number of words, i.e. automatically multiplied by 4_{10} (100₂)
- → Can branch to ± 2¹⁵ words from the PC
 - i.e. ± 2¹⁷ bytes from the **PC**
 - We can now branch 4 times farther!



6.4 Branch: PC-Relative Addressing (5/5)

Branch calculation:

If the branch is **not taken**:

$$PC = PC + 4$$

(PC + 4 is address of next instruction)

If the branch is taken:

$$PC = (PC + 4) + (immediate \times 4)$$

- Observations:
 - **immediate** field specifies the number of words to jump, which is the same as the number of instructions to "skip over"
 - immediate field can be positive or negative
 - Due to hardware design, add immediate to (PC+4), not to PC (more in later topic)



6.5 Branch: Example (1/3)

```
Loop: beq $9, $0, End # rlt addr: 0
add $8, $8, $10 # rlt addr: 4
addi $9, $9, -1 # rlt addr: 8
j Loop # rlt addr: 12
End: # rlt addr: 16
```

beq is anI-Formatinstruction →

I-Format Fields	Value	Remarks
opcode	4	
rs	9	(first operand)
rt	0	(second operand)
immediate	???	(in base 10)



6.5 Branch: Example (2/3)

```
$9,
                                              $0,
                                                             # rlt addr: 0
                    Loop:
                                                    End
                                beq
                                        $8, $8, $10 # rlt addr: 4
If the branch is not taken:
                                add
     PC = PC + 4
                                addi $9, $9, -1 # rlt addr: 8
(PC + 4 is address of next instruction)
If the branch is taken:
                                                             # rlt addr: 12
                                        Loop
  PC = (PC + 4) + (immediate \times 4)
                                                                rlt addr: 16
                     End:
```

immediate field:

- Number of instructions to add to (or subtract from) the PC, starting at the instruction following the branch
- In beq case, immediate = 3
- End = (PC + 4) + (immediate × 4)



6.5 Branch: Example (3/3)

```
Loop: beq $9, $0, End # rlt addr: 0
add $8, $8, $10 # rlt addr: 4
addi $9, $9, -1 # rlt addr: 8
j Loop # rlt addr: 12
End: # rlt addr: 16
```

Field representation in decimal:

opcode	rs	rt	immediate	
4	9	0	3	

Field representation in binary:

000100 01001 00000 000000000000011



6.6 Try It Yourself #3

```
Loop: beq $9, $0, End # rlt addr: 0

If the branch is not taken:
PC = PC + 4

(PC + 4 is address of next instruction)

If the branch is taken:
PC = (PC + 4) + (immediate × 4)

End:

beq $9, $0, End # rlt addr: 4

add $8, $8, $10 # rlt addr: 4

beq $0, $9, -1 # rlt addr: 12


# rlt addr: 16
```

• What would be the immediate value for the second beg instruction?

Answer: - 4




6. I-Format: Summary



NOTE:

C16_{2s} is in 2s complement arith is arithmetic operation

opco	de rs	rt	immediate
XX	rs	rt	C16 _{2s}



NOTE:

C16_{2s} is in 2s complement

1d/st is a load or store operation

opcode	rs	rt	immediate	
XX	rs	rt	C16 _{2s}	



6. I-Format: Summary

MIPS instruction c16 is raw binary (no negative) logic is logical operation \$rt, \$rs, C16 logic (bitwise operation)

immediate opcode rt rs XX C16 rt rs

MIPS instruction

branch \$rs, \$rt, label

NOTE:

NOTE:

branch is a branch operation label is converted to number first (*PC-relative addressing*)

opcode	rs	rt	immediate	
XX	rs	rt	label	

NOTE:

please note the position of rs and rt here. The first register is NOT rt but is rs instead!



7. J-Format (1/5)

- For branches, PC-relative addressing was used:
 - Because we do not need to branch too far
- For general jumps (j):
 - We may jump to anywhere in memory!
- The ideal case is to specify a 32-bit memory address to jump to
 - Unfortunately, we can't (② why?)



7. J-Format (2/5)

Define fields of the following number of bits each:

6 bits 26 bits

As usual, each field has a name:

opcode target address

- Keep opcode field identical to R-format and I-format for consistency
- Combine all other fields to make room for larger target address



7. J-Format (3/5)

We can only specify 26 bits of 32-bit address

Optimisation:

- Just like with branches, jumps will only jump to wordaligned addresses, so last 2 bits are always 00
- So, let's assume the address ends with '00' and leave them out
- → Now we can specify 28 bits of 32-bit address




7. J-Format (4/5)

- Where do we get the other 4 bits?
 - MIPS choose to take the 4 most significant bits from
 PC+4 (the next instruction after the jump instruction)
 - → This means that we cannot jump to anywhere in memory, but it should be sufficient *most of the time*
- Question:
 - What is the maximum jump range? 256MB boundary
- Special instruction if the program straddles
 256MB boundary
 - Look up jr instruction if you are interested
 - Target address is specified through a register



7. J-Format (5/5)


Summary: Given a Jump instruction





7. 256MB Boundary


- Due to the use of the first 4-bits from the PC (i.e., the memory address of the currently executed instruction), we can only jump within our <u>block</u>.
- If you are at the top of the boundary, you <u>cannot</u> jump up.
- If you are at the bottom of the boundary, you <u>cannot</u> jump down.
- Can you figure out the address of the <u>top</u> and the <u>bottom</u>? (discuss in forum)





7.1 J-Format: Example

```
jump
            $9, $0, End # addr:
Loop:
       beq
                                       target
            $8, $8, $10
       add
                          # addr:
                                  12
       addi $9, $9, -1
                          # addr:
                                  16
                            addr: 20 ← PC
            Loop
End:
                            addr: 24
```



Check your understanding by constructing the new PC value

opcode

target address

000010




7.2 Branching Far Way

Given the instruction

Assume that the address **L1** is farther away from the PC than what can be supported by **beq** and **bne** instructions

Challenge:


 Construct an equivalent code sequence with the help of unconditional (j) and conditional branch (beq, bne) instructions to accomplish this far away branching





8. Addressing Modes (1/3)

Register addressing: operand is a register



Immediate addressing: operand is a constant within the instruction itself (addi, andi, ori, slti)


```
op rs rt immediate

MIPS:
addi, andi, ori, xori, slti
```



8. Addressing Modes (2/3)


Base addressing (displacement addressing):
 operand is at the memory location whose
 address is sum of a register and a constant in
 the instruction (1w, sw)






8. Addressing Modes (3/3)

 PC-relative addressing: address is sum of PC and constant in the instruction (beg, bne)



Pseudo-direct addressing: 26-bit of instruction concatenated with upper 4-bits of PC (j)





Summary (1/2)

MIPS Instruction:32 bits representing a single instruction

R	opcode	rs	rt	rd	shamt	funct
П	opcode	rs	rt	immediate		
J	opcode	target address				

- Branches and load/store are both I-format instructions;
 but branches use PC-relative addressing, whereas
 load/store use base addressing
 IN OTHER WORDS:
- Branches use <u>PC-relative</u> addressing displayed
 Jumps use <u>pseudo-direct</u> addressing
- beq, bne: ignore PC, count displacementj: use PC, ignore displacement
- Shifts use R-format, but other immediate instructions (addi, andi, ori) use I-format



Summary (2/2)

	MIPS assembly language							
Category	Instruction	Example	Meaning	Comments				
	add	add \$s1, \$s2, \$s3	\$s1 = \$s2 + \$s3	Three operands; data in registers				
Arithmetic	subtract	sub \$s1, \$s2, \$s3	\$s1 = \$s2 - \$s3	Three operands; data in registers				
	add immediate	addi \$s1, \$s2, 100	\$s1 = \$s2 + 100	Used to add constants				
	load w ord	lw \$s1, 100(\$s2)	\$s1 = Memory [\$s2 + 100	Word from memory to register				
	store w ord	sw \$s1, 100(\$s2)	Memory[\$s2 + 100] = \$s1	Word from register to memory				
Data transfer	load byte	lb \$s1, 100(\$s2)	\$s1 = Memory [\$s2 + 100	Byte from memory to register				
	store byte	sb \$s1, 100(\$s2)	Memory[\$s2 + 100] = \$s1	Byte from register to memory				
	load upper immediate	lui \$s1, 100	\$s1 = 100 * 2 ¹⁶	Loads constant in upper 16 bits				
	branch on equal	beq \$s1, \$s2, 25	if (\$s1 == \$s2) go to PC + 4 + 100	Equal test; PC-relative branch				
Conditional	branch on not equal	bne \$s1, \$s2, 25	if (\$s1 != \$s2) go to PC + 4 + 100	Not equal test; PC-relative				
branch	set on less than	slt \$s1, \$s2, \$s3	if (\$s2 < \$s3) \$s1 = 1; else \$s1 = 0	Compare less than; for beq, bne				
	set less than immediate	slti \$s1, \$s2, 100	if (\$s2 < 100) \$s1 = 1; else \$s1 = 0	Compare less than constant				
	jump	j 2500	go to 10000	Jump to target address				
Uncondi-	jump register	jr \$ra	go to \$ra	For sw itch, procedure return				
tional jump	jump and link	jal 2500	\$ra = PC + 4; go to 10000	For procedure call				



End of File

