





SIMILAR VIDEO TUTORIAL



This video shows the replacement procedure of a similar car part on another vehicle

i Important!

This replacement procedure can be used for:

BMW 3 Convertible (E46) 323Ci 2.5, BMW 3 Convertible (E46) 320Ci 2.2, BMW 3 Convertible (E46) 325Ci 2.5, BMW 3 Convertible (E46) 318Ci 2.0, BMW 3 Convertible (E46) 320Cd 2.0

The steps may slightly vary depending on the car design.

This tutorial was created based on the replacement procedure for a similar car part on: BMW 3 Saloon (E46) 318i 1.9

CLUB.AUTODOC.CO.UK 1–13







REPLACEMENT: BRAKE CALIPER - BMW 3 CONVERTIBLE (E46). LIST OF THE TOOLS YOU'LL NEED:



- Wire brush
- WD-40 spray
- Brake cleaner
- Copper grease
- Combination spanner #9
- Flare nut spanner #14
- HEX bit No.H7.

- Wheel impact socket #17
- Ratchet wrench
- Torque wrench
- Flat Screwdriver
- Brake bleeder kit
- Crow bar
- Wheel chock

Buy tools

CLUB.AUTODOC.CO.UK 2-13







Replacement: brake caliper – BMW 3 Convertible (E46). Tip from AUTODOC experts:

- The replacement procedure is identical for the left and right brake calipers on the same axle.
- All work should be done with the engine stopped.

REPLACEMENT: BRAKE CALIPER – BMW 3 CONVERTIBLE (E46). TAKE THE FOLLOWING STEPS:

- Open the bonnet. Unscrew the brake fluid reservoir cap.
- Secure the wheels with chocks.



- Loosen the wheel mounting bolts. Use wheel impact socket #17.
- Raise the front of the car and secure on supports.
- 5 Unscrew the wheel bolts.



CLUB.AUTODOC.CO.UK 3-13







Replacement: brake caliper - BMW 3 Convertible (E46). Tip:

• To avoid injury, hold up the wheel when unscrewing the bolts.





Detach the brake caliper retaining spring. Use a flat screwdriver.



Remove the dust boot caps of the brake caliper guide pins. Use a crowbar.



Clean the area where the brake hose is connected to the caliper, and the guide pins area. Use a wire brush. Use a brake cleaner.



CLUB.AUTODOC.CO.UK 4–13








AUTODOC recommends:

 Replacement: brake caliper – BMW 3 Convertible (E46). After applying the spray, wait a few minutes.





- Clean the brake caliper fasteners. Use a wire brush. Use WD-40 spray.
- Unscrew the brake caliper fastening. Use HEX No.H7. Use a ratchet wrench.



Spread the brake pads. Use a crowbar.



CLUB.AUTODOC.CO.UK 5-13







14 Remove the brake caliper.



Replacement: brake caliper – BMW 3 Convertible (E46). AUTODOC recommends:

- When replacing the brake caliper, it is recommended to check the brake hose for damages and, if necessary, to replace it with a new one.
- When replacing a brake caliper it is recommended to replace brake pads, check the state of the brake discs and replace them with new ones if necessary.
- Check the brake caliper bracket, brake caliper guide pins and boots. Clean them.
 Replace, if necessary.
- Don't press the brake pedal after the brake caliper has been removed. As a result, the piston can fall out from the brake cylinder, and brake fluid leakage and depressurization of the system may occur.

15 Remove the brake pads.



CLUB.AUTODOC.CO.UK 6-13







Unscrew the brake hose from the brake caliper. Use a flare nut spanner #14.



Treat the brake hose. Use a brake cleaner.



Replacement: brake caliper – BMW 3 Convertible (E46). Tip from AUTODOC:

• After applying the spray, wait a few minutes.

Install and fix the brake hose into a new caliper.



19 Install the brake pads.



CLUB.AUTODOC.CO.UK 7-13







Replacement: brake caliper – BMW 3 Convertible (E46). AUTODOC experts recommend:

- If going to use the old brake pads, clean them.
- Use a wire brush.





Install the dust boot caps of the brake caliper guide pins.



Undo the brake bleeder screw. Use a combination spanner #9.



CLUB.AUTODOC.CO.UK 8-13







Connect the brake bleeder kit to the brake bleeder screw.



Bleed the brake caliper system. Without starting the engine, press the brake pedal several times until you feel significant resistance.



- Disconnect the brake bleeder kit.
- Tighten the brake caliper bleed screw. Use a combination spanner #9. Use a torque wrench. Tighten it to 10 Nm torque.



Clean dirt from the brake hose bolt. Use a brake cleaner.



CLUB.AUTODOC.CO.UK 9-13







Replacement: brake caliper – BMW 3 Convertible (E46). Tip:

• After applying the spray, wait a few minutes.





Treat the surface where the brake disc contacts the wheel rim. Use copper grease.



Clean the brake disk surface. Use a brake cleaner.



Install the wheel.



CLUB.AUTODOC.CO.UK 10-13