





### SIMILAR VIDEO TUTORIAL



This video shows the replacement procedure of a similar car part on another vehicle

# i Important!

This replacement procedure can be used for: BMW 6 Coupe (E63) 645Ci 4.4, BMW 6 Coupe (E63) 630i 3.0, BMW 6 Coupe (E63) 650i 4.8, BMW 6 Coupe (E63) 635d 3.0

The steps may slightly vary depending on the car design.

This tutorial was created based on the replacement procedure for a similar car part on: BMW 5 Saloon (E60) 520d 2.0

CLUB.AUTODOC.CO.UK 1–17







# REPLACEMENT: STRUT MOUNT – BMW 6 COUPE (E63). LIST OF THE TOOLS YOU'LL NEED:



- Wire brush
- WD-40 spray
- Brake cleaner
- Copper grease
- Combination spanner #18
- Combination spanner #22
- Drive socket # 13
- Drive socket # 18
- Torx bit T40

- HEX bit no.H7.
- Wheel impact socket #17
- Ratchet wrench
- Flat Screwdriver
- Hydraulic transmission jack
- Tap wrench
- Hydraulic strut spring compressor
- Wheel chock

**Buy tools** 

CLUB.AUTODOC.CO.UK 2-17







#### Replacement: strut mount – BMW 6 Coupe (E63). AUTODOC recommends:

- The replacement procedure is identical for the mounts of the left and right shock struts of the rear suspension.
- All mounts of the rear shock struts should be replaced simultaneously.
- All work should be done with the engine stopped.
- Be sure to replace all self-locking nuts and bolts during installation.

# REPLACEMENT: STRUT MOUNT – BMW 6 COUPE (E63). RECOMMENDED SEQUENCE OF STEPS:

1

Secure the wheels with chocks.



2

Loosen the wheel mounting bolts. Use wheel impact socket #17.



3

Raise the rear of the car and secure on supports.

CLUB.AUTODOC.CO.UK 3-17







4 Unscrew the wheel bolts.



#### AUTODOC recommends:

• Important! Hold the wheel while unscrewing the fastening bolts. BMW 6 Coupe (E63)

Remove the wheel.

6



Disconnect the ABS sensor wiring. Use a flat screwdriver.



Remove the mounting bracket of the ABS sensor wiring from the upper arm. Use a flat screwdriver.



CLUB.AUTODOC.CO.UK 4-17







- Clean all joints of the arm. Use a wire brush. Use WD-40 spray.
- 9 Unscrew the front arm fastener. Use a combination spanner #18 (2 pieces).



- Remove the front fastener of the control arm.
- Unscrew the fastener connecting the control arm to the rear knuckle. Use a combination spanner #22. Use Torx T40. Use a ratchet wrench.



Detach the suspension arm from the rear knuckle.



13 Remove the arm.



CLUB.AUTODOC.CO.UK 5-17







- Clean the shock absorber fasteners. Use a wire brush. Use WD-40 spray.
- Unscrew the lower fastener of the shock absorber strut. Use a combination spanner #18. Use a drive socket #18. Use a tap wrench.



- Remove the fastening bolt. Use a combination spanner #18. Use a flat screwdriver.
- Detach the bottom part of the shock strut.



- Lower the car.
- Open the boot lid.
- Remove the clips of the boot side lining. Use a flat screwdriver.



Detach the boot side lining.



CLUB.AUTODOC.CO.UK 6-17







Remove the suspension strut mount cap.



- Clean the fasteners of the shock strut upper mount. Use a wire brush. Use WD-40 spray.
- Unscrew the top fastening of the shock strut mount. Use a drive socket #13. Use a ratchet wrench.



# Replacement: strut mount – BMW 6 Coupe (E63). Professionals recommend:

- To avoid injuries, hold the shock strut when undoing the fastening bolts.
- Remove the suspension strut.
- Set the shock absorber strut on the spring compressor tool.



CLUB.AUTODOC.CO.UK 7–17







#### Replacement: strut mount – BMW 6 Coupe (E63). Tip from AUTODOC experts:

- Note that when using a spring compressor, spring coils need to be securely gripped, compressing the spring on the opposite sides.
- Ensure the correct position of the spring in the retainer.
- Make sure that the spring coils tightly entered the lock handles.
- Compress the spring.



- Treat the shock strut rod. Use a wire brush. Use WD-40 spray.
- Remove the strut piston rod nut. Use a combination spanner #18. Use HEX No.H7.



Remove the top strut mount. Use a flat screwdriver.



CLUB.AUTODOC.CO.UK 8-17







# Replacement: strut mount – BMW 6 Coupe (E63). Tip:

- Examine the shock absorber dust cap and the bump stop. Replace them if necessary.
- Clean the mounting seat of the shock strut mount. Use a wire brush. Use WD-40 spray.
- Install a new top shock strut mount.



Tighten the shock strut piston rod nut. Use a combination spanner #18. Use HEX No.H7. Use a torque wrench. Tighten it to 27 Nm torque.



# Replacement: strut mount – BMW 6 Coupe (E63). Tip from AUTODOC experts:

• Check to make sure the spring is positioned correctly. Avoid its misalignment.

Treat the shock strut rod. Use copper grease.

34

CLUB.AUTODOC.CO.UK 9-17







Decompress the spring.



- Remove the assembled shock strut.
- 37 Install the shock strut into the wheel arch.



38 Screw the top fastening of the shock strut mount.



#### **AUTODOC** recommends:

• BMW 6 Coupe (E63) – To avoid injury, hold the suspension strut while screwing in the fastening bolts.

CLUB.AUTODOC.CO.UK 10-17