





This video shows the replacement procedure of a similar car part on another vehicle

i Important!

This replacement procedure can be used for:

BMW 3 Saloon (E90) 320i 2.0, BMW 3 Saloon (E90) 325i 2.5, BMW 3 Saloon (E90) 330i 3.0, BMW 3 Saloon (E90) 320d 2.0, BMW 3 Saloon (E90) 318i 2.0, BMW 3 Saloon (E90) 318d 2.0, BMW 3 Saloon (E90) 330d 3.0, BMW 3 Saloon (E90) 325xi 2.5, BMW 3 Saloon (E90) 330xi 3.0, BMW 3 Saloon (E90) 330xd 3.0, BMW 3 Saloon (E90) 320si 2.0, BMW 3 Saloon (E90) 335i 3.0, BMW 3 Saloon (E90) 335d 3.0, BMW 3 Saloon (E90) 335xi 3.0, (+ 11)

The steps may slightly vary depending on the car design.

This tutorial was created based on the replacement procedure for a similar car part on: BMW 3 Coupe (E92) 330i 3.0

CLUB.AUTODOC.CO.UK 1–7





REPLACEMENT: TAILGATE STRUTS – BMW 3 SALOON (E90). TOOLS YOU'LL NEED:



Multipurpose grease

Flat Screwdriver

Buy tools

CLUB.AUTODOC.CO.UK 2-7





Replacement: tailgate struts – BMW 3 Saloon (E90). AUTODOC recommends:

- Right and left gas struts of the boot lid should be replaced simultaneously.
- The replacement procedure is identical for the right and left gas struts of the boot lid.
- All work should be done with the engine stopped.

REPLACEMENT: TAILGATE STRUTS – BMW 3 SALOON (E90). RECOMMENDED SEQUENCE OF STEPS:

1 Open the boot lid.



Release the circlip connecting the gas strut to the boot lid. Use a flat screwdriver.



CLUB.AUTODOC.CO.UK 3-7







Release the circlip connecting the gas strut to the car body. Use a flat screwdriver.



Replacement: tailgate struts – BMW 3 Saloon (E90). AUTODOC experts recommend:

- To avoid any injuries, be sure to hold the boot lid while demounting the gas struts.
- Remove the boot lid gas strut.



Clean the fasteners of the boot lid gas strut.



CLUB.AUTODOC.CO.UK 4–7







Treat the fasteners of the boot lid gas strut. Use a multipurpose grease.



7 Install the new boot lid gas strut.

Replacement: tailgate struts – BMW 3 Saloon (E90). Professionals recommend:

- To avoid any injuries, be sure to hold the boot lid while installing the gas strut.
- Snap on the circlip connecting the gas strut to the boot lid.



Snap on the circlip connecting the gas strut to the car body.



CLUB.AUTODOC.CO.UK 5-7





Check the working condition of the boot lid gas springs after they are installed.



Close the lid of the luggage compartment.





VIEW MORE TUTORIALS

CLUB.AUTODOC.CO.UK 6-7