






VIDEO TUTORIAL



(i) Important!

This replacement procedure can be used for:

BMW 3 Touring (E91) 316d 2.0, BMW 1 Coupe (E82) 118d 2.0, BMW 1 Hatchback (E81) 116i 1.6, BMW 1 Hatchback (E81) 120d 2.0, BMW 3 Saloon (E90) 320i 2.0, BMW 3 Saloon (E90) 318d 2.0, BMW 1 Hatchback (E81) 118i 2.0, BMW 1 Hatchback (E81) 118d 2.0, BMW 1 Convertible (E88) 120i 2.0, BMW 1 Convertible (E88) 125i 3.0, BMW 1 Convertible (E88) 118i 2.0, BMW 3 Saloon (E90) 316i 1.6, BMW 1 Convertible (E88) 118d 2.0, BMW 1 Hatchback (E81) 120i 2.0, BMW 1 Coupe (E82) 120d 2.0, (+8)

The steps may slightly vary depending on the car design.

CLUB.AUTODOC.CO.UK 1–13







REPLACEMENT: BRAKE PADS – BMW E90. LIST OF THE TOOLS YOU'LL NEED:



- Wire brush
- WD-40 spray
- Brake cleaner
- Anti-squeal paste
- Copper grease
- HEX bit no.H7.
- Wheel impact socket #17

- Ratchet wrench
- Torque wrench
- Brake caliper wind back tool
- Flat Screwdriver
- Crow bar
- Wheel chock

BUY TOOLS

CLUB.AUTODOC.CO.UK 2-13







Replacement: brake pads – BMW E90. Tip from AUTODOC experts:

- Perform the replacement of brake pads in complete set for each axis. This
 provides effective braking.
- The replacement procedure is identical for all brake pads on the same axle.
- Please note: all work on the car BMW E90 should be done with the engine switched off.

CARRY OUT REPLACEMENT IN THE FOLLOWING ORDER:

1

Open the bonnet. Unscrew the brake fluid reservoir cap.



Secure the wheels with chocks.

3

Loosen the wheel mounting bolts. Use wheel impact socket #17.



CLUB.AUTODOC.CO.UK 3-13







A Raise the front of the car and secure on supports.



5 Unscrew the wheel bolts.



AUTODOC recommends:

- Warning! To avoid injury, hold the wheel while unscrewing the fastening bolts.
 BMW E90
- Remove the wheel.



Detach the brake caliper retaining spring. Use a flat screwdriver.



CLUB.AUTODOC.CO.UK 4–13







Remove the dust boot caps of the brake caliper guide pins. Use a flat screwdriver.



9 Spread the brake pads. Use a crowbar.



- Clean the brake caliper fasteners. Use a wire brush. Use WD-40 spray.
- Unscrew the brake caliper fastening. Use HEX No.H7. Use a ratchet wrench.



Remove the brake caliper.



CLUB.AUTODOC.CO.UK 5–13







Replacement: brake pads – BMW E90. AUTODOC recommends:

- Tie the caliper to the suspension or to the body with a wire without disconnecting from the brake hose to prevent depressurization of the brake system.
- Make sure that the brake caliper is not hanging on the brake hose.
- Don't press the brake pedal after the brake caliper has been removed. As a result, the piston can fall out from the brake cylinder, and brake fluid leakage and depressurization of the system may occur.
- Check the brake caliper bracket, brake caliper guide pins and boots. Clean them. Replace, if necessary.

Remove the brake pads.



Replacement: brake pads - BMW E90. Tip:

• Measure the brake disc thickness. Upon reaching the wear limit the part must be replaced.

6-13 CLUB.AUTODOC.CO.UK







Clean the brake caliper bracket from dirt and dust. Use a wire brush. Use a brake cleaner.



AUTODOC recommends:

- Replacement: brake pads BMW E90. After applying the spray, wait a few minutes.
- Treat the brake caliper piston. Use a brake cleaner.



AUTODOC recommends:

- After applying the spray, wait a few minutes.
- Press in the brake caliper piston. Use brake caliper wind back tool.



CLUB.AUTODOC.CO.UK 7–13







Treat the brake pads in the area where their surface comes into contact with the brake caliper bracket. Use antisqueal paste.



Replacement: brake pads – BMW E90. Tip:

• Make sure the disc surface is clean before installing the pads.

18

Install new brake pads.



Replacement: brake pads – BMW E90. AUTODOC recommends:

• Make sure the pads are installed with linings facing the disc.

19

Install the brake caliper and fix it. Use HEX No.H7. Use a torque wrench. Tighten it to 30 Nm torque.



CLUB.AUTODOC.CO.UK 8-13







20 Install the dust boot caps of the brake caliper guide pins.



Install the brake caliper retaining spring. Use a flat screwdriver.



Treat the surface where the brake disc contacts the wheel rim. Use copper grease.



Clean the brake disk surface. Use a brake cleaner.

23



AUTODOC recommends:

 Replacement: brake pads – BMW E90. After applying the spray, wait a few minutes.

CLUB.AUTODOC.CO.UK 9-13







24 Install the wheel.

26



AUTODOC recommends:

 Warning! To avoid injury, hold the wheel while screwing in the fastening bolts on the car. BMW E90

Screw in the wheel bolts. Use wheel impact socket #17.



Lower the car and working in a cross order, tighten the wheel bolts. Use wheel impact socket #17. Use a torque wrench. Tighten it to 120 nm torque.



Replacement: brake pads – BMW E90. AUTODOC recommends:

 Without starting the engine, press the brake pedal several times until you feel significant resistance.

CLUB.AUTODOC.CO.UK 10-13