

### SIMILAR VIDEO TUTORIAL



This video shows the replacement procedure of a similar car part on another vehicle

### (i) Important!

This replacement procedure can be used for: BMW 6 Convertible (F12) 640d xDrive 3.0, BMW 6 Convertible (F12) 640d 3.0

The steps may slightly vary depending on the car design.

This tutorial was created based on the replacement procedure for a similar car part on: BMW 3 Saloon (E90) 320d 2.0

CLUB.AUTODOC.CO.UK 1–10





# REPLACEMENT: FUEL FILTER – BMW 6 CONVERTIBLE (F12). TOOLS YOU NEED:



- All-purpose cleaning spray
- Drive socket #8
- Drive socket # 13
- Torx bit T20
- Fluid container

- Flat screwdriver
- Crow bar
- Ratchet wrench
- Wheel chock

**Buy tools** 

CLUB.AUTODOC.CO.UK 2-10



#### Replacement: fuel filter – BMW 6 Convertible (F12). Tip:

- Ensure adequate ventilation of the workplace. Fuel vapors are poisonous.
- All work should be done with the engine stopped.

# REPLACEMENT: FUEL FILTER – BMW 6 CONVERTIBLE (F12). RECOMMENDED SEQUENCE OF STEPS:

- Open the fuel door.
- 2 Unscrew the fuel filler cap.
- Lift the car using a jack or place it over an inspection pit.
- Unscrew fixing bolts of the protective cover. Use a drive socket #8. Use a ratchet wrench.



Remove the protective cover.



CLUB.AUTODOC.CO.UK 3-10





6 Prepare a container for fluids.



Treat the fasteners attaching the tubes to the fuel filter. Use all-purpose cleaning spray.



Loosen the fuel filter clamps. Use a flat screwdriver.



Remove the snap ring of the fuel pressure regulator retainer clip.



Detach the fuel pressure regulator from the fuel filter. Use a crowbar.



CLUB.AUTODOC.CO.UK 4-10





## Replacement: fuel filter – BMW 6 Convertible (F12). AUTODOC experts recommend:

• Be careful! Fuel may leak from the filter housing and hoses.





Disconnect the fuel supply lines from the fuel filter.



Unscrew the fastener of the fuel filter bracket. Use Torx T20. Use a ratchet wrench.



CLUB.AUTODOC.CO.UK 5-10







Remove the fuel filter. Put the old filter cartridge in the container.



15 Install a new fuel filter.

### Replacement: fuel filter – BMW 6 Convertible (F12). AUTODOC recommends:

- Remember, it is important not to mix up the input and output of the filter. Arrows on the filter indicate the direction of fuel flow.
- During installation, take care to prevent dust and dirt from getting into the fuel filter housing.
- Attention! Use quality filters BMW 6 Convertible (F12).

Connect the fuel supply lines to the fuel filter.

17



Tighten the fuel supply line fastening. Use a flat screwdriver.



CLUB.AUTODOC.CO.UK 6-10







18 Install the bracket on the fuel filter.



Tighten the fastener of the fuel filter bracket. Use Torx T20. Use a ratchet wrench.



Tighten the fuel filter fasteners. Use a drive socket #13. Use a ratchet wrench.



Attach the fuel pressure regulator to the fuel filter. Install the snap ring of the fuel pressure regulator's retainer clip.



CLUB.AUTODOC.CO.UK 7-10





Take the fluid container away from under the fuel filter.



23 Install the protective cover.



Tighten fixing bolts of the protective cover. Use a drive socket #8. Use a ratchet wrench.



- Lower the car.
- Tighten the fuel filler cap.
- Close the fuel door.

Replacement: fuel filter – BMW 6 Convertible (F12). AUTODOC experts recommend:

• Before starting off, switch the ignition on and off several times. This should be done to activate the fuel pump to make it pump fuel through the fuel system.

CLUB.AUTODOC.CO.UK 8-10





Shut off the engine.

## Replacement: fuel filter – BMW 6 Convertible (F12). Tip:

• To protect the environment from pollution, be sure to dispose of the used filters at special collection points.



**VIEW MORE TUTORIALS** 

CLUB.AUTODOC.CO.UK 9-10