

#### VIDEO TUTORIAL



### i Important!

This replacement procedure can be used for:

BMW 3 Saloon (E36) 320i 2.0, BMW 3 Coupe (E36) 320i 2.0, BMW 3 Saloon (E36) 325i 2.5, BMW 3 Coupe (E36) 325i 2.5, BMW 3 Convertible (E36) 320i 2.0, BMW 3 Convertible (E36) 325i 2.5, BMW 3 Coupe (E36) M3 3.0, BMW 3 Convertible (E36) M3 3.0, BMW 3 Touring (E36) 320i 2.0, BMW 3 Touring (E36) 328i 2.8, BMW 3 Saloon (E36) 328i 2.8, BMW 3 Coupe (E36) 328i 2.8, BMW 3 Convertible (E36) 328i 2.8, BMW 5 Saloon (E39) 520i 2.0, BMW 5 Saloon (E39) 523i 2.5, (+ 68)

The steps may slightly vary depending on the car design.

CLUB.AUTODOC.CO.UK 1-8







### REPLACEMENT: AIR FILTER - BMW E36. TOOLS YOU MIGHT NEED:



Microfibre towel

Fender cover

**BUY TOOLS** 

CLUB.AUTODOC.CO.UK 2-8





#### Replacement: air filter – BMW E36. AUTODOC recommends:

- Follow the terms, recommendations and requirements of the part operation provided by the manufacturer.
- All work should be done with the engine stopped.

# REPLACEMENT: AIR FILTER – BMW E36. TAKE THE FOLLOWING STEPS:

Open the hood.



Use a fender protection cover to prevent damaging paintwork and plastic parts of the car.



Release the air filter cover clips.



CLUB.AUTODOC.CO.UK 3-8







4 Take off the filter lid.



#### AUTODOC recommends:

- Replacement: air filter BMW E36. To avoid damaging the part during installation, do not use excessive force.
- Remove the filter element from the filter housing.



Cover the air intake hose with a microfibre towel to prevent dust and dirt from getting into the system.



Clean the air filter cover and housing.



CLUB.AUTODOC.CO.UK 4-8



## Replacement: air filter – BMW E36. Tip from AUTODOC experts:

• Before cleaning the air filter cover and housing, cover the air duct parts, mass airflow sensor (if available), throttle valve with a clean cloth.





Insert a new filter element into the filter housing. Make sure that the filter edge fits tight to the housing.



9

#### **AUTODOC** recommends:

- Replacement: air filter BMW E36. Be sure to position the filtering element correctly. Avoid misalignment.
- Take care to only use quality filters.
- During installation, make sure to prevent dust and dirt from getting into the air filter housing.

CLUB.AUTODOC.CO.UK 5-8







10 Reinstall the air filter cover. Fasten it.



#### **AUTODOC** recommends:

- Replacement: air filter BMW E36. Do not use excessive force during installation. This may damage the part.
- Press the air filter cover clips into place.
- Remove the fender protection cover.




Close the hood.






**VIEW MORE TUTORIALS** 

CLUB.AUTODOC.CO.UK 6-8





# AUTODOC — TOP QUALITY AND AFFORDABLE CAR PARTS ONLINE



A GREAT SELECTION OF SPARE PARTS FOR YOUR CAR

**BUY SPARE PARTS FOR BMW** 

**AIR FILTER: A WIDE SELECTION** 

CLUB.AUTODOC.CO.UK 7-8